Malfunction analysis

Error Code

- **For Fixed Speed Model**

Code	Error Description
E1	Room Temperature Sensor short or open
E2	Coil Temperature Sensor short or open
E5/H6	Fan Motor error
E6/U8	Zero Crossing error
dF	Defrost error

- **For Inverter Model**

ODU Flash Light	IDU Error Code	Abnormality or Protection Description
25	**EE**	IDU EEPROM Fault
26	**F0**	IDU Fan motor Fault
27	**E1**	IDU PCB Zero-Crossing Fault
28	**F3**	IDU Evaporator Temperature Sensor Fault
29	**F1**	IDU Room Air Temperature Sensor Fault
1	**EF**	ODU EEPROM Fault
2	**F6**	IDU to ODU Communication Fault
4	**E4**	Compressor Starting Abnornal
5	**E3**	Compressor out-of-step Abnormal
6	**F9**	IPM Module Fault
8	**F5**	Compressor Discharge Temperature Sensor fault
9	**E5**	Compressor Suction Temperature Sensor fault
10	**F4**	Compressor Condenser Temperature Sensor fault
11	**F2**	Compressor Ambient Temperature Sensor fault
12	**E2**	Outdoor DC Fan motor fault
13	**P2**	ODU AC Current protection
14	**P0**	Compressor phase Current protection
15	**P7**	ODU over-high/over-low AC Voltage Protection
16	**P8**	ODU over-high/over-low DC Voltage Protection
17	**P9**	IPM Overheat temperature protection
18	**P1**	Compressor Discharge Temperature Overheat protection
19	**P5**	Cooling Indoor unit coil anti-freezing protection
20	**P6**	Cooling Outdoor coil Overheat protection
21	**P4**	Heating indoor coil Overheat protection
22	**PA**	Cooling outdoor ambient temperature over-low protection
23	**PE**	Heating outdoor ambient temperature over-high protection

⚠ WARNING

- When below phenomenon occurs, please turn off air conditioner and disconnect power immediately, and then contact the dealer or qualified professionals for service.
  - Power cord is overheating or damaged.
  - There is abnormal sound during operation.
  - Circuit break trips off frequently.
  - Air conditioner gives off burning smell.
  - Indoor unit is leaking.
- Do not repair or refit the air conditioner by yourself.
- If the air conditioner operates under abnormal conditions, it may cause malfunction, electric shock or fire hazard.