Error Codes

Error Code

ERROR SIGNALS ON THE DISPLAY FOR FIXED SPEED MODELS

Code	Error Description
E1	Ambient/Room temperature sensor fault
E2	Evaporator/Coil temperature sensor fault
dF	Defrost protection

ERROR SIGNALS ON THE DISPLAY FOR INVERTER MODELS

Code	Error Description
EE	Indoor machine EE fault
E3	Indoor coil sensor fault
E4	Indoor ambient temperature sensor fault
E0	Outdoor EE fault
E6	main board and drive board communication fault
F1	Compressor starting abnormal (phase, failure, reverse)
F2	Compressor out of step fault
F3	IPM module fault
F5	Discharge temperature sensor fault
F8	Outdoor ambient temperature sensor fault

Testing Frequency Setting Method

Full-Capacity

1. Switch on the AC and wait for compressor start working, set the mode to cooling Mode and temperature to 16°C and Fan speed high by remote controller.
2. Press the "DISPLAY" button on remote controller 8 time continuously .

Half-Capacity

1. Switch on the AC and wait for compressor start working, set the mode to cooling Mode and temperature to 17°C and Fan speed high by remote controller.
2. Press the "DISPLAY" button on remote controller 8 time continuously .

(These setting are for laboratory testing and hence not to be used for normal operation)

Note:- Full / Half Capacity are applicable for INVERTER Models.