Product Version ICADVM20.1 October 2020 © 2020 Cadence Design Systems, Inc. All rights reserved. Printed in the United States of America.

Cadence Design Systems, Inc. (Cadence), 2655 Seely Ave., San Jose, CA 95134, USA.

Open SystemC, Open SystemC Initiative, OSCI, SystemC, and SystemC Initiative are trademarks or registered trademarks of Open SystemC Initiative, Inc. in the United States and other countries and are used with permission.

Trademarks: Trademarks and service marks of Cadence Design Systems, Inc. contained in this document are attributed to Cadence with the appropriate symbol. For queries regarding Cadence's trademarks, contact the corporate legal department at the address shown above or call 800.862.4522. All other trademarks are the property of their respective holders.

Restricted Permission: This publication is protected by copyright law and international treaties and contains trade secrets and proprietary information owned by Cadence. Unauthorized reproduction or distribution of this publication, or any portion of it, may result in civil and criminal penalties. Except as specified in this permission statement, this publication may not be copied, reproduced, modified, published, uploaded, posted, transmitted, or distributed in any way, without prior written permission from Cadence. Unless otherwise agreed to by Cadence in writing, this statement grants Cadence customers permission to print one (1) hard copy of this publication subject to the following conditions:

- 1. The publication may be used only in accordance with a written agreement between Cadence and its customer.
- 2. The publication may not be modified in any way.
- 3. Any authorized copy of the publication or portion thereof must include all original copyright, trademark, and other proprietary notices and this permission statement.
- 4. The information contained in this document cannot be used in the development of like products or software, whether for internal or external use, and shall not be used for the benefit of any other party, whether or not for consideration.

Disclaimer: Information in this publication is subject to change without notice and does not represent a commitment on the part of Cadence. Except as may be explicitly set forth in such agreement, Cadence does not make, and expressly disclaims, any representations or warranties as to the completeness, accuracy or usefulness of the information contained in this document. Cadence does not warrant that use of such information will not infringe any third party rights, nor does Cadence assume any liability for damages or costs of any kind that may result from use of such information.

Restricted Rights: Use, duplication, or disclosure by the Government is subject to restrictions as set forth in FAR52.227-14 and DFAR252.227-7013 et seq. or its successor.

Contents

<u> Preface</u>	. 9
<u>Scope</u>	10
Licensing Requirements	
Related Documentation	
What's New and KPNS	
Installation, Environment, and Infrastructure	
Technology Information	
Virtuoso Tools	
SKILL Documents	
Additional Learning Resources	
<u>Video Library</u>	
Virtuoso Videos Book	
Rapid Adoption Kits	
Help and Support Facilities	
Customer Support	
Feedback about Documentation	
Understanding Cadence SKILL	15
Using SKILL Code Examples	15
Sample SKILL Code	
Accessing API Help	16
Typographic and Syntax Conventions	17
Identifiers Used to Denote Data Types	18
1	
_	
Parameterized Cell Functions	21
Safety Rules for Creating SKILL Pcells	22
Calling SKILL Procedures from within Pcells	23
Using Macros in Pcell SKILL Code	23
Physical Limits for Functions	23
Recommended, Supported SKILL Functions for Pcells	24
Finding Supported SKILL Functions	

Using print Functions in a Pcell	
Enclosing the Body of Code in a let or prog for Local Variables	26
What to Avoid When Creating Pcells	27
About Pcell Super and Submaster Cells	29
Using the SKILL Operator ~> with Pcells	29
pc Functions for SKILL Pcell Code	31
pcExprToString	32
pcTechFile	33
2	
Graphical Parameterized Cell Functions	4
•	
Graphical Pcell Functions	
pcColinearPoints	
pcConcatOrient	
pcDefineCondition	
<u>pcDefineInheritParam</u>	
pcDefineParamCell	
pcDefineParamLabel	9
pcDefineParamLayer	10
pcDefineParamPath	12
pcDefineParamPolygon	14
pcDefineParamProp	16
pcDefineParamRect	17
pcDefineParamRefPointObject	18
pcDefinePathRefPointObject	19
pcDefinePCell	20
pcDefineParamSlot	24
pcDefinePPCell	25
pcDefineRepeat	31
pcDefineSteppedObject	
pcDefineStretchLine	
pcDeleteCondition	
pcDeleteParam	
pcDeleteParamLayer	
pcDeleteParamProp	

pcDeleteParamShape	. 42
pcDeleteRefPoint	. 43
pcDeleteRepeat	. 44
pcDeleteSteppedObject	. 45
pcDraw	. 46
pcExprToProp	. 48
pcFilterPoints	. 49
pcFix	. 50
pcGetBendAngle	. 53
pcGetCodeParamNames	. 54
pcGetCodeParamValue	. 55
pcGetConditions	. 56
pcGetDefaultParamsFromClass	. 57
pcGetInheritParamDefn	. 58
pcGetInheritParams	. 59
pcGetOffsetPath	. 60
pcGetOffsetPolygon	. 62
pcGetParamSlotType	. 64
pcGetPathRefPoint	. 65
pcGetParameters	. 68
pcGetParamLabelDefn	. 69
pcGetParamLabels	. 70
pcGetParamLayers	. 71
pcGetParamLayerDefn	. 72
pcGetParamProps	
pcGetParamShapeDefn	. 74
pcGetParamShapes	
pcGetParamSlotValue	
pcGetRefPointDefn	
pcGetRefPoints	
pcGetRepeatDefn	
pcGetRepeats	
pcGetStepDirection	
pcGetSteppedObjectDefn	
pcGetSteppedObjects	
pcGetStretchDefn	

pcGetStretches	. 85
pcGetStretchSummary	. 86
pcGrowBox	. 87
pcGrowPoints	. 89
pcHICompileToSkill	. 91
pcHIDefineCondition	. 92
pcHIDefineInheritedParameter	. 93
pcHIDefineLabel	. 94
pcHIDefineLayer	. 95
pcHIDefineParamCell	. 96
pcHIDefineParameterizedShape	. 97
pcHIDefineParamRefPointObject	. 98
pcHIDefinePathRefPointObject	. 99
pcHIDefineProp	100
pcHIDefineRepeat	101
pcHIDefineSteppedObject	102
pcHIDefineStretch	103
pcHIDeleteCondition	104
pcHIDeleteLayer	105
pcHIDeleteParameterizedShape	106
pcHIDeleteProp	107
pcHIDeleteRefPointObject	108
pcHIDeleteRepeat	109
pcHIDeleteSteppedObject	110
pcHIDisplayCondition	111
pcHIDisplayInheritedParameter	
pcHIDisplayLayer	
pcHIDisplayParameterizedShape	
pcHIDisplayParams	
pcHIDisplayProp	
pcHIDisplayRefPointObject	
pcHIDisplayRepeat	
pcHIDisplaySteppedObject	
pcHIEditParameters	
pcHIModifyCondition	
pcHIModifyLabel	

pcHIModifyLayer	 . 123
pcHIModifyParams	 . 124
pcHIModifyRefPointObject	 . 125
pcHIModifyRepeat	 . 126
pcHIModifySteppedObject	 . 127
pcHIModifyStretchLine	 . 128
pcHIQualifyStretchLine	 . 129
pcHIRedefineStretchLine	 . 130
pcHISummarizeParams	 . 131
pclsParamSlot	 . 132
pcModifyParam	 . 133
pcRedefineStretchLine	 . 134
pcRestrictStretchToObjects	 . 136
pcRound	 . 137
pcSetFTermWidth	 . 139
pcSetParamSlotsFromMaster	 . 140
pcSetParamSlotValue	 . 141
pcSkillGen	 . 142
pcStepAlongShape	 . 144
<u>auHiUltraPCell</u>	 . 146
Pcell Compiler Customization SKILL Functions	 . 148
pcUserAdjustParameters	 . 149
pcUserGenerateArray	 . 150
pcUserGenerateInstance	 . 151
pcUserGenerateInstancesOfMaster	 . 152
pcUserGenerateLPP	 . 154
pcUserGeneratePin	 . 155
pcUserGenerateProperty	 . 156
pcUserGenerateShape	 . 157
pcUserGenerateTerminal	 . 158
pcUserInitRepeat	 . 159
pcUserPostProcessCellView	 . 160
pcUserPostProcessObject	 . 161
pcUserPreProcessCellView	 . 162
pcUserSetTermNetName	 . 163
Parameterized Cell SKILL Cross-Reference Table	164

<u>3</u>		
<u>E</u>	xpress Pcells Data Management Functions	169
	dbClearPcellCache	170
	dbSavePcellCache	171
	dbSavePcellCacheForCV	172
	dbSavePcellCacheForCVOnly	173
	dbUpdatePcellCache	174
	xpcEnableExpressPcell	175
	xpcDumpCache	176

Preface

This document provides information about creating parameterized cells (Pcells) using Cadence[®] SKILL language and the Pcell graphical user interface (GUI). It describes the safety rules for creating SKILL Pcells, information about Pcell master cells and submaster cells, and descriptions of the supported pc functions. This user guide describes how to create graphical and SKILL Pcells.

/Important

Only the functions and arguments described in this manual are available for public use. Any undocumented functions or arguments are likely to be private and could be subject to change without notice. It is recommended that you check with your Cadence representative before using them.

This user guide is aimed at CAD developers and designers of integrated circuits and assumes that you are familiar with:

- The Virtuoso design environment and application infrastructure mechanisms designed to support consistent operations between all Cadence[®] tools.
- The applications used to design and develop integrated circuits in the Virtuoso design environment, notably, the Virtuoso Layout Suite, and Virtuoso Schematic Editor.
- The Virtuoso design environment technology file.

This preface contains the following topics:

- Scope
- Licensing Requirements
- Related Documentation
- Additional Learning Resources
- Customer Support
- Feedback about Documentation
- Understanding Cadence SKILL
- Typographic and Syntax Conventions

Identifiers Used to Denote Data Types

Scope

Unless otherwise noted, the functionality described in this guide can be used in both mature node (for example, IC6.1.8) and advanced node and methodologies (for example, ICADVM20.1) releases.

Label	Meaning
(ICADVM20.1 Only)	Features supported only in ICADVM20.1 advanced nodes and advanced methodologies releases.
(IC6.1.8 Only)	Features supported only in mature node releases.

Licensing Requirements

For information on licensing in the Virtuoso design environment, see the <u>Virtuoso Software</u> <u>Licensing and Configuration Guide</u>.

Related Documentation

What's New and KPNS

- Virtuoso Parameterized Cell What's New
- <u>Virtuoso Parameterized Cell Known Problems and Solutions</u>

Installation, Environment, and Infrastructure

- Virtuoso Parameterized Cell SKILL Reference
- Virtuoso Relative Object Design User Guide
- <u>Sample Parameterized Cells Installation and Reference</u>
- Cadence Installation Guide

Preface

- <u>Virtuoso Design Environment User Guide</u>
- Cadence Application Infrastructure User Guide
- Component Description Format User Guide

Technology Information

- <u>Virtuoso Technology Data User Guide</u>
- Virtuoso Technology Data ASCII Files Reference
- Virtuoso Technology Data SKILL Reference

Virtuoso Tools

- <u>Virtuoso Layout Suite SKILL Reference</u>
- Virtuoso Layout Suite XL User Guide
- Virtuoso Schematic Editor L User Guide
- Virtuoso Space-based Router User Guide
- <u>Virtuoso Design Rule Driven Editing User Guide</u>
- <u>Virtuoso Relative Object Design User Guide</u>
- <u>Design Data Translator's Reference</u>

SKILL Documents

- <u>Virtuoso Design Environment SKILL Reference</u>
- Cadence SKILL Language User Guide
- <u>Cadence SKILL Language Reference</u>
- Cadence SKILL Development Reference
- Virtuoso Technology Data SKILL Reference
- Virtuoso Layout Suite SKILL Reference
- Virtuoso Schematic Editor SKILL Reference
- Cadence User Interface SKILL Reference

<u>Cadence Interprocess Communication SKILL Reference</u>

Additional Learning Resources

Video Library

The <u>Video Library</u> on the Cadence Online Support website provides a comprehensive list of videos on various Cadence products.

To view a list of videos related to a specific product, you can use the *Filter Results* feature available in the pane on the left. For example, click the *Virtuoso Layout Suite* product link to view a list of videos available for the product.

You can also save your product preferences in the Product Selection form, which opens when you click the *Edit* icon located next to *My Products*.

Virtuoso Videos Book

You can access certain videos directly from Cadence Help. To learn more about this feature and to access the list of available videos, see Virtuoso Videos.

Rapid Adoption Kits

Cadence provides a number of <u>Rapid Adoption Kits</u> that demonstrate how to use Virtuoso applications in your design flows. These kits contain design databases and instructions on how to run the design flow.

To explore the full range of training courses provided by Cadence in your region, visit <u>Cadence Training</u> or write to training_enroll@cadence.com.

Note: The links in this section open in a separate web browser window when clicked in Cadence Help.

Help and Support Facilities

Virtuoso offers several built-in features to let you access help and support directly from the software.

■ The Virtuoso *Help* menu provides consistent help system access across Virtuoso tools and applications. The standard Virtuoso *Help* menu lets you access the most useful help

and support resources from the Cadence support and corporate websites directly from the CIW or any Virtuoso application.

■ The Virtuoso Welcome Page is a self-help launch pad offering access to a host of useful knowledge resources, including quick links to content available within the Virtuoso installation as well as to other popular online content.

The Welcome Page is displayed by default when you open Cadence Help in standalone mode from a Virtuoso installation. You can also access it at any time by selecting *Help – Virtuoso Documentation Library* from any application window, or by clicking the *Home* button on the Cadence Help toolbar (provided you have not set a custom home page).

For more information, see <u>Getting Help</u> in *Virtuoso Design Environment User Guide*.

Customer Support

For assistance with Cadence products:

Contact Cadence Customer Support

Cadence is committed to keeping your design teams productive by providing answers to technical questions and to any queries about the latest software updates and training needs. For more information, visit https://www.cadence.com/support.

Log on to Cadence Online Support

Customers with a maintenance contract with Cadence can obtain the latest information about various tools at https://support.cadence.com.

Feedback about Documentation

You can contact Cadence Customer Support to open a service request if you:

- Find erroneous information in a product manual
- Cannot find in a product manual the information you are looking for
- Face an issue while accessing documentation by using Cadence Help

You can also submit feedback by using the following methods:

■ In the Cadence Help window, click the *Feedback* button and follow instructions.

On the Cadence Online Support <u>Product Manuals</u> page, select the required product and submit your feedback by using the <i>Provide Feedback</i> box.				

Understanding Cadence SKILL

Cadence SKILL is a high-level, interactive programming language based on the popular artificial intelligence language, Lisp. It lets you customize and extend your design environment. Using SKILL you can validate the steps of your algorithm incrementally before incorporating them into a larger program.

For more information about the SKILL language, see <u>Getting Started</u> in the *SKILL Language User Guide*.

Using SKILL Code Examples

The SKILL APIs in this user manual are explained with illustrative code examples.

You can copy these examples from the manual and paste them directly into the Command Interpreter Window (CIW) or use the code in non-graphical SKILL mode.

Sample SKILL Code


The following code sample shows the syntax of a SKILL API that accepts three arguments.

axIGetRunStatus

The first argument $t_sessionName$ is a required argument, where t signifies the data type of the argument. The second and third arguments ?optionName $t_optionName$ and ?historyName $t_historyName$ are optional keyword arguments (identified by a question mark), which are specified in name-value pairs and can be placed in any order during the function call.

The return value is the value that the SKILL API returns after evaluating the expression. In this case, it is a list of status values, <code>l_statusValues</code>.

Example



Accessing API Help

Quick reference information for SKILL APIs is available from the CIW and the SKILL API Finder. To access the reference information for a particular SKILL API, do one of the following:

- Type help <function_name> in the CIW.
- Type startFinder ([?funcName $t_functionName$]) in the CIW.
- Start the <u>SKILL API Finder</u> from the CIW by choosing *Tools Finder* or type cdsFinder on the UNIX command line.

In the *Search in* field of the displayed Cadence SKILL API Finder window, type the SKILL API name for which you want to display the help information and click *Go*.

The matches for the searched SKILL API appear in the *Results* area.

To view the complete documentation of the searched SKILL API, select the API name in the *Results* area and click the *More Info* button. The complete documentation of the selected SKILL API appears in a new Cadence Help window.

Typographic and Syntax Conventions

The following typographic and syntax conventions are used in this manual.

text	Indicates names of manuals, menu commands, buttons, and fields.
text	Indicates text that you must type exactly as presented. Typically used to denote command, function, routine, or argument names that must be typed literally.
z_argument	Indicates text that you must replace with an appropriate argument value. The prefix (in this example, z_{-}) indicates the data type the argument can accept and must not be typed.
	Separates a choice of options.
{ }	Encloses a list of choices, separated by vertical bars, from which you must choose one.
[]	Encloses an optional argument or a list of choices separated by vertical bars, from which you may choose one.
[?argName t_arg]	
	Denotes a <i>key argument</i> . The question mark and argument name must be typed as they appear in the syntax and must be followed by the required value for that argument.
•••	name must be typed as they appear in the syntax and must be
•••	name must be typed as they appear in the syntax and must be followed by the required value for that argument.
•••	name must be typed as they appear in the syntax and must be followed by the required value for that argument. Indicates that you can repeat the previous argument. Used with brackets to indicate that you can specify zero or more
····	name must be typed as they appear in the syntax and must be followed by the required value for that argument. Indicates that you can repeat the previous argument. Used with brackets to indicate that you can specify zero or more arguments. Used without brackets to indicate that you must specify at least
···· ->	name must be typed as they appear in the syntax and must be followed by the required value for that argument. Indicates that you can repeat the previous argument. Used with brackets to indicate that you can specify zero or more arguments. Used without brackets to indicate that you must specify at least one argument. Indicates that multiple arguments must be separated by

If a command-line or SKILL expression is too long to fit within the paragraph margins of this document, the remainder of the expression is moved to the next line and indented. In code excerpts, a backslash (\) indicates that the current line continues on to the next line.

Identifiers Used to Denote Data Types

The Cadence SKILL language supports several data types to identify the type of value you can assign to an argument.

Data types are identified by a single letter followed by an underscore; for example, t is the data type in $t_viewNames$. Data types and the underscore are used as identifiers only; they should not be typed.

Prefix	Internal Name	Data Type
а	array	array
A	amsobject	AMS Object
b	ddUserType	DDPI object
В	ddCatUserType	DDPI Category Object
C	opfcontext	OPF context
d	dbobject	Cadence database object (CDBA)
е	envobj	environment
f	flonum	floating-point number
F	opffile	OPF file ID
g	general	any data type
G	gdmSpecIIUserType	gdm spec
h	hdbobject	hierarchical database configuration object
K	mapiobject	MAPI object
1	list	linked list
L	tc	Technology file time stamp
m	nmpllUserType	nmpll user type
M	cdsEvalObject	_
n	number	integer or floating-point number
0	userType	user-defined type (other)
p	port	I/O port
q	gdmspecListIIUserType	gdm spec list

Prefix	Internal Name	Data Type
r	defstruct	defstruct
R	rodObj	relative object design (ROD) object
S	symbol	symbol
S	stringSymbol	symbol or character string
t	string	character string (text)
T	txobject	Transient Object
и	function	function object, either the name of a function (symbol) or a lambda function body (list)
U	funobj	function object
V	hdbpath	_
W	wtype	window type
X	integer	integer number
Y	binary	binary function
&	pointer	pointer type

For more information, see *Cadence SKILL Language User Guide*.

1

Parameterized Cell Functions

This chapter provides information about creating parameterized cells (Pcells) using Cadence[®] SKILL language instead of using the graphical user interface. It includes safety rules for creating SKILL Pcells, information about Pcell master cells and submaster cells, and descriptions of supported pc functions.

Most of the supported pc SKILL functions listed in this chapter correspond to the commands available only through the graphical user interface, and they can only be used to create Pcells for the graphical Pcell environment. However, there are four pc Pcell functions that you can use within the body of SKILL Pcell code:

- pcExprToString
- pcFix
- pcRound
- pcTechFile

To read more about pc functions that you can use within Pcell code, see <u>Recommended</u>, <u>Supported SKILL Functions for Pcells</u> on page 24. For a description of the four pc Pcell functions listed above, see <u>pc Functions for SKILL Pcell Code</u> on page 31, later in this chapter.

Note: We recommend using Virtuoso[®] relative object design (ROD) functions in your Pcell code. ROD is a high-level language for defining layout connectivity, geometries, and the relationships between them. For information about ROD, see the *Virtuoso Relative Object Design User Guide*.

This section contains the following information:

Safety Rules for Creating SKILL Pcells on page 22

Calling SKILL Procedures from within Pcells on page 23

Using Macros in Pcell SKILL Code on page 23

Physical Limits for Functions on page 23

Parameterized Cell Functions

Recommended, Supported SKILL Functions for Pcells on page 24

About Pcell Super and Submaster Cells on page 29

pc Functions for SKILL Pcell Code on page 31

Safety Rules for Creating SKILL Pcells

This section provides important rules for creating SKILL Pcells, including which functions are safe to use and what to avoid.



If you use SKILL functions that are unsupported or not intended for use in Pcells, your Pcell code will be liable to fail when you try to translate your design to a format for use with a non-Virtuoso Cadence application or third-party application.

The purpose of creating a Pcell is to *automate the creation of data*. Pcells should be designed as standalone entities, independent of the environment in which they are created and independent of the variety of environments in which you or someone else might want to use them. An environment can react to a Pcell, but Pcell code should not react to, interact with, or be dependent on an environment.

Although it is possible to create Pcells that depend on something in your current or local environment, and that use either unsupported or unrecommended functions, your Pcell code is likely to fail when you try to translate it for us in a different environment. And although it is possible to load, read, and write to files in the UNIX file system from within a Pcell, do not do so. You cannot control the file permission settings in other locations, so reading or writing from a Pcell can cause the Pcell to fail in other directories, other environments, and during evaluation by translators.

Functions that are not supported for use by customers within SKILL Pcells usually belong to specific applications (tools); they are unknown to other environments, to other tools, and to data translators. For example, if you create a Pcell in the icfb environment and include place-and-route functions, the Pcell will fail in the layout environment. Also, application-specific functions that are not supported for customer use can disappear or change without notice.

Create Pcells using only the recommended, supported functions. You can identify them by their prefixes. However, you can also use all of the basic SKILL language functions defined in the <u>Cadence SKILL Language Reference</u>; these functions do not have prefixes. To use only recommended, supported, documented functions, follow the rules in this section.

Parameterized Cell Functions

Calling SKILL Procedures from within Pcells

You can call your own SKILL procedures from within Pcells. However, the code in procedures called by Pcells must follow all of the safety rules described in this section. The safety rules apply to all code that is evaluated when the system evaluates a Pcell, and that includes SKILL procedures called by the Pcell.

Called procedures are not compiled with the Pcell, so you must make sure they are loaded before the system evaluates the Pcell. You can do this by attaching the code files to your library; then the system automatically loads the procedures the first time it accesses the library.

For information about how to attach code files to a library, see "How to Package a Pcell" in the *Virtuoso Parameterized Cell Reference*.

Using Macros in Pcell SKILL Code

Macros in Pcells are only expanded one level. You can include macros that do not reference or contain other macros (are not nested) in your Pcell SKILL code, and they will be expanded successfully.

To include a nested macro in a Pcell, it is recommended that you use an explicit function call in the Pcell code section of the pcDefinePCell function, and make sure that the function is defined and available (loaded) prior to any evaluation of the Pcell. This is usually done by including the function in your libInit.il file. If you do not use this method for nested macros, the nested code is treated as an undefined function, causing the Pcell evaluation to fail.

Physical Limits for Functions

You can avoid creating a Pcell that is too large to be processed or displayed by not exceeding the physical limitations for SKILL functions. The following section is copied from the <u>Cadence SKILL Language User Guide</u>, <u>Chapter 3</u>, "Creating Functions in SKILL":

The following physical limitations exist for functions:

- Total number of required arguments is less than 65536
- Total number of *keyword/optional* arguments is less than 255
- Total number of local variables in a let is less than 65536
- Total number of local variables in a let must be less than 65536

Parameterized Cell Functions

Max size of code vector is less than 1GB

By default, code vectors are limited to functions that can compile less than 32KB words. This translates roughly into a limit of 20000 lines of SKILL code per function. The maximum number of arguments limit of 32KB is mostly applicable in the case when functions are defined to take an @rest argument or in the case of app1y called on an argument list longer than 32KB elements.

Recommended, Supported SKILL Functions for Pcells

When you create SKILL routines within Pcells, use only the following functions:

- The SKILL functions documented in the <u>Cadence SKILL Language Reference</u>; for example, car, if, foreach, sprintf, while.
- SKILL functions from the following families:

db dd cdf rod tech abe cst tx

■ The following four pc SKILL functions, which are documented in this chapter:

pcExprToString pcFix

<u>pcRound</u> <u>pcTechFile</u>

You can use only these four pc SKILL functions because

- Most supported pc functions correspond to the graphical user interface commands. You can use them to create Pcells in the graphical Pcell environment, but you cannot use them in the body of SKILL Pcell code.
- Both the Pcell graphical user interface and the Pcell compiler are coded using pc
 SKILL functions. You cannot use the graphical user interface or compiler functions at all.

For a description of the four pc SKILL functions you can use in the body of Pcell code, see <u>"pc Functions for SKILL Pcell Code"</u> on page 31.

Parameterized Cell Functions

Finding Supported SKILL Functions

You can use either the listFunctions command or the Cadence Finder quick reference tool to list supported functions. But remember, you cannot use most supported functions within your Pcell code.

Note: In releases prior to 4.4.3, the listFunctions command displayed a list of all SKILL functions. Starting with release 4.4.3, the listFunctions command displays only public SKILL functions. *Public SKILL functions* are supported by Cadence for use by customers. If you are using a software release prior to 4.4.3 and use the listFunctions command to display Pcell functions, the list returned is misleading because it includes pc functions used to code the graphical user interface and compiler.

You can use the Finder tool to quickly check which SKILL functions are documented and supported for the db, dd, cdf, rod, and tech SKILL families.

Using the Finder Tool

To use the Finder tool, follow the steps below.

in alphabetical order in the *Matches* field.

- 1. Start the Finder by doing one of the following: From within the Cadence Design Framework II product (DFII), choose Tools -SKILL Development and click Finder. In a UNIX window, type cdsFinder. **2.** To display the supported SKILL functions, For Searching, select All Available Finder Data. For Search String, click at beginning. In the data entry area below Search String, type the function prefix. For example, type tech. Click Search. All of the supported, documented SKILL functions for the prefix you entered appear
- 3. To see the arguments and a short description for a function that is listed in the *Matches* field, click the function name.

The syntax and a brief description of the selected function appear in the Descriptions window. You might need to scroll up to see the syntax.

Parameterized Cell Functions

4. If necessary, scroll up to see the syntax.

For functions that have keyword-value pairs for arguments, each argument probably wraps to the next line.

- **5.** If the arguments are wrapping, make the Finder window wider by stretching the lower-left corner.
- **6.** Before selecting another function, click the *Clear* button.

Using print Functions in a Pcell

You cannot print or generate output from a Pcell, as it causes the Pcell evaluation to fail. However, you can bypass the system processing for print functions by using the fprintf or println function to print directly to stdout (standard output) in the format shown below:

```
fprintf( stdout ... )
println( variable stdout )
where variable is your variable name. For example
fprintf( stdout "myVariable = %L \n" myVariable )
```

Using printf or println in a Pcell

If you use the printf or println function in a Pcell, the output is treated as an error. In a cellview, errors are indicated by flashing markers. You can query the error in the cellview, change your Pcell code to fix the error, and recompile your Pcell.

To query markers, do the following:

- **1.** Choose *Verify Markers Explain*.
- 2. Click a flashing marker.

A dialog box appears, showing the text printed from the Pcell by the printf or println function.

Enclosing the Body of Code in a let or prog for Local Variables

When you use local variables in the body of SKILL Pcell code in a pcDefinePCell
statement, be sure to enclose the Pcell code in a let or prog statement, and define all variables used in the Pcell code at the beginning of the let or prog statement. Defining variables as part of a let or prog prevents conflicts with variables used by the Pcell compiler.

Parameterized Cell Functions

Using let gives faster performance than prog; prog allows multiple exits while let exits only at its end.

What to Avoid When Creating Pcells

When creating a Pcell, do not use functions with prefixes other than db, dd, cdf, rod, and tech. Although it is possible to call procedures with other prefixes from within a Pcell, you will not be able to view the Pcell in a different environment or translate it into the format required by another database. Most translators, including the physical design translators, can translate only basic SKILL functions; the four pc functions; and functions in the SKILL families db, dd, cdf, rod, and tech.

Specifically, **do not** use functions with application-specific prefixes such as ael, abs, de, ge, hi, las, le, pr, and sch. Procedures in any application-specific family are at a higher level of functionality than can be used in a Pcell safely. For example, if you create a Pcell using le functions, the Pcell works only in environments that include the Virtuoso layout editor. You cannot use a translator to export your design from the DFII database.

When a translator cannot evaluate a function, one of the following happens:

- The translator fails and issues an undefined function error message.
- The translator continues, issues a warning message, and translates the data incorrectly.

To make your design translate successfully, you must resolve undefined functions in Pcells. You can do this by flattening the Pcells, which results in a loss of hierarchy and parameterization, or by rewriting the Pcell code to eliminate the undefined functions.

Important

Here are more important rules for creating Pcells. In your Pcell code,

- □ Do not prompt the user for input.
- Do not generate messages; message output is interpreted as an error.
- □ Do not load, read, or write to files in the UNIX file system.
- Do not run any external program that starts another process.
- If you need to drive external programs to calculate cell shapes, you can do this in SKILL. Use CDF callback procedures to save the resulting list of coordinate pairs in a string, and then pass the string as input to a SKILL Pcell.

This method has the advantage that the external program needs to be called only once per instance, not each time the design is opened. For more information about

Parameterized Cell Functions


- callback procedures, refer to "<u>Using the Component Description Format</u>" in the *Virtuoso Parameterized Cell Reference*.
- Do not generate output with print functions, except as described in <u>"Using print Functions in a Pcell"</u> on page 26.

For more information about creating SKILL Pcells, also see

- The "Creating SKILL Parameterized Cells" chapter in the Virtuoso Parameterized Cell Reference
- How to use relative object design functions (with the prefix rod) to create geometry for Pcells in the *Virtuoso Relative Object Design User Guide*

About Pcell Super and Submaster Cells

The master cell of a Pcell has two levels: a (super) master cell in the database and one or more temporary submaster cells in virtual memory. The Parameterized Cell software creates one submaster cell in virtual memory for each unique set of parameter values assigned to an instance of the (super) master cell.



A submaster cell resides in virtual memory for the duration of your editing session and is accessible by all cellviews. When you create an instance in a cellview, and a submaster with the same parameter values already exists in virtual memory, no new submaster is generated; the new instance references the existing submaster cell.

When you close all cellviews that reference a particular submaster cell, the database software automatically purges (removes) the referenced submaster cell from virtual memory but does not remove the master Pcell from your disk.

When you edit an editing session by exiting the Cadence software, the database software automatically purges (removes) all submaster cells from virtual memory. Purging does not remove master Pcells from your disk.

Using the SKILL Operator ~> with Pcells

When you use the SKILL operator ~> to access information about the master cell of a Pcell instance, you must look two levels above the instance. If you look at only one level above, you access information about the Pcell submaster.

For example, for the instance I1 of the Pcell master mux2, you retrieve the database identity (dbId) of the mux2 Pcell master with the following statement:

I1~>master~>superMaster

Parameterized Cell Functions

But if	you	use	the	staten	nent
--------	-----	-----	-----	--------	------

I1~>master

you retrieve the $\ensuremath{\textit{dbId}}$ for the Pcell submaster.

Parameterized Cell Functions

pc Functions for SKILL Pcell Code

When you create SKILL routines within Pcells, use only the following pc functions:

- pcExprToString
- pcTechFile
- pcFix
- pcRound

Note: See pcRound and pcFix under "Graphic Parameterized Cell SKILL Functions".

Parameterized Cell Functions

pcExprToString

```
pcExprToString(
    g_ilExpr
)
=> t string
```

Description

Converts a SKILL expression to a string. The Pcell compiler uses this function to create labels that display the value of an expression as a string enclosed in quotes.

Argument

 g_ilExpr

SKILL expression you want to convert to a string.

Value Returned

t_string

The string equivalent of the SKILL expression, enclosed in quotes. If the value of the expression is nil or an error occurred, an empty string is returned.

Example

For the following expression, the system retrieves the value of the minimum width rule for the metall layer from the technology file and then converts that value to a string enclosed in quotes.

```
pcExprToString( techGetSpacingRule( tfId "minWidth" "metal1" ) )
```

Parameterized Cell Functions

pcTechFile

```
pcTechFile(
    g_expression
)
=> q result
```

Description

Evaluates an expression contained in a string. The Pcell compiler uses this function as an envelope around stretch expressions that access information from a technology file. This function prevents any symbols used in the technology file access expression from being defined as parameters of the Pcell.

Argument

g_expression

The expression you want the system to evaluate when the Pcell containing the expression is evaluated.

Value Returned

g result

The value that resulted from evaluating the expression. If an error occurs, look in the CIW or at the $\mathtt{CDS.log}$ file for a message about the error.

Example

In the following statement, the symbol minWidth is used only during evaluation of the expression; it is not treated as a Pcell parameter:

```
pcTechFile( llp~>minWidth )
```

where 11p is an internal variable, ~> is an operator, and minWidth is recognized by the system as a symbol.

If you did not use the pcTechFile function, the system would assume that minWidth is a Pcell parameter.

Parameterized Cell Functions

2

Graphical Parameterized Cell Functions

This chapter describes each of the supported pc functions you can use to create Pcells in the graphical Pcell environment. Do not use the functions in this section within the body of SKILL Pcell code.

Graphical Pcell Functions on page 2

Pcell Compiler Customization SKILL Functions on page 148

Parameterized Cell SKILL Cross-Reference Table on page 164

Graphical Parameterized Cell Functions

Graphical Pcell Functions

pcColinearPoints

```
\begin{array}{c} \text{pcColinearPoints} \, (\\ & 1\_pointList1 \\ & 1\_pointList2 \\ & 1\_pointList3 \\ ) \\ & \Rightarrow \text{t / nil} \end{array}
```

Description

Verifies whether the three coordinates specified are collinear lying on or passing through the same straight line and orthogonal parallel to the X or Y axis.

Arguments

l_pointList1	First list of coordinates, specified as a list of two floating point numbers in the following format:
	'(x y)
l_pointList2	Second list of coordinates, specified as a list of two floating point numbers in the following format:
	'(x y)
l_pointList3	Third list of coordinates, specified as a list of two floating point numbers in the following format:
	'(x y)

Value Returned

t The three specified coordinates are collinear and orthogonal.

The three specified coordinates are not collinear and orthogonal.

Example

```
pcColinearPoints('(1.0 2.0)'(1.3 2.0)'(3.0 2.0))
```

Graphical Parameterized Cell Functions

Verifies whether the three coordinates listed a	are collinear and orthogonal.
---	-------------------------------

Graphical Parameterized Cell Functions

pcConcatOrient

```
pcConcatOrient(
    t_orientation1
    t_orientation2
)
=> t_concatOrient / R0
```

Description

Concatenates two specified object orientations into one.

Arguments

t_orientation1	String specifying the first orientation.
	Valid Values: "R0", "R90", "R180", "R270", "MX", "MY", "MR90", "MR270"
	MR90 is equivalent to MXR90
	MR270 is equivalent to MYR90
t_orientation2	String specifying the second orientation.
t_orientation2	String specifying the second orientation. Valid Values: "R0", "R90", "R180", "R270", "MX", "MY", "MR90", "MR270"
t_orientation2	Valid Values: "R0", "R90", "R180", "R270",

Value Returned

```
t_concatOrientOrientation resulting from the concatenation."R0"Returns "R0" if the concatenation fails.
```

Example

```
pcConcatOrient("R0" "R90") => "R90"
```

Concatenates the orientation R0 with R90, resulting in an orientation of R90.

Graphical Parameterized Cell Functions

pcDefineCondition

```
pcDefineCondition(
    d_cvId
    l_figs
    l_namelist
    g_condition
    g_stretch
    f_adjust
)
=> d_condId / nil
```

Description

Specifies that the conditional inclusion of a list of objects is controlled by a given SKILL expression. Also specifies the inclusion of a dependent stretch control line. If the SKILL expression evaluates to a value other than nil, the objects are included.

Graphical Parameterized Cell Functions

Arguments

d_cvId	The database ID of the cellview in which the conditional inclusion is defined.
l_figs	List of objects controlled by the same conditional expression.
l_namelist	List of symbols referenced in the conditional expression. These become parameters of the Pcell.
g_condition	SKILL expression controlling the inclusion of the selected objects in the instance.
g_stretch	SKILL symbol specifying the name of a dependent stretch control line associated with this conditional inclusion. Use \mathtt{nil} if there is no dependent stretch control line.
f_adjust	Amount by which a dependent stretch is adjusted from its reference dimension if $g_condition$ evaluates to nil. This argument is ignored if $g_stretch$ is nil.

Value Returned

d_condId	Group ID used to store the details of the conditional inclusion.
nil	Returned if d_cvId does not identify a cellview or l_figs does not contain any objects.

Example

```
pcDefineCondition(cv figs list('Q bar 'Reset) "Q bar && Reset" "condStretch" 12.25)
```

Defines a conditional expression $Q_bar \&\& Reset$ in cellview d_cvId that controls the inclusion of the objects in l_figs . It declares Q_bar and Reset as symbols used as parameters for the Pcell. It also defines the stretch control line condStretch as dependent on this conditional inclusion, with the stretch value decreased 12.25 from the reference dimension if $Q_bar \&\& Reset$ evaluates to nil.

Graphical Parameterized Cell Functions

pcDefineInheritParam

```
pcDefineInheritParam(
    d_instId
    s_parameter
    g_value
    l_namelist
)
    => d_inheritGroup / nil
```

Description

Specifies that a parameter of an instance of a Pcell takes its value from a parameter definition of the enclosing cellview. The selection filter allows you to select only instances.

Arguments

d_instId	Database ID of an instance of a Pcell.
s_parameter	Name of a parameter in the master cellview of $d_instide{tide}$.
g_value	SKILL expression for the value of $s_parameter$ in d_instID .
l_namelist	List of symbols used in g_value . These become parameters of the Pcell.

Value Returned

d_inheritGroup	Group ID used to record the details of the inherited parameter.
nil	Returned if d_{instiD} does not identify an instance or if there are no inherited parameters defined in it.

Example

```
nfetWidthInheritance = pcDefineInheritParam(nfet1 'w 'nfetWidth list('nfetWidth))
```

Causes parameter w on instance nfet1 to take its value from the nfetWidth parameter of the enclosing cellview. It declares nfetWidth as a parameter of the enclosing cellview.

Graphical Parameterized Cell Functions

pcDefineParamCell

```
pcDefineParamCell(
    d_cellviewId
    ['disablePrompt]
)
=> t / nil
```

Description

Allows you to compile a graphical Pcell (super) master in the database from the cellview you specify. If you do not compile a Pcell before you place an instance of it in another design, the system interprets the design as a standard fixed cell instead of a Pcell. Each time you edit a graphical Pcell, you must recompile it so that all placed instances reflect the changes.

Prerequisites

You must have already defined parameters for the cellview.

Arguments

l_cellviewId	Database ID for the cellview (cellview ID). This argument is required.
'disablePrompt	If set to $ t$, a prompt, which is displayed during the Pcell master compilation, gets disabled whenever no parameter is specified in the cell.

Value Returned

t Parameterized (super) master was created.

nil Parameterized (super) master was not created.

Example

```
pcDefineParamCell( cellviewId )
```

Compiles a (super) master cell from the cellview identified by the variable cellviewId.

Graphical Parameterized Cell Functions

pcDefineParamLabel

```
pcDefineParamLabel(
    d_labelId
    S_height
)
=> t / nil
```

Description

Defines a parameterized label. A parameterized label is not an instance name, but a label displaying values within a Pcell, such as width and height of gates. This function should be used only when creating graphical Pcells.

Arguments

d_labelId	Database ID for the label you want to parameterize. The label is a SKILL expression evaluated in the instance.
S_height	Height of the text in user units.
	Valid Values: any string or symbol

Value Returned

t	Returned if the label is converted to a parameterized label.
nil	Returned if the label is not converted to a parameterized label.

Example

```
labelId=dbCreateLabel(geGetEditCellView() "poly1"
20:10 "width*height" "lowerLeft" "R0" "stick" 2)
pcDefineParamLabel(labelId "2")
```

The stretch parameters width and height are defined before using the example. Creates a label using the values of width times height. In the example above the dbld produced by the dbCreateLabel function is assigned to a variable named labelid. Defines $d_1abelid$ as a parameterized label whose text is evaluated when you place the Pcell. The height of the label is 2 microns.

Graphical Parameterized Cell Functions

pcDefineParamLayer

```
pcDefineParamLayer(
    d_cvId
    l_shapes
    g_layerExpr
    l_namelist
    [ g_purposeExpr ]
    )
    => d_paramLayerId
```

Description

Specifies that a set of shapes has its layer and purpose determined by a parameter definition in the cellview. The selection filter prevents you from selecting instances or stretch control lines.

Arguments

d_cvId	The database ID of the cellview in which the parameter applies.
l_shapes	List of shapes in d_cvId that take their layer from a parameter of the cell.
g_layerExpr	SKILL expression for the layer to which the specified shapes belong. This expression evaluates to a string that must be a valid layer name.
l_namelist	List of symbols referenced in $g_layerExpr$. These become parameters of the cell.
g_purposeExpr	SKILL expression for the layer purpose to which the specified shapes belong. This expression evaluates to a string that must be a valid layer purpose.

Value Returned

d_paramLayerId Group ID used to record the details of the layer parameter.

Example

```
diffLayerParam =
pcDefineParamLayer(geGetEditCellView(w=getCurrentWindow())
geGetSelSet(w) 'diffLayer list("nDiff") list('diffLayer))
```

Graphical Parameterized Cell Functions

Causes the layer of the set of selected shapes to be determined by the value of the parameter diffLayer. It specifies nDiff as the default value for diffLayer and declares diffLayer as a parameter of the cell.

Graphical Parameterized Cell Functions

pcDefineParamPath

```
pcDefineParamPath(
    d_pathId
    S_param
    g_margin
    g_width
    n_defaultWidth
    t_snap
    l_namelist
)
=> d_paramShapeId
```

Description

Defines a path that has its vertices determined by a parameter of the cell. When you place the Pcell, you enter a coordinate string that is used as the vertices of the parameterized path. You can use this function more than once in a cellview if all paths have the same vertices.

Graphical Parameterized Cell Functions

Arguments

d_pathId	Database ID of a path that has its vertices determined by a parameter of the cell.
S_param	Name of the parameter controlling the vertices of the path. By default, this parameter is coords.
g_margin	SKILL expression for the margin by which the path is offset from the coordinate list defined by parameter.
g_width	SKILL expression for the width of the path.
n_defaultWidth	Value to use for the width if $width$ evaluates to a nonnumerical value.
t_snap	Snap used by the editor when digitizing path vertices to place an instance of this cell.
	Valid Values: orthogonal, anyAngle, diagonal, L90
l_namelist	List of symbols used in the g_width SKILL expression. These

Value Returned

d_paramShapeId Group ID used to record details of the parameterized paths.

become parameters of the Pcell.

Example

```
pcDefineParamPath( path 'coords 2 'gateWidth 1-5 "orthogonal" list( 'gateWidth ) )
```

Defines path as a parameterized path that takes its vertices from the value of the parameter coords offset by 2, with a width equal to the value of the gateWidth parameter or 1–5 if gateWidth evaluates to a nonnumerical value. It tells the editor to use orthogonal snap when entering vertices for the path and declares gateWidth as a parameter of the cell.

Graphical Parameterized Cell Functions

pcDefineParamPolygon

```
pcDefineParamPolygon(
    d_polygonId
    S_param
    g_margin
    t_snap
    l_namelist
)
    => d_paramShapeId
```

Description

Defines a polygon that has its vertices determined by a parameter of the cell. When you place the Pcell, you enter a coordinate string that is used as the vertices of the parameterized polygon. You can use this function more than once in a cellview.

Arguments

d_polygonId	The database ID of the polygon that has its vertices determined by a parameter of the cell.
S_param	Name of the parameter controlling the vertices of the polygon. By default, this parameter is coords.
g_margin	SKILL expression for the amount to enlarge or shrink the vertices of the polygon as compared to the coordinate list in the parameter.
t_snap	Snap used by the editor when digitizing polygon vertices to place an instance of this cell.
	Valid Values: orthogonal, anyAngle, diagonal, L90
l_namelist	List of symbols used in the g_{margin} SKILL expression. These become parameters of the Pcell.

Value Returned

d_paramShapeId Group ID used to record details of the parameterized polygons.

Example

```
pcDefineParamPolygon( polygon 'coords '(-margin) "orthogonal" list( 'margin ) )
```

Graphical Parameterized Cell Functions

Defines $d_polygonId$ as a parameterized polygon that takes its vertices from the value of the parameter coords, shrunk by the value of the g_margin parameter. It tells the editor to use orthogonal snap when entering vertices for the polygon and declares margin as a parameter of the cell.

Graphical Parameterized Cell Functions

pcDefineParamProp

```
pcDefineParamProp(
    d_cvId
    t_name
    g_expr
)
=> t / nil
```

Description

Defines a parameterized property that can be accessed using a SKILL procedure. You can use this property to store any value within the Pcell.

Arguments

d_cvId	The database ID of the cellview in which the parameter applies.
t_name	Name of the parameterized property.
g_expr	SKILL expression for the property value.

Value Returned

t	Returned if the parameterized property is created.
nil	Returned if the parameterized property is not created.

Example

```
pcDefineParamProp(cv "myProp" 'length)
```

Defines a property name myProp to be a parameterized property of the cellview cv. The property myProp takes its value from the parameter length and is evaluated when the instance is created.

Graphical Parameterized Cell Functions

pcDefineParamRect

```
pcDefineParamRect(
    d_rectangleId
    S_param
    g_margin
    l_namelist
)
    => d_paramShapeId
```

Description

Defines a rectangle that has its vertices determined by a parameter of the cell. When you place the Pcell, you enter two coordinates that are used as the vertices of the parameterized rectangle. You can use this function more than once in a cellview.

Arguments

d_rectangleId	The database ID of the rectangle that has its vertices determined by a parameter of the cell.
S_param	Name of the parameter controlling the vertices of the rectangle. By default, this parameter is coords.
g_margin	SKILL expression for the amount to enlarge or shrink the vertices of the rectangle as compared to the coordinate list in the parameter.
l_namelist	List of symbols used in the g_{margin} SKILL expression. These become parameters of the Pcell.

Value Returned

d_paramShapeId Group ID used to record details of the parameterized rectangles.

Example

```
pcDefineParamRect(rect 'coords '(-margin) list('margin))
```

Defines rect as a parameterized rectangle that takes its vertices from the value of the parameter coords, reduced by the value of the margin parameter. It also declares margin as a parameter of the cell.

Graphical Parameterized Cell Functions

pcDefineParamRefPointObject

```
pcDefineParamRefPointObject(
    g_objects
    S_param
    l_refpoint
)
=> d refPointId
```

Description

Specifies that the location of an object or group of objects in the instance is determined by the location of a reference point that is a parameter of the cell. The objects in the instance have the same relationship to the reference point parameter as the objects in the master cellview have to the corresponding reference point in the master cellview.

Arguments

g_objects	List of objects whose locations are to be determined by the parameterized reference point.
S_param	Name of the parameter for the parameterized reference point.
	Valid Values: any string or symbol
l_refpoint	Coordinates of the reference point in the master cellview.

Value Returned

d_refPointId	Group ID used to record the details of the parameterized
	reference point.

Example

```
pcDefineParamRefPointObject(list(pin) 'pinPoint centerBox (pin~>bBox))
```

Causes the object pin to be located relative to the coordinate parameter pinPoint. The reference point for pinPoint in the master cellview is the center point of the pin object.

Graphical Parameterized Cell Functions

pcDefinePathRefPointObject

Description

Specifies that the location of an object or group of objects in the instance be determined by the location of the endpoint of a parameterized path. The objects in the instance have the same relationship to the endpoint of the digitized path in the instance as the objects in the master cellview have to the corresponding endpoint of the parameterized path in the master cellview.

Arguments

l_objects	List of objects whose locations are to be determined by the endpoint of a parameterized path.
S_param	Name of the parameter controlling the parameterized path whose endpoint determines the location of the objects. By default, this parameter is coords.
t_endpoint	Endpoint of the path that determines the location of the objects.
	Valid Values: first, last

Value Returned

d_refPointId Group ID used to store the details of the parameterized reference point.

Example

```
pcDefinePathRefPointObject( list ( via ) 'coords "first" )
```

Causes the object via to be located relative to the first vertex of the coords parameter. The coords parameter controls the vertices of a parameterized path.

Graphical Parameterized Cell Functions

pcDefinePCell

Description

Creates parameterized (super) master cellview. This function enables you to pass a SKILL definition for a Pcell including a list of its parameters.

Also, refer to dbDefineProc in the Virtuoso Design Environment SKILL Reference.

Arguments

1_cellIdentifier List containing the library database ID, cell name, view name, and view type. View type is optional and defaults to maskLayout.

Valid Values: maskLayout, schematic, schematicSymbol

Graphical Parameterized Cell Functions

1_formalArgs

The parameter declaration section, containing a list of input parameters and their default values, all enclosed in parentheses. Each element of the list is itself a list containing a parameter symbol, its (optional) data type, and a default value.

Do not use the list keyword, but enclose the parameters in parentheses instead.

In addition, The <code>l_formalArgs</code> argument to <code>pcDefinePCell</code> can include an expression. However, it is the value of that expression and not the expression itself, which gets associated as a default value of the corresponding parameter. As a result, such expression cannot be retrieved later on once the Pcell has been compiled (i.e. super master created).

You can specify 1_formalArgs as:

Format 1:

(S_paramName tS_paramType g_paramValue)

Format 2:

(S_paramName g_paramValue)

where,

- *S_paramName*: A symbol of the parameter name.
- tS_paramType: Either a string or a symbol to represent the parameter type of a Pcell parameter.

 You may or may not enclose the parameter type within quotes. Valid values include boolean, int, float, and ilList. It is optional to include the parameter type (see the *Caution* note).

Graphical Parameterized Cell Functions

g_paramValue: Default value of a defined parameter. The value specified must match the specified parameter type if the specified parameter type is defined as a Pcell parameter list.

Note: Cadence encourages you to follow the first format to define a Pcell parameter because this format can be comprehended clearly both by the graphical Pcell application and the end user of Pcell.

Example 1: (Switch1 "float" 0.625)

Example 2: (Switch2 float 0.625)

Example 3: (Switch3 0.625)

Caution

For boolean arguments, you "must" specify the data type. It helps you to avoid any issues with the accurate parameter type checking, which is enforced in OpenAccess. If you specify the default value of an argument as 'nil' without specifying the data type, the argument value might be interpreted as the integer zero instead of the boolean nil (false).

Consider specifying the data type of a boolean argument as shown in the following example:

```
(is orthogonal boolean arg "boolean" nil)
```

where, the data type of the is_orthogonal_boolean_arg argument has been specified as Boolean and the default value of this boolean argument has been set to nil.

body_of_code

SKILL code for creating geometries and pins. You must provide code here. Enclose the code in a let or prog statement. If you use variables in the code, define them at the beginning of the let or prog statement. Using let gives faster performance than prog; prog allows multiple exits while let exits only at its end. Optionally, from within this code, you can call SKILL functions, application functions, and your own user-defined functions.

22

Graphical Parameterized Cell Functions

Calls to functions from within the $body_of_code$ section are part of the Pcell, but the functions themselves are **not** part of the Pcell. These functions must be available each time the Pcell is evaluated. If a called function is not available when a Pcell is evaluated, the Pcell fails.

If you want the system to automatically load functions when it opens your library, include the functions in your libInit.il file. **Do not** load a file from within a Pcell. For more information about what to do and what to avoid when writing Pcell code, see <u>"Safety Rules for Creating SKILL Pcells"</u> on page 22.

Value Returned

d_cellViewId

The cellview ID of the parameterized (super) master is returned if the (super) master is created.

ni1

Returned if the parameterized (super) master cellview is not created.

Example

```
pcDefinePCell(
 list( ddGetObj("tutorial") "ask" "layout"
 ) ; end of list for first argument
    (layer string "metal1")
    (width float 3.0)
    (length float 6.0)
  ) ; end of pcell parameters
  let(
        (); no local variables in this example
        rodCreateRect (
                        ?name
                                    "minMetal"
                        ?width
                                    width
                        ?layer
                                    layer
                        ?length
                                    length
      ) ; end of rodCreateRect
    ) ; end of body of code let
 ) ; end of pcDefinePCell
```

This example creates a rectangle named minMetal on the metall layer, with a width equal to 3 and a length equal to six.

Graphical Parameterized Cell Functions

pcDefineParamSlot

```
pcDefineParamSlot(
    g_type
    g_value
    g_pcIsParamSlot
)
=> l paramDefDPL
```

Description

Constructs a parameter DPL, which is used to define a parameter slot of the specified device.

Arguments

g_type	A string defining the parameter type. Valid values are string, int, float, and ILList.
g_value	The value of the parameter slot.
g_pcIsParamSlot	A Boolean, which indicates whether it is a parameter slot.
	Default value is t.

Value Returned

1_paramDefDPL The created parameter DPL.

Example

Constructs a parameter DPL, which is used to define a parameter slot of pcParamClass.

Graphical Parameterized Cell Functions

pcDefinePPCell

Description

Creates a parameterized Pcell master cellview (P²cell) that enables you to pass the SKILL definition for a Pcell, including a list of its arguments, similar to the <u>pcDefinePCell</u> function. This function also accepts a code argument declaration list and a code argument override list, where the code parameter can be used in the Pcell code body to create multiple Pcell super masters from a single Pcell code.

Within pcDefinePPCell, the override code parameter is always a simple variable, which receives the input provided by the caller of pcDefinePPCell. This will always be the use model of P²cell because there is always a driver function that calls it. The function should not be used as a top-level function (not inside a procedure) because that will lose the purpose of the new parameterization feature.

Graphical Parameterized Cell Functions

Arguments

 $l_cellIdentifier$

A list that contains the library database ID, cell name, view name, and view type. View type is optional and defaults to maskLayout.

Valid view type values: maskLayout, schematic, schematicSymbol

1 overrideCodeParams

A SKILL list in the DPL format. Each parameter within the DPL is represented by a pair of $s_codeParamName$ and $g_codeParamValue$. Only the value can be a SKILL expression.

Syntax:

```
list( nil S_codeParamName
g_codeParamValue ... )
```

Example:

```
list( nil 'param1 "value1" 'param2 t
'param3 width*3 )
```

- S_codeParamName: A symbol or a string of the name of code parameter. It needs to match a declared code parameter name. A warning is issued for a mismatched name and the default value is used instead.
- g_codeParamValue: A SKILL expression that evaluates the given value to obtain the value of each code parameter. Within the pcDefinePPCell function, the override code argument is always a simple variable that receives the input provided by the caller of pcDefinePPCell.

The caller of pcDefinePPCell can construct the value of a code parameter using any method as long as the format of the result specified by the override code parameter is in the DPL format. This helps you to assign and update the values. It is expected this will be modified later to generate multiple Pcell super masters from one P²cell definition.

Graphical Parameterized Cell Functions

1_defaultCodeParams

A list that contains one or many code parameter specification. Each code parameter specification is defined in the following format:

(S_codeParamName[S_codeParamType]
g_codeParamValue)

- S_codeParamName: A symbol or a string of the name of code parameter. It needs to match a declared code parameter name. A warning is issued for a mismatched name and the default value is used instead.
- S_codeParamType: A string or a symbol defining the value type of the code parameter.

Valid values: boolean, int, float, string, and ilList. It is optional to include the code parameter type except for Boolean. For Boolean code parameter, you must specify the data type to avoid ambiguity against the ilList type.

g_codeParamValue: A SKILL expression that evaluates the given value to obtain the value of each code parameter. Within the pcDefinePPCell function, the override code argument is always a simple variable that receives the input provided by the caller of pcDefinePPCell.

The caller of pcDefinePPCell can construct the value of a code parameter using any method as long as the format of the result specified by the override code parameter is in the DPL format. This helps you to assign and update the values. It is expected this will be modified later to generate multiple Pcell super masters from one P²cell definition.

The declared code parameter is in a simple list format. This format is consistent with the declaration of Pcell parameters used by pcDefinePCell.

Graphical Parameterized Cell Functions

This declaration cannot contain another SKILL expression inside it.

Note: Like the override code parameter, the entire declaration itself can be defined outside pcDefinePPCell, but it hides the declaration from the Pcell code and is therefore not recommended.

ls formalArgs

A list of parameters defining a Pcell parameter set. There are the following two ways to define the Pcell parameter set.

- Define a Pcell parameter through an explicit list of parameters, same style as the pcDefinePCell function.
- Call a user-defined function, which returns a Pcell parameter set. When P²cell parser detects the Pcell parameters by calling a user-defined function, Parser executes the user function and pass the newly created super master ID as its argument.

body_of_code

SKILL code for creating geometries and pins. You must provide code here. Enclose the code in a let or prog statement. If you use variables in the code, define them at the beginning of the let or prog statement. Using let gives faster performance than prog; prog allows multiple exits while let exits only at its end. Optionally, from within this code, you can call SKILL functions, application functions, and your own user-defined functions.

Calls to functions from within the $body_of_code$ section are part of the Pcell, but the functions themselves are **not** part of the Pcell. These functions must be available each time the Pcell is evaluated. If a called function is not available when a Pcell is evaluated, the Pcell fails.

If you want the system to automatically load functions when it opens your library, include the functions in your libInit.il file. **Do not** load a file from within a Pcell. For more information about what to do and what to avoid when writing Pcell code, see "Safety Rules for Creating SKILL Pcells" on page 22.

You can access the name and value of any code parameter using <u>pcGetCodeParamNames</u> and <u>pcGetCodeParamValue</u> functions.

Graphical Parameterized Cell Functions

Value Returned

d_cellViewId The cellview ID of the parameterized super master if the Pcell

is successfully compiled.

nil If the parameterized super master cellview is not created.

Example

```
procedure( createPmos(xVal)
    let((libName cellName ppcDef overrideCodeParams )
        ; Setup library and cell name, and the override code parameter
        ; values
        libName = "PcellDemo"
cellName = "pmos"
        overrideCodeParams = list( nil
             'layerName "Via2" 'rectWidth 3*xVal 'createGate t)
        ; Calls myMakeMos to create one Pcell super master
        myMakeMos ( libName cellName "layout" "maskLayout"
            overrideCodeParams)
        ; Update the cell name and one of the override code parameter value
        cellName = "pmos ng"
        overrideCodeParams->createGate = nil
        ; Calls myMakeMos to create another Pcell super master
        myMakeMos (libName cellName "layout" "maskLayout"
            overrideCodeParams)
    )
)
procedure ( myMakeMos (libName cellName viewName viewType @optional
        (overrideCPs nil))
    let((smId)
        ; Use pcDefinePPCell to create a Pcell that accepts code parameters
        smId = pcDefinePPCell(
             ; Define super master's identification
            list(ddGetObj(libName) cellName viewName viewType )
            ; Define variable to accept override code parameters
            overrideCPs
            ; Define code parameters
                ( layerName string "Metal")
                 ( rectWidth float 1.0 )
                 ( createGate boolean nil )
            ; Define Pcell parameters
( (dd1 "none")
                 (sd1 "none" )
                       5.0)
                 (w
                 (1
                         1.0)
```

Graphical Parameterized Cell Functions

```
(fingers 1 )
    ; Define Pcell code
    let( (cv rect rectW createGate)
        cv = pcCellView
        sd1 = cv~>parameters~>sd1
        dd1 = cv~>parameters~>dd1
        w = aelNumber(cv~>parameters~>w)
        1 = aelNumber(cv~>parameters~>l)
        fingers = cv~>parameters~>fingers
        ; Leverage code parameter to create different
        ; contents for a Pcell super master
        createGate = pcGetCodeParamValue(cv "createGate")
        when ( createGate
            layerName = pcGetCodeParamValue(cv "layerName")
            rectW = pcGetCodeParamValue(cv "rectWidth")
            rect = dbCreateRect(cv
                list(layerName "drawing")
                list( 2:2 3:2+round(rectW))))
smId
```

This example develops multiple Pcell super masters by using the P²cell method.

Graphical Parameterized Cell Functions

pcDefineRepeat

```
pcDefineRepeat(
    d_cvId
    l_shapes
    l_namelist
    g_stepX
    g_stepY
    g_repeatX
    g_repeatY
    g_stretchX
    g_stretchY
    g_adjustX
    g_adjustY
    t_direction
    )
    => d repeatId
```

Description

Defines a repetition parameter to be applied to specified objects. Objects can be repeated in the X direction, Y direction, or both. If the value for the repetition direction, $t_direction$, is horizontal and vertical, the pcDefineRepeat function creates a two-dimensional array.

Graphical Parameterized Cell Functions

Arguments

d_cvId	The database ID of the cellview in which the parameter applies.
l_shapes	List of the shapes replicated.
l_namelist	List of the symbols referenced in the step or repeat expressions. These become parameters of the Pcell.
g_stepX	SKILL expression specifying stepping distance in the horizontal direction.
g_stepY	SKILL expression specifying stepping distance in the vertical direction.
g_repeatX	SKILL expression specifying the number of times objects are repeated in the horizontal direction.
g_repeatY	SKILL expression specifying the number of times objects are repeated in the vertical direction.
g_stretchX	Name of the vertical, dependent stretch control line associated with this repetition.
g_stretchY	Name of the horizontal, dependent stretch control line associated with this repetition.
g_adjustX	SKILL expression specifying the adjustment from the reference dimension to be applied to the vertical, dependent stretch control line.
g_adjustY	SKILL expression specifying adjustment from the reference dimension to be applied to the horizontal, dependent stretch control line.
t_direction	Direction of repetition.
	Valid Values: horizontal, vertical, horizontal and vertical

Value Returned

d_repeatId Group ID used to store details of the repetition.

Example

Graphical Parameterized Cell Functions

```
pcDefineRepeat(
    cv ; cv is defines as cellview ID
                                                     numGates and cellPitch
    figs ; list of figures to repeat
                                                     are parameters of the Pcell
    list('numGates 'cellPitch)
    'cellPitch
    nil
    '(numGates-1)
    nil
    'gateStretch
    nil
    '(pcFix(pcRepeat - 1) * pcStep)
    nil
    'horizontal
) ; close for pcDefineRepeat
```

Defines a horizontal repetition in cellview cv affecting the objects listed in figs. The horizontal stepping distance is cellPitch. The number of horizontal repetitions is numGates-1.

This example declares numGates and cellPitch as parameters of the Pcell. It also names gateStretch as a dependent stretch control line for the repetition, with an adjustment from the reference dimension defined by the expression pcFix(pcRepeat - 1) * pcStep.

Graphical Parameterized Cell Functions

pcDefineSteppedObject

```
pcDefineSteppedObject(
    g_objects
    S_param
    g_step
    g_startOffset
    g_endOffset
    l_namelist
)
    => d_stepObjectId
```

Description

Defines an object or group of objects to be repeated along the length or perimeter of a parameterized shape that has already been defined in the Pcell. The selection filter prevents you from selecting stretch control lines, parameterized shapes, or objects in other repeatalong-shape groups.

Graphical Parameterized Cell Functions

Arguments

g_objects	List ot ob	jects repea	ated along [•]	the length or	perimeter of a

parameterized shape.

S_param Name of the parameter controlling the parameterized shape

along which objects are repeated. By default, this parameter is

coords.

g_step SKILL expression for the stepping distance between

repetitions.

g_startOffset SKILL expression for the space left between the first vertex of

the parameterized shape and the first repeated object.

g_endOffset SKILL expression for the space left between the last vertex of

the parameterized shape and the last repeated object.

1_namelist List of symbols used in g_step, g_startOffset, or

 $g_endOffset$ expressions. These become parameters of the

Pcell.

Value Returned

d_stepObjectId Group ID used to record the details of the repetition along the

parameterized shape.

Example

pcDefineSteppedObject(list(via1 via2) 'coords 'viaPitch 1.25 1.25 list('viaPitch))

Specifies that objects via1 and via2 are to be repeated along the parameterized shape controlled by coords, using a stepping distance determined by the parameter viaPitch, with a gap of 1.25 between the start of the vertices and the first repetition and between the last repetition and final vertex of parameterized shape. It also declares viaPitch as a parameter of the Pcell.

Graphical Parameterized Cell Functions

pcDefineStretchLine

```
pcDefineStretchLine(
    d_lineId
    g_paramExpr
    t_direction
    f_defval
    f_minval
    f_maxval
    g_stretchRepeated
)
    => d_StretchId
```

Description

Defines a stretch control line used to control stretching in the X direction or Y direction. Objects repeated in the direction parallel to the stretch direction can be set to stretch.

Graphical Parameterized Cell Functions

Arguments

d_lineId	The database ID of the line used as the stretch control line. By default, this line is drawn on the layer stretch.
g_paramExpr	SKILL expression or symbol controlling the stretch.
t_direction	Direction of the stretch.
	Valid Values: right, left, rightAndLeft, up, down, upAndDown
f_defval	Default value (reference dimension) for the stretch.
f_minval	Minimum value for the stretch.
f_maxval	Maximum value for the stretch. Use $\ensuremath{\mathtt{nil}}$ if no maximum is specified.
g_stretchRepeated	Boolean expression indicating whether to stretch shapes that

Value Returned

d_StretchId Group ID used to store the details of the stretch parameter.

are repeated in the direction parallel to the stretch.

Example

```
pcDefineStretchLine(stretchLine 'nfetWidth, "right" 1.25 1.25 25 nil)
```

Defines stretchLine as a stretch control line controlled by the parameter nfetWidth. The stretch direction is right. The default and the minimum values are 1.25, and the maximum value is 25. Horizontally repeated shapes are not stretched.

Graphical Parameterized Cell Functions

pcDeleteCondition

```
pcDeleteCondition(
    d_groupId
)
=> t / nil
```

Description

Deletes a previously defined conditional inclusion parameter.

Arguments

d_groupId Group ID of the conditionally included objects.

Value Returned

t Returned if the parameter is deleted.

nil Returned if *d_groupId* is not a conditional inclusion

parameter.

Example

foreach(cond pcGetCondition(cv) pcDeleteCondition(cond))

Deletes all conditional inclusion parameters in the cellview cv.

Graphical Parameterized Cell Functions

pcDeleteParam

Description

Deletes the definition of the parameter identified by $t_paramName$. It is recommended to use <u>pcHIEditParameters</u> on page 120 instead of this function.

Prerequisites

You must have defined the named parameter.

Arguments

d_cvId	Τ	he database	ID	0	the	cellview	in w	hic	h t	he	paramet	erized	
--------	---	-------------	----	---	-----	----------	------	-----	-----	----	---------	--------	--

property should be deleted.

t_paramName Name of the parameter in quotes.

Value Returned

t Returned if the parameter definition is deleted.

nil Returned if *t_paramName* is not a valid parameter name.

Example

```
pcDeleteParam( cellviewId "width" )
```

Deletes the parameter named width.

Graphical Parameterized Cell Functions

pcDeleteParamLayer

Description

Deletes a parameter associating a set of shapes with a layer parameter.

Prerequisites

You must have defined the layer parameter.

Arguments

d_groupId Group ID of the shapes assigned the layer parameter you want

to delete.

Value Returned

t Returned if the parameter is deleted.

nil Returned if d_groupId is not a valid identifier for a layer

parameter.

Example

pcDeleteParamLayer(diffLayerParam)

Deletes the layer parameter identified by diffLayerParam.

Graphical Parameterized Cell Functions

pcDeleteParamProp

```
pcDeleteParamProp(
    d_cvId
    t_propname
)
=> t / nil
```

Description

Deletes a parameterized property in the cellview d_cvId .

Arguments

d cvId	The database ID of the cellview in which the parame	terized
--------	---	---------

property should be deleted.

t_propname Name of the parameterized property.

Value Returned

t Returned if the parameterized property is deleted.

nil Returned if no parameterized property is defined with the given

name or the parameterized property cannot be deleted.

Example

```
pcDeleteParamProp( cv "myProp" )
```

Deletes the parameterized property named myProp.

Graphical Parameterized Cell Functions

pcDeleteParamShape

Description

Deletes a parameterized shape directive, causing the specified shape to revert back to a regular (nonparameterized) shape.

Prerequisites

You must have defined the shape as a parameterized path, polygon, or rectangle.

Arguments

d_memberId The database ID of the shape whose parameter you want to

delete.

Value Returned

t Returned if the parameter is deleted.

nil Returned if the shape is not defined as a parameterized path,

polygon, or rectangle.

Example

foreach(shape allMyParamShapes pcDeleteParamShape(shape))

Deletes all shape parameters in the list allMyParamShapes.

Graphical Parameterized Cell Functions

pcDeleteRefPoint

Description

Deletes a reference point parameter. You can use this command to delete either a reference point defined relative to a parameter of the cell or a reference point defined relative to a parameterized path endpoint.

Note: You must have defined the reference point parameters.

Arguments

d_groupId The database ID of the parameterized reference point you want

to delete.

Value Returned

t Returned if the reference point parameter is deleted.

nil Returned if d_groupId is not a valid identifier for a

parameterized reference point.

Example

```
pcDeleteRefPoint( gateContactRefPt )
```

Deletes the parameterized reference point defined by the symbol gateContactRefPt.

Graphical Parameterized Cell Functions

pcDeleteRepeat

```
pcDeleteRepeat(
    d_groupId
)
=> t / nil
```

Description

Deletes the repetition parameter *d_groupId*.

Arguments

d_groupId The database ID of the repetition parameter you want to delete.

Value Returned

t Returned if the parameter is deleted.

nil Returned if *d_groupId* is not a repeat identifier.

Example

```
foreach( repeat pcGetRepeats ( cv ) pcDeleteRepeat ( repeat ) )
```

Deletes all repetition parameters in the cellview CV.

Graphical Parameterized Cell Functions

pcDeleteSteppedObject

```
pcDeleteSteppedObject(
    d_groupId
)
=> t / nil
```

Description

Deletes the repetition-along-shape parameter *d_groupId*.

Arguments

d_groupId The database ID of the repetition along a shape as returned by

pcDefineSteppedObject.

Value Returned

t Returned if the parameter is deleted.

nil Returned if *d_groupId* is not a repetition-along-shape

identifier.

Example

```
foreach( obj allMySteppedObjs pcDeleteSteppedObject ( obj ) )
```

Deletes all repetition-along-shape parameters in the list allMySteppedObjs.

Graphical Parameterized Cell Functions

pcDraw

Description

Creates database objects for the specified SKILL++ Pcell class. This method is implemented for each SKILL++ Pcell class. pcDraw is called by the Pcell source code in pcDefinePCell for the associated Pcell.

Arguments

g_device

A SKILL++ Pcell class object that is inherited from class pcParamClass.

Value Returned

t

If the database objects are created for a specified SKILL++ Pcell class.

nil

If the database objects are not created.

Example

```
defmethod( pcDraw ((device RING))
    let((cv ringS ringW coreBBox llx lly urx ury pts ring)
        ringS = pcGetParamSlotValue(device 'ringS)
        ringW = pcGetParamSlotValue(device 'ringW)
            coreBBox = getCoreBBox(device)
            llx = xCoord( lowerLeft(coreBBox))
lly = yCoord( lowerLeft(coreBBox))
            urx = xCoord( upperRight(coreBBox))
            ury = yCoord( upperRight(coreBBox))
                pts = list(
                     llx-ringS:lly-ringS
                                                       ; points on inner edges
                     urx+ringS:lly-ringS
                     urx+ringS:ury+ringS
                     llx-ringS:ury+ringS
                                                 ; extending to outer edge
                     llx-ringS:lly-ringS-ringW
                     llx-ringS-ringW:lly-ringS-ringW ; points on outer edges
                     llx-ringS-ringW:ury+ringS+ringW
                     urx+ringS+ringW:ury+ringS+ringW
                     urx+ringS+ringW:lly-ringS-ringW
                     llx-ringS:lly-ringS-ringW)
                     ; layer is chosen for its color's visibility
```

Graphical Parameterized Cell Functions

Creates the database objects from SKILL++ Pcell class object, $\mbox{\tt RING}.$

Graphical Parameterized Cell Functions

pcExprToProp

```
pcExprToProp(
          txfl_argument
)
=> l_typeValue / nil
```

Description

Evaluates the argument and returns a list containing the data type and value of the result.

Arguments

txfl_argument

String, integer, floating-point number, list, or combination of data types forming a valid expression, that specify the argument.

Valid Values: String, integer, floating-point number, list, or a combination of data types that form a valid expression.

Value Returned

$l_typeValue$	List containing the following two elements: data type and value,
	where the data type can be a string, integer, or floating-point

number.

nil Returned if txfl_argument has an invalid data type or

contains an invalid expression.

Example 1

```
a = 1.5
b = 1.6
pcExprToProp(a + b + 3) => ("float" 6.1)
```

Returns the data type (floating-point number) and value (6.1) of the result of evaluating the specified argument.

Example 2

```
pcExprToProp('(23)) => "ilList" (23)
```

Returns the data type (list) and value (a list containing two numbers, 2 and 3).

Graphical Parameterized Cell Functions

pcFilterPoints

Description

Determines whether the specified list of coordinates represents a manhattan shape.

Arguments

Value Returned

Returns the list of coordinates when it represents a manhattan shape.

Returned if the list of coordinates does not represent a manhattan shape or the function did not complete successfully.

Example

The list of coordinates does represent a manhattan shape.

Graphical Parameterized Cell Functions

pcFix

Description

Converts a number to an integer in the format fixnum. When n_num is close to a whole number, the system keeps the integer part of the number and adds a single decimal place equal to zero. Here, close means the value of the number is within the range of plus or minus the value of $f_precision$ of the integer part of the number specified by n_num . When the value is not within this range, the function allows the system to use the value in the first decimal place to round the n_num to an integer in the format number.0; the system ignores all other decimal places. This function is useful for correcting the round-off approximation that can occur with floating-point numbers that are stored in 32 or 64 bits.

For example, if the condition you want to test is x = 15.0, use the pcFix function to ensure that results in the range from 14.999 to 15.999 are converted to 15.0. This implies the following:

When x equals	$\operatorname{pcFix}(x)$ returns
14.998	14.0
14.999	15.0
15.0	15.0
15	15.0
15.998	15.0
15.999	16.0

The following shows

the results of specifying the optional $f_precision$ argument:

When x equals	And f_precision equals	Then pcFix returns
14.998	0.001	14

Graphical Parameterized Cell Functions

14.998	0.005	15
14	0.001	14
14	0.005	14
14.0	0.001	14
14.0	0.005	14
14.999	0.0001	14
14.999	0.001	15

Arguments

n_num Any number you want to convert.

f_precision Floating-point number specifying number of decimal places to

the right of the decimal point to use as a range for determining whether n num is close to a whole number.

Whether II_IIam is close to a whole ha

Default: 0.001

Value Returned

x_result

A number with one decimal place that is equal to zero. If n_num does not contain a number, an error occurs; look in the CIW or at the CDS. log file for a message about the error.

Example

If you want to test for the condition x equals 6.0, you need to use pcFix to correct a possible rounding problem that could occur with a floating-point number. Otherwise, your condition might never be satisfied, because x might never be equal to 6.0; instead, it might be a close value, such as 5.9999999.

The following code shows how to use pcFix to correct floating-point rounding errors:

```
if( pcFix( x ) == 6.0
    ; perform conditional operations here
) ;endif
```

If you used the code shown below instead, your condition might never be satisfied:

$$x = 6.0$$

if ($x == 6.0$

Graphical Parameterized Cell Functions

; perform conditional operations here
) ;endif

Graphical Parameterized Cell Functions

pcGetBendAngle

Description

Determines whether the specified list of three coordinates represents a bend to the left (+90 degrees) or to the right (-90 degrees). The three coordinates must define a 90 degree angle.

Arguments

$l_pointList$	List of three coordinates in one of the following formats:
	list('(x1 y1) '(x2 y2) '(x3 y3))
	'(x1:y1 x2:y2 x3:y3)

Value Returned

x_signedDegrees	Returns the positive number 90 when the three coordinates represent a bend to the left; returns the number -90 when the three coordinates represent a bend to the right.
nil	Returned if the three coordinates do not represent a bend to the right or to the left, or if the function did not complete successfully.

Example

```
pcGetBendAngle( 0:1 1:0 1:1 ) => 90
```

The three coordinates represent a bend to the left.

Graphical Parameterized Cell Functions

pcGetCodeParamNames

Description

Returns a list of all the defined code parameter names for the specified design ID.

Arguments

d_cellviewId A Pcell super master ID or Pcell sub master ID. If you specify a

sub master ID, the function will obtain the defined code

parameter names from its super master.

Value Returned

1_codeParamNames A list of all the defined code parameter names of the specified

cellview ID.

nil No code parameter is defined for the specified cellview ID.

Example

```
pcGetCodeParamNames( cvId )
=> ( "param_1" "param_2" "param_3" )
```

Returns all the defined code parameter names for cvId.

Graphical Parameterized Cell Functions

pcGetCodeParamValue

```
pcGetCodeParamValue(
    d_cellViewId
    S_codeParamName
)
    => g_value / nil
```

Description

Returns the value of a specified code parameter.

Arguments

d_cellViewId	A Pcell super master ID or sub master ID. If cellView ID is a Pcell sub master ID, the function will obtain the code parameter from its super master.
S_codeParamName	The name of any defined code parameter. Type: Symbol or String.

Value Returned

g_value	Returns the value of the specified code parameter. The returned value can be integer, float, string, boolean, or a list.
nil	Specified code not found.

Example

```
createGateValue = pcGetCodeParamValue( cvId "createGate" )
=> t
```

In this example, <code>createGate</code> is a defined boolean code parameter. It returns the value of the <code>createGate</code> code parameter.

Graphical Parameterized Cell Functions

pcGetConditions

Description

Returns a list of identifiers for conditional inclusion parameters in the specified cellview.

Prerequisites

You must have defined the conditional inclusion parameters.

Arguments

 d_{CVId} The database ID of the cellview containing conditional inclusion

parameters.

Value Returned

1_condlist List of the object IDs used to store the details of the conditional

inclusion parameters.

nil Returned if d_{cvId} does not identify a cellview or if no

conditional inclusion parameters are defined in the cellview.

Example

```
condlist = pcGetConditions(cv)
```

Lists all conditional inclusion parameters defined in cv.

Graphical Parameterized Cell Functions

pcGetDefaultParamsFromClass

Description

Displays the defined Pcell parameter list from the specified class name.

Arguments

 $s_className$ A class symbol declared for a class name of a Pcell.

Value Returned

1_paramList The parameter list that contains (paramName paramType value).

Example

pcGetDefaultParamsFromClass('CORE)

Returns a defined Pcell parameter list from the specified class name, 'CORE.

Graphical Parameterized Cell Functions

pcGetInheritParamDefn

Description

Returns an identifier for an inherited parameter in the specified cellview.

Prerequisites

You must have defined the inherited parameter.

Arguments

d_instId	The database ID of the instance of the Pcell whose inherited
----------	--

parameter is to be retrieved.

Value Returned

I_Inneric Group id used to record details of the inhelited parameter	l_inherit	Group ID used to record details of the inherited parameter.
--	-----------	---

nil Returned if *d_instId* does not identify an instance as a Pcell

or if there is no inherited parameter defined in it.

Example

```
inherit = pcGetInheritParamDefn(inst)
```

Retrieves the inherited parameter defined in *d_instId*.

Graphical Parameterized Cell Functions

pcGetInheritParams

Description

Returns a list of identifiers for inherited parameters in the specified cellview.

Prerequisites

You must have defined the inherited parameter.

Arguments

 d_{CVId} The database ID of the cellview whose inherited parameters

you want listed.

Value Returned

1_inheritlist List of object IDs used to record details of the inherited

parameters.

nil Returned if d_cvId does not identify a cellview or if there are

no inherited parameters defined in the cellview.

Example

```
inheritlist = pcGetInheritParams( cv )
```

Gets a list of all the inherited parameters defined in cv.

Graphical Parameterized Cell Functions

pcGetOffsetPath

Description

Applies the offset to each vertex of the path to create a list of vertices for a longer or shorter version of the path. Returns a list of points for the vertices of the offset version of the path. This function does not change the original path and does not create the offset version of the path

Arguments

d_cvId	The database ID of the cellview containing the path.
l_vertex_points	A list of lists identifying a path in the cellview, where each sublist specifies the coordinates for one vertex. Use the following format: list($'$ (x y) $'$ (x y) $'$ (x y))
n_offset	An integer or floating-point number.

Value Returned

Example

```
pcGetOffsetPath( cv list( '(6.0 6.0) '(10.0 6.0) '(10.0 16.0) '(20.0 16.0) ) 2.0 )
```

Creates and returns the following list of points, which are offset from the specified path by 2.0:

```
((6.0 8.0)
(8.0 8.0)
(8.0 18.0)
```

Graphical Parameterized Cell Functions

(20.0 18.0)

Graphical Parameterized Cell Functions

pcGetOffsetPolygon

```
pcGetOffsetPolygon(
    d_cvId
    1_vertex_points
    n_offset
)
    => 1_vertex_points / nil
```

Description

Applies the offset to each edge of the polygon to create a list of the vertices for an oversized or undersized version of the polygon. Returns a list of points for the vertices of the offset version of the polygon. This function does not change the original polygon and does not create the offset version of the polygon

Arguments

d_cvId	The database ID of the cellview containing the polygon.
l_vertex_points	A list of lists identifying a polygon in the cellview, where each sublist specifies the coordinates for one vertex. Use the following format: list($'$ (\times y) $'$ (\times y) $'$ (\times y))
n_offset	An integer or floating-point number; a positive number specifies an oversized polygon, a negative number specifies an undersized polygon.

Value Returned

l_vertex_points	A list of lists specifying the vertices of an oversized or undersized version of the polygon after the offset has been applied. The list is in the following format: ($(x \ y) \ (x \ y) \ \dots \ (x \ y)$)
nil	The polygon was not found or the offset was not applied successfully.

Example

```
pcGetOffsetPolygon( cv list( '(2.7 2.4) '(8.0 2.4) '(8.0 7.1) '(6.4 7.1) '(6.4 4.3) '(2.7 4.3) ) 3.0 )
```

Graphical Parameterized Cell Functions

Oversize the polygon specified in the list by adding 3.0 to every edge, and returns the following points for the un-created oversized polygon:

```
((-0.3 -0.6)
(11.0 -0.6)
(11.0 10.1
(3.4 10.1)
(3.4 7.3)
(-0.3 7.3)
```

Graphical Parameterized Cell Functions

pcGetParamSlotType

```
pcGetParamSlotType(
    g_device
    s_propName
)
    => t_paramType
```

Description

Checks the type contained in the parameter slot propName of the given device. Parameter type is a string whose value is int, float, string, or iLList.

Arguments

g_device A SKILL++ Pcell class object that is inherited from class	device
--	--------

pcParamClass.

s_propName A parameter slot name of the given device.

Value Returned

t_paramType The type contained in the parameter slot propName of the

given device.

Example

```
pcell = makeInstance( 'CORE )
pcGetParamSlotType(pcell 'cyanW)
```

Returns the type of cyanW as float.

Graphical Parameterized Cell Functions

pcGetPathRefPoint

```
pcGetPathRefPoint(
    d_cvId
    l_objectVertices
    l_pathVertices
    t_endpoint
    l_offset
)
=> l_newObjVertices / nil
```

Description

Creates a list of coordinates representing the object specified by the $1_objectVertices$ argument when offset from the specified endpoint of the parameterized path, where the offset is defined by 1_offset and the path is defined $1_pathVertices$.

Graphical Parameterized Cell Functions

Arguments

 d_cvId The database ID of the cellview containing the parameterized

path.

1_objectVertices List of coordinates determining the object that is offset from the

parameterized path, in one of the following formats: list('(

x1 y1) '(x2 y2) ... '(xn yn)) list(x1:y1 x2:y2 ... xn:yn)

1_pathVertices List of coordinates identifying the parameterized path, in one of

the following formats: list('(x1 y1) '(x2 y2) ...

'(xn yn)) list(x1:y1 x2:y2 ... xn:yn)

t_endpoint String specifying an endpoint of the parameterized path.

Valid Values: "first" or "last"

Default: none

1_offset List specifying the distance by which the object is offset from

the endpoint of the parameterized path, where the elements of

the list are integers or floating-point numbers.

Valid Values: list of integers and/or floating-point numbers, or

nil

Default: none

Value Returned

1_newObjVertices List of coordinates specifying the object as located in

relationship to the specified endpoint of the parameterized path, offset by the specified distance. The list is in the following

format:

 $((x y) (x y) \dots (x y))$

where x and y can be an integer or floating-point number.

nil The function did not complete successfully.

Example

```
obj = list( 4.0:1.0 5.0:1.0 5.0:2.5 6.5:2.5 6.5:-0.5 4.0:-0.5 )
path = list( 0:0 0:9 )
```

Graphical Parameterized Cell Functions

The example specifies the original object with the variable obj and the parameterized path with the variable path. The pcGetPathRefPoint function then determines the new coordinates for the object in relationship to the last endpoint of the path, with no offset.

Graphical Parameterized Cell Functions

pcGetParameters

```
pcGetParameters(
    d_cvId
)
=> 1 paramlist / nil
```

Description

Returns a list of parameters and their default values defined in the specified cellview.

Note: You must have defined the parameters in this cellview.

Arguments

 d_{CVId} The database ID of the cellview containing the parameters.

Value Returned

l_paramlist	List of the parameter names and their default values. The list is in the form $(t_paramName\ g_defaultValue)$.
nil	Returned if d_cvId does not identify a cellview or if there are no parameters defined in the cellview.

Example

```
paramlist = pcGetParameters( cv )
```

Gets list of all parameters defined in ${\tt CV}.$

Graphical Parameterized Cell Functions

pcGetParamLabelDefn

Description

Returns the parameterized label identifier resulting from a call to pcDefineParamLabel on the specified label.

Prerequisites

You must have defined a parameterized label.

Arguments

d_labelId The database ID of the label whose parameterized label is to

be retrieved.

Value Returned

d_paramlabelId Object ID of the parameterized label.

nil Returned if *d_labelId* does not identify a label or there are

no parameterized labels defined in it.

Example

```
paramLabel = pcGetParamLabelDefn( label )
```

Retrieves parameterized labels defined in label.

Graphical Parameterized Cell Functions

pcGetParamLabels

Description

Returns a list of parameterized labels in the specified cellview.

Prerequisites

You must have defined a parameterized label.

Arguments

d_cvId The database ID of the cellview containing parameterized

labels.

Value Returned

1_labellist List of object IDs of the parameterized labels.

nil Returned if d_cvId does not identify a cellview or if there are

no parameterized labels defined in the cellview.

Example

```
labellist = pcGetParamLabels( cv )
```

Gets a list of all the parameterized labels defined in cv.

Graphical Parameterized Cell Functions

pcGetParamLayers

Description

Returns a list of identifiers for layer parameters in the specified cellview.

Prerequisites

You must have defined layer parameters for this cellview.

Arguments

d_cvId	The c	latak	oase	ID	of :	the	cellview	whose	layer	parameters	you
--------	-------	-------	------	----	------	-----	----------	-------	-------	------------	-----

want listed.

Value Returned

$l_layerlist$	List of object IDs used to record details of layer parameters.
----------------	--

nil Returned if d_cvId does not identify a cellview or if there are

no layer parameters defined in the cellview.

Example

```
layerlist = pcGetParamLayers( cv )
```

Gets a list of all the layer parameters defined in cv.

Graphical Parameterized Cell Functions

pcGetParamLayerDefn

Description

Returns the identifier for a layer parameter of a specified shape.

Prerequisites

You must have defined a layer parameter for this shape.

Arguments

d_instId The database ID of the shape whose layer parameter is to be

retrieved.

Value Returned

1_layerId Object ID used to record details of a layer parameter.

nil Returned if d_{instId} does not identify a shape or there are

no layer parameters defined in it.

Example

```
layer = pcGetParamLayerDefn( shape )
```

Retrieves the layer parameters defined in shape.

Graphical Parameterized Cell Functions

pcGetParamProps

Description

Lists parameterized properties in the specified cellview.

Prerequisites

You must have defined the parameterized properties.

Arguments

d_cvId The database ID of the cellview containing parameterized

properties.

Value Returned

1_proplist List of object IDs of parameterized properties.

nil Returned if d_cvId does not identify a cellview or if there are

no parameterized properties defined in the cellview.

Example

```
proplist = pcGetParamProps( cv )
```

Gets a list of all parameterized properties defined in cv.

Graphical Parameterized Cell Functions

pcGetParamShapeDefn

Description

Returns an identifier for a parameterized shape parameter resulting from a call to pcDefineParamPath, pcDefineParamPolygon, Or pcDefineParamRect.

Note: You must have defined the parameterized shape.

Arguments

d_instId The database ID of the shape whose parameterized shape

parameter is to be retrieved.

Value Returned

d_paramShapeId Group ID used to record details of the parameter.

nil Returned if d_{instId} does not identify a shape or there are

no parameterized shape parameters defined in it.

Example

```
paramshape = pcGetParamShapeDefn( shape )
```

Retrieves parameterized shape parameters defined in shape.

Graphical Parameterized Cell Functions

pcGetParamShapes

Description

Returns a list of identifiers for the parameterized shape parameters in the specified cellview.

Prerequisites

You must have defined a parameterized shape for this cellview.

Arguments

 d_{CVId} The database ID of the cellview containing the shape

parameters you want listed.

Value Returned

1_paramshapelist List of the object IDs of the shape parameters.

nil Returned if d_cvId does not identify a cellview or if there are

no parameterized shapes defined in the cellview.

Example

```
paramshapelist = pcGetParamShapes( cv )
```

Lists all shape parameters defined in CV.

Graphical Parameterized Cell Functions

pcGetParamSlotValue

```
pcGetParamSlotValue
    g_device
    s_propName
)
=> g_value
```

Description

Returns the value of the parameter slot, propName, of the specified device.

Arguments

g_device A SKILL++ Pcell class object that is inl	s inherited from class
---	------------------------

pcParamClass.

s_propName A Pcell slot name of the given device.

Value Returned

g_value The value of the parameter slot, propName, of the given

device.

Example

```
pcell = makeInstance( 'CORE )
pcGetParamSlotValue( pcell 'cyanW )
```

Returns the cyanw parameter slot value of the pcell.

Graphical Parameterized Cell Functions

pcGetRefPointDefn

Description

Returns an identifier for the reference point parameter defined in the specified cellview.

Prerequisites

You must have defined a reference point parameter for the cellview.

Arguments

d_objectId The databa	e ID of the object with the reference point
-----------------------	---

parameter.

Value Returned

l refPointId	Group ID used to record details of the reference poi	int
I_rerPointia	Group ID used to record details of the reference poi	ΠIL

parameter.

nil Returned if *d_objectId* does not identify an object or there

is no reference point parameter defined with it.

Example

```
refpoint = pcGetRefPointDefn( fig )
```

Retrieves a reference point parameter defined in fig.

Graphical Parameterized Cell Functions

pcGetRefPoints

Description

Returns a list of identifiers for all the reference point parameters in a specified cellview.

Prerequisites

You must have defined parameters in this cellview.

Arguments

d_cvId	The database	D of the cellview wl	hose reference point
--------	--------------	----------------------	----------------------

parameters you want listed.

Value Returned

l_refpointlist	List of object IDs used to record details of reference point

parameters.

nil Returned if d_cvId does not identify a cellview or if there are

no reference point parameters defined in the cellview.

Example

```
refpointlist = pcGetRefPoints( cv )
```

Gets a list of all the reference point parameters defined in cv.

Graphical Parameterized Cell Functions

pcGetRepeatDefn

Description

Returns a list of identifiers for all repetition parameters assigned to an object in the cellview. A single object can be assigned to more than one repetition group.

Prerequisites

You must have defined repetition parameters for the cellview.

Arguments

d_objectId	The database	ID of the ob	ject with re	petition parameters.

Value Returned

l_repeatlist	Group ID for the internal structure used to record details of repetition parameters. Returns one object ID for each repeat parameter defined on the given object.
nil	Returned if $d_objectId$ does not identify an object or there are no repetition parameters defined with it.

Example

```
repeat = pcGetRepeatDefn(fig)
```

Retrieves the repetition parameters defined for fig.

Graphical Parameterized Cell Functions

pcGetRepeats

Description

Returns a list of identifiers for repetition parameters in the specified cellview.

Prerequisites

You must have defined repetition parameters for the cellview.

Arguments

 d_{CVId} The database ID of the cellview with repetition parameters.

Value Returned

l_repeatlist	List of object IDs used to record the details of repetition parameters.
nil	Returned if d_{CVId} does not identify a cellview or if there are no repetition parameters defined in the cellview.

Example

```
repeatlist = pcGetRepeats( cv )
```

Lists all repetition parameters defined in cv.

Graphical Parameterized Cell Functions

pcGetStepDirection

Description

Returns the direction from the first point in the list to the second point in the list.

Arguments

```
1\_pointList List of coordinates in either of the following formats:

'( ( x1 y1 ) ( x2 y2 ) ) ( x1:y1 x2:y2 )
```

Value Returned

```
t\_step \textit{Direction} \qquad \text{String stating the direction of the step.} \\ \text{Valid Values: "up", "down", "right", "left"} \\ \text{nil} \qquad \qquad \text{The direction from the first point in the list to the second point in the list is neither vertical nor horizontal.} \\
```

Example

```
pcGetStepDirection( '( 0 0 ) '( 1 0 ) )
=> "right"
```

Returns the direction from point 0:0 to point 1:0.

Graphical Parameterized Cell Functions

pcGetSteppedObjectDefn

Description

Returns an identifier for repetition-along-shape parameters resulting from calls to pcDefineSteppedObject. The object cannot be a parameterized shape.

Prerequisites

You must have defined the repetition-along-shape parameters for this object.

Arguments

d_objectId Ine datab	ase ID of the object for which	ch repetition-along-shape
----------------------	--------------------------------	---------------------------

parameters are retrieved.

Value Returned

l stepobild	List of object IDs use	

parameterized shape parameters.

nil Returned if d_objectId does not identify an object that is

defined as a parameterized shape.

Example

```
stepobj = pcGetSteppedObjectDefn( fig )
```

Gets a list of all the repetition-along-shape parameters defined in cellview.

Graphical Parameterized Cell Functions

pcGetSteppedObjects

Description

Returns a list of identifiers for the repetition-along-shape parameters in the specified cellview.

Prerequisites

You must have defined repetition-along-shape parameters for this cellview.

Arguments

d_{cvId} The database ID of the cellview containing the repetition-a
--

shape parameters.

Value Returned

l_stepobjlist	List of object IDs used to record	details of the repetition-along-
	Elot of object ibe acca to record	actaile of the repetition along

shape parameters.

nil Returned if d_{cvId} does not identify a cellview or if there is no

repetition-along-shape parameters defined in the cellview.

Example

```
stepobjlist = pcGetSteppedObjects( cv )
```

Gets a list of all the repetition-along-shape parameters defined in cv.

Graphical Parameterized Cell Functions

pcGetStretchDefn

```
pcGetStretchDefn(
    d_objectId
)
=> d StretchId / nil
```

Description

Returns the identifier for a stretch parameter.

Note: You must have defined this line as a stretch control line.

Arguments

d_objectId The database ID of the line with the stretch parameter.

Value Returned

d_StretchId Group ID used to record details of the stretch control line.

Returned if a stretch control line is not defined.

Example

```
stretch = pcGetStretchDefn( stretchline )
```

Retrieves a stretch parameter defined with stretchline.

Graphical Parameterized Cell Functions

pcGetStretches

Description

Returns a list of identifiers for the stretch parameters in the specified cellview.

Prerequisites

You must have defined the stretch control lines.

Arguments

d_cvId	The database ID of the cellview containing the stretch
--------	--

parameters.

Value Returned

l_stretchlist	List of object IDs used to record details of the stretch

parameters.

nil Returned if d_cvId does not identify a cellview or if there are

no stretch parameters defined in the cellview.

Example

```
stretchlist = pcGetStretches( cv )
```

Gets a list of all stretch parameters defined in cv.

Graphical Parameterized Cell Functions

pcGetStretchSummary

Description

For a parameterized master cell created using the Virtuoso Pcell graphical user interface tool, returns a list of lists, where each list contains the field names and values from the Stretch in X and Stretch in Y forms for each stretch line that was defined for the parameterized cell.

Arguments

d_cvId The database ID of the cellview containing a Pcell master with

stretch lines.

Value Returned

1_stretchLines A list of lists, where each list contains the field names and

values from the Stretch in X and Stretch in Y forms for one

stretch line that was defined for the Pcell.

nil The function did not execute successfully.

Example

```
pcStretchSummary( cv )
```

For a Pcell master containing two stretch lines, returns a list containing two lists, each of which contain the form field names and values for one stretch line; for example:

```
(("Stretch Type: Horizontal " "Name or Expression for Stretch: Length" "Stretch Direction: left" "Reference Dimension (Default): 1.000000")

("Stretch Type: Vertical " "Name or Expression for Stretch: width" "Stretch Direction: up" "Reference Dimension (Default): 1.000000")
)
```

Graphical Parameterized Cell Functions

pcGrowBox

Description

Increase or decrease the size of the specified box by the specified margin. The system adds xf_{margin} to each coordinate in the list and returns a list of the coordinates of the resulting box.

Arguments

l_pointList

List of coordinates defining the original rectangular box, in either of the following formats:

```
'( (x1 y1 ) (x2 y2 ))
(x1:y1 x2:y2 )
```

xf_margin

Positive or negative integer or floating-point number used to increment or decrement the points of the original box.

Valid Values: integer or floating-point number

Value Returned

l incrementedPointList

List of coordinates defining the incremented box, in either of the following formats:

```
'((x1 y1)(x2 y2))
(x1:y1 x2:y2)
```

nil

The function did not complete successfully.

Example

```
pcGrowBox('(0:0 2:2) 5.5)
=>((-5.5 -5.5)
(7.5 7.5))
```

Graphical Parameterized Cell Functions

Increments the two points of the original box by 5.5 and returns a list of the points defining the incremented box.

Graphical Parameterized Cell Functions

pcGrowPoints

Description

Increase or decrease the size of a manhattan polygon by the specified margin. The system adds xf_{margin} to each coordinate in the list and returns a list of the coordinates of the resulting polygon.

Arguments

1_pointList List of coordinates defining the original manhattan polygon, in

either of the following formats:

```
'((x1 y1)(x2 y2)...(xn yn))
(x1:y1 x2:y2 ... xn:xy)
```

xf_margin

Positive or negative integer or floating-point number used to increment or decrement the points of the original manhattan polygon.

Valid Values: integer or floating-point number

Value Returned

1_incrementedPointList

List of coordinates defining the incremented manhattan polygon, in either of the following formats:

```
'((x1 y1)(x2 y2)...(xn yn))
(x1:y1 x2:y2 ... xn:xy)
```

nil

The function did not complete successfully.

Example

Graphical Parameterized Cell Functions

```
(-5.0 11.0)
(-5.0 12.5)
(16.5 12.5)
(16.5 -10.5)
(-6.0 -10.5)
```

Increments each point of the original manhattan polygon by 10 and returns a list of the points of the incremented polygon.

Graphical Parameterized Cell Functions

pcHICompileToSkill

Description

Displays the <u>Compile To SKILL</u> form to let you create a SKILL file from the data in the current cellview. The file can then be edited as any SKILL file.

Prerequisites

Before you compile a cellview to a SKILL file, you must define all parameters for the cellview.

Arguments

None.

Value Returned

t The SKILL file was created.

nil The SKILL file was not created.

Graphical Parameterized Cell Functions

pcHIDefineCondition

Description

Lets you designate specified objects as conditional by prompting you to select one or more objects in the current cellview. When you complete selecting objects, the system displays the <u>Conditional Inclusion</u> form.

Arguments

None.

Value Returned

t The objects were defined as conditional.

nil The objects were not defined as conditional.

Graphical Parameterized Cell Functions

pcHIDefineInheritedParameter

Description

Lets you designate a Pcell instance whose parameters should be inherited from the Pcell parent in which the instance is placed by prompting you to select the instance in the current cellview. After you select the instance, the system displays the <u>Define/Modify Inherited Parameters</u> form.

Arguments

None.

Value Returned

t The function completed successfully.

nil The function did not complete successfully.

Graphical Parameterized Cell Functions

pcHIDefineLabel

Description

Displays the <u>Define Parameterized Label</u> form to let you create a parameterized label for Pcell you are currently editing. After you complete the form, the system prompts you to enter an anchor point for the label.

Arguments

None.

Value Returned

t The label was created.

nil The label was not created.

Graphical Parameterized Cell Functions

pcHIDefineLayer

Description

Lets you designate specified shapes to be in a parameterized layer group by prompting you to select one or more shapes in the current cellview. When you complete selecting shapes, the system displays the <u>Define Parameterized Layer</u> form.

Arguments

None.

Value Returned

t The parameterized label group was created.

nil The parameterized label group was not created.

Graphical Parameterized Cell Functions

pcHIDefineParamCell

```
pcHIDefineParamCell(
      [ l_cellIdentifier ]
)
      => t / nil
```

Description

Displays the <u>Compile To Pcell</u> form to let you create a graphical Pcell (super) master in the database from the design in the current window or from the cellview you specify. If you do not compile a Pcell before you place an instance of it in another design, the system interprets the design as a standard fixed cell instead of a Pcell. Each time you edit a graphical Pcell, you must recompile it so that all placed instances reflect the changes.

Prerequisites

You must have already defined parameters for the cellview.

Arguments

1_cellIdentifier Database ID for the cellview (cellview ID).

Default: Current cellview ID

Value Returned

t The parameterized (super) master was created.

nil The parameterized (super) master was not created.

Example

```
pcHIDefineParamCell( cellview Id )
```

Displays the Compile To Pcell form.

Graphical Parameterized Cell Functions

pcHIDefineParameterizedShape

Description

Lets you assign the vertices of a shape as parameters of the Pcell you are currently editing by prompting you to select a shape. You can parameterize paths, polygons, and rectangles. When you place an instance of the Pcell, you supply values for the parameters by entering coordinates.

You can define multiple shapes in the same Pcell master as parameterized, as long as they are all of the same shape type. For example, you can define several rectangles as parameterized, but you cannot define one rectangle and one polygon as parameterized in the same Pcell master. For more information about parameterized shapes, see "Parameterized Shapes Commands" in the <u>Virtuoso Parameterized Cell Reference</u>.

Arguments

None.

Value Returned

t The parameterized shape was created.

nil The parameterized shape was not created.

Graphical Parameterized Cell Functions

pcHIDefineParamRefPointObject

Description

Lets you specify a reference point parameter as the origin point for a selected object or group of objects in the Pcell you are currently editing. The system prompts you for the reference point, then prompts you to select the object(s). When you complete selecting objects, the system displays the <u>Reference Point by Parameter</u> form. There can be only one reference point parameter defined in a Pcell.

Arguments

None.

Value Returned

t The parameterized reference point was created.

nil The parameterized reference point was not created.

Graphical Parameterized Cell Functions

pcHIDefinePathRefPointObject

Description

Lets you specify the end of a parameterized path as the reference point for objects in the Pcell you are currently editing by prompting you to select the objects. When you complete selecting objects, the system displays the <u>Reference Point by Path Endpoint</u> form. There can be only one reference-point-by-path-endpoint parameter defined in a Pcell.

Prerequisites

The parameterized path must exist before you define the reference point.

Arguments

None.

Value Returned

t The reference point was created.

nil The reference point was not created.

Graphical Parameterized Cell Functions

pcHIDefineProp

Description

Displays the <u>Parameterized Property</u> form to let you specify a property for the Pcell you are currently editing.

Arguments

None.

Value Returned

t The property was created.

nil The property was not created.

Graphical Parameterized Cell Functions

pcHIDefineRepeat

```
pcHIDefineRepeat(
    t_direction
)
=> d repeatId
```

Description

Lets you define a repetition parameter for specified objects by prompting you to select one or more objects in the current cellview. When you complete selecting objects, the system displays one of the following forms, depending on the value of the $t_direction$ argument: Repeat in X, Repeat in Y, or Repeat in X and Y.

Arguments

t_direction Direction of repetition. When the value is 2D, the function

creates a two-dimensional array.

Valid Values: horizontal, vertical, 2D

Value Returned

d_repeatId Group ID used to store details of the repetition.

Example

```
pcHIDefineRepeat( "horizontal" )
```

Prompts you to select objects in the current cellview and then displays the Repeat in X form.

Graphical Parameterized Cell Functions

pcHIDefineSteppedObject

Description

Lets you specify an object or group of objects to repeat along the coordinate string controlling a parameterized shape by prompting you to select the objects in the Pcell you are currently editing. The Pcell must already contain a parameterized shape. When you complete selecting objects, the system displays the <u>Repeat Along Shape</u> form.

Arguments

None.

Value Returned

t The repetition group was created.

nil The repetition group was not created.

Graphical Parameterized Cell Functions

pcHIDefineStretch

```
pcHIDefineStretch(
    t_direction
)
=> d StretchId
```

Description

Allows you to define a stretch parameter for specified objects by prompting you to select one or more objects in the current cellview. The argument $t_direction$ determines which form the system displays when you complete selecting objects: Stretch in X or Stretch in Y.

Arguments

t_direction Direction of the stretch.

Valid Values: right, left, rightAndLeft, up, down,

upAndDown

Value Returned

d_StretchId Group ID used to store the details of the stretch parameter.

Example

```
pcHIDefineStretch( "up" )
```

Prompts you to select objects in the current cellview and then displays the Stretch in Y form.

Graphical Parameterized Cell Functions

pcHIDeleteCondition

Description

Lets you delete an object from a conditional induction group by prompting you to select the object in the current cellview. When you select the object, the system displays the <u>Delete Conditional Inclusion</u> form.

Arguments

None.

Value Returned

t The object was removed from the conditional inclusion group.

nil The object was not removed from the conditional inclusion group.

Graphical Parameterized Cell Functions

pcHIDeleteLayer

Description

Lets you remove a parameterized layer group by prompting you to select a shape in the group. When you select a shape, the system highlights all objects in the parameterized layer group and displays the <u>Delete Parameterized Layer</u> form.

Arguments

None.

Value Returned

t The parameterized layer group was deleted.

nil The parameterized layer group was not deleted.

Graphical Parameterized Cell Functions

pcHIDeleteParameterizedShape

Description

Lets you delete a parameterized shape from the Pcell you are currently editing by prompting you to select the parameterized shape. When you delete a parameterized shape, the coordinates of the shape are no longer parameters of the Pcell.

Arguments

None.

Value Returned

t The parameterized shape was deleted.

nil The parameterized shape was not deleted.

Graphical Parameterized Cell Functions

pcHIDeleteProp

Description

Displays the <u>Delete Parameterized Property</u> form to let you specify a property to delete from the Pcell you are currently editing. When there is more than one parameterized property defined for the Pcell, click *Next* to view another property.

Arguments

None.

Value Returned

t The property was deleted.

nil The property was not deleted.

Graphical Parameterized Cell Functions

pcHIDeleteRefPointObject

Description

Lets you delete either a reference point defined as a parameter of the cellview or a reference point defined relative to the endpoint of a parameterized path by prompting you to select any object in the reference point group. After you select an object, the system highlights all objects in the group and opens either the <u>Delete Reference Point</u> form or the <u>Delete Reference Point</u> <u>By Path</u> form.

Arguments

None.

Value Returned

t The reference point group was deleted.

nil The reference point group was not deleted.

Graphical Parameterized Cell Functions

pcHIDeleteRepeat

Description

Lets you delete a repeat group from the Pcell you are currently editing by prompting you to select a shape in the repeat group you want to delete. After you select a shape, the system highlights all shapes in the group and displays one of the following forms, depending on the type of repeat group you selected: <u>Delete Repeat in X</u>, <u>Delete Repeat in Y</u>, or <u>Delete Repeat in Y</u>, or <u>Delete Repeat in Y</u>, and Y.

Arguments

None.

Value Returned

t The repeat group was deleted.

nil The repeat group was not deleted.

Graphical Parameterized Cell Functions

pcHIDeleteSteppedObject

Description

Lets you delete a repetition along shape group from the Pcell you are currently editing by prompting you to select a member (shape) of the repetition along shape group.

Arguments

None.

Value Returned

t The repetition along shape group was deleted.

nil The repetition along shape group was not deleted.

Graphical Parameterized Cell Functions

pcHIDisplayCondition

Description

Highlights a conditional inclusion group in the current cellview window and displays the <u>Show Conditional Inclusion</u> text window with information about the highlighted group. When there is more than one conditional inclusion group, click *OK* in the text window to view the next one.

Arguments

None.

Value Returned

t Highlights inclusion groups and displays the Show Conditional

Inclusion text window.

nil There are no inclusion groups or the Show Conditional

Inclusion text window did not display.

Graphical Parameterized Cell Functions

pcHIDisplayInheritedParameter

Description

Highlights a Pcell instance whose parameters are inherited from the Pcell parent in which the instance is placed and displays the <u>Show Inherited Parameters</u> text window with information about the highlighted instance. When there is more than one Pcell instance with inherited parameters, click *OK* in the text window to view the next one.

Arguments

None.

Value Returned

t	Highlights instances with inherited	d parameters and displays the

Show Inherited Parameters text window.

nil There are no instances with inherited parameters or the Show

Inherited Parameters text window did not display.

Graphical Parameterized Cell Functions

pcHIDisplayLayer

Description

Highlights a parameterized layer group in the current cellview window and displays <u>Show Parameterized Layer</u> text window with information about the highlighted group. When there is more than one parameterized layer group, click *OK* in the text window to view the next one.

Arguments

None.

Value Returned

t Highlights parameterized layer groups and displays the Show

Parameterized Layer text window.

nil There are no parameterized layer groups or the Show

Parameterized Layer text window did not display.

Graphical Parameterized Cell Functions

pcHIDisplayParameterizedShape

Highlights a parameterized shape in the current cellview window and displays the <u>Show Parameterized Shape</u> text window with information about the highlighted group. When there is more than one parameterized shape, click *OK* in the text window to view the next one.

Arguments

None.

Value Returned

t Highlights parameterized shapes and displays the Show

Parameterized Shape text window.

nil There are no parameterized shapes or the Show Parameterized

Shape text window did not display.

Graphical Parameterized Cell Functions

pcHIDisplayParams

Description

Although the pcHIDisplayParams function still displays the Show Parameters text window, the information contained in the window might not be complete. The Show Parameters command has been replaced by the Edit Parameters command. To display information about Pcell parameters, use either the pcHIEditParameters function or the pcHIParamsSummarize function.

Arguments

None.

Value Returned

t The Show Parameters text window displays or there are no

parameters defined for the Pcell.

nil There are no parameters defined for the Pcell or if the Show

Parameters text window does not display.

Graphical Parameterized Cell Functions

pcHIDisplayProp

Description

Displays a <u>Show Parameterized Property text</u> window with information about all parameterized properties defined for the Pcell you are currently editing.

Arguments

None.

Value Returned

t The text window was displayed.

nil The text window was not displayed.

Graphical Parameterized Cell Functions

pcHIDisplayRefPointObject

Description

Highlights a reference point group in the current cellview window and opens the <u>Show</u> <u>Reference Point</u> text window with information about the highlighted group. When there is more than one reference point group, click *OK* in the text window to view the next one.

Arguments

None.

Value Returned

t The Show Reference Point text window displays or there are no

reference point groups.

nil There are no reference point groups or the Show Reference

Point text window did not display.

Graphical Parameterized Cell Functions

pcHIDisplayRepeat

Highlights a repeat group in the current cellview window and displays one of the following text windows, depending on the type of group you selected: Show Repeat in X, Show Repeat in Y, or Show Repeat in X and Y with information about the highlighted group. When there is more than one repeat group, click OK in the text window to view the next one.

Arguments

None.

Value Returned

t A repeat group exists and the text window was displayed.

nil A repeat group does not exist.

Graphical Parameterized Cell Functions

pcHIDisplaySteppedObject

Description

Highlights the objects in a repetition along shape group in the current cellview window and opens the <u>Show Repetition Along Shape</u> text window with information about the highlighted group. When there is more than one repetition along shape group, click *OK* in the text window to view the next one.

Arguments

None.

Value Returned

t Highlights objects in a repetition along shape group and opens

the text window.

nil There are no repetition along shape groups or the text window

does not display.

Graphical Parameterized Cell Functions

pcHIEditParameters

Description

Lets you change the data type and/or value for parameters already defined for the Pcell by displaying the <u>Edit Parameters</u> form.

Arguments

None.

Value Returned

t Always returns t.

Graphical Parameterized Cell Functions

pcHIModifyCondition

Description

Lets you add objects to a conditional inclusion group by prompting you to select an object in the inclusion group you want to modify. The system highlights all objects in the selected group and prompts you to select shapes to be added to the group. When you complete selecting the objects, the system displays the <u>Modify Conditional Inclusion</u> form.

Arguments

None.

Value Returned

t Selected shapes were added to the conditional inclusion group.

nil Selected shapes were not added to the conditional inclusion

group.

Graphical Parameterized Cell Functions

pcHIModifyLabel

Description

Prompts you to select the parameterized label you want to modify. After you select the label, displays the <u>Modify Parameterized Label</u> form to let you change the values for the selected label.

Arguments

None.

Value Returned

t The parameterized label was modified.

nil The parameterized label was not modified.

Graphical Parameterized Cell Functions

pcHIModifyLayer

Description

Lets you add shapes to a parameterized layer group by prompting you to select an object in the layer group you want to modify. The system highlights all objects in the selected group and prompts you to select shapes to be added to the group. When you complete selecting the shapes, the system displays the <u>Modify Parameterized Layer</u> form.

Arguments

None.

Value Returned

group.

nil The selected shapes were not added to the parameterized layer

group.

Graphical Parameterized Cell Functions

pcHIModifyParams

Description

Lets you change the data type and/or value for parameters already defined for the Pcell by displaying the <u>Edit Parameters</u> form. This function is equivalent to the pcHIEditParameters function.

Arguments

None.

Value Returned

t Always returns t.

Graphical Parameterized Cell Functions

pcHIModifyRefPointObject

Description

Lets you add objects to a reference group by prompting you to select an object in the group you want to modify. The system highlights all objects in the selected group and prompts you to select shapes to be added to the group. When you complete selecting the shapes, the system lets you change the reference point by displaying either the <u>Reference Point by Parameter</u> form or the <u>Reference Point by Path Endpoint</u> form, depending on the type of group you selected. There can be only one reference point parameter and only one reference point by path endpoint defined for a Pcell.

Arguments

None.

Value Returned

t The reference group was modified.

nil The reference group was not modified.

Graphical Parameterized Cell Functions

pcHIModifyRepeat

Description

Lets you add shapes to a repeat group by prompting you to select a shape in the repeat group you want to modify. After you select an object, the system highlights all shapes in the group and prompts you to select shapes to be added to the group. When you complete selecting shapes, the system displays one of the following forms, depending on the type of repeat group you selected: Modify Repeat in X, Modify Repeat in Y, or Modify Repeat in X and Y.

Arguments

None.

Value Returned

t The repeat group was modified.

nil The repeat group was not modified.

Graphical Parameterized Cell Functions

pcHIModifySteppedObject

Description

Lets you add shapes to a repetition along shape group by prompting you to select a shape in the group you want to modify. After you select a shape, the system highlights all shapes in the group and displays the <u>Modify Repetition Along Shape</u> form.

Arguments

None.

Value Returned

t The repetition along shape group was modified.

nil The repetition along shape group was not modified.

Graphical Parameterized Cell Functions

pcHIModifyStretchLine

Description

Prompts you to select the stretch line you want to modify. After you select a stretch line, displays the <u>Stretch in X or Stretch in Y</u> form, depending on whether you are modifying an X stretch line or a Y stretch line, to let you change the values for the selected stretch line.

Arguments

None.

Value Returned

t The stretch line was modified;.

nil The stretch line was not modified.

Graphical Parameterized Cell Functions

pcHIQualifyStretchLine

Description

Lets you add shapes to be affected by a stretch line by prompting you to select the stretch line. After you select a stretch line, prompts you to select the shapes to be affected. No form is displayed.

Arguments

None.

Value Returned

t The stretch line was qualified.

nil The stretch line was not qualified.

Graphical Parameterized Cell Functions

pcHIRedefineStretchLine

Description

Lets you redefine a previously defined stretch control line or change the parameters assigned to a stretch control line by prompting you to select the stretch line. After you select a stretch line, the system prompts you to draw a stretch line to replace the selected stretch line. After you draw the line, the system displays the <u>Stretch in X</u> or <u>Stretch in Y</u> form, depending on whether you are redefining an X stretch line or a Y stretch line, to let you change the values for the redefined stretch line.

Arguments

None.

Value Returned

t The stretch line was redefined.

nil The stretch line was not redefined.

Graphical Parameterized Cell Functions

pcHISummarizeParams

Description

Displays the <u>Pcell Parameter Summary</u> text window with information about the parameters defined for the Pcell.

Arguments

None.

Value Returned

t The Pcell Parameter Summary text box was displayed.

nil The Pcell Parameter Summary text box was not displayed.

Graphical Parameterized Cell Functions

pclsParamSlot

```
pcIsParamSlot(
    g_device
    s_propName
)
    => t / nil
```

Description

Checks whether the specified propName is a parameter slot of the specified device.

Arguments

g_device	A SKILL++ Pcell class object that is inherited from the class
	_

pcParamClass.

 $s_propName$ A parameter slot name of the given device.

Value Returned

t If the specified propName is a parameter slot of the specified

device.

nil If the specified propName is not a parameter slot of the

specified device.

Example

```
pcell = makeInstance( 'CORE )
pcIsParamSlot( pcell 'cyanW )
=> t
```

Returns t because \mathtt{cyanW} is defined as a parameter slot in CORE class.

Graphical Parameterized Cell Functions

pcModifyParam

Description

Lets you modify the parameter type and default value for parameters assigned to a compiled Pcell.

Arguments

d_cvId	The database ID of the specified cellview.

S_param Name of the parameter.

Valid Values: a string or symbol

 t_type Type of the parameter.

Valid Values: int, float, Boolean, string, ILList

g_value Default value of the parameter. Valid Value: any value

consistent with the value type specified

Value Returned

d_paramId Group ID of the property that stores the parameter.

nil Returned if the function does not execute.

Example

```
pcModifyParam( supermaster "gateWidth" "float" 0.625 )
```

The above example modifies the parameter gateWidth to have float as its type and 0.625 as its default value.

Graphical Parameterized Cell Functions

pcRedefineStretchLine

```
pcRedefineStretchLine(
    d_lineId
    g_paramExpr
    t_direction
    f_defval
    f_minval
    f_maxval
    g_stretchRepeated
)
=> d_StretchId / nil
```

Description

Redefines the attributes of an existing stretch control line. You can also specify a new location for the stretch control line with this command.

Note: You must have defined the stretch control line.

Arguments

d_lineId	The database ID of the stretch control line.
g_paramExpr	SKILL expression or symbol controlling the stretch.
t_direction	Direction of the stretch.
	Valid Values: right, left, rightAndLeft, up, down, upAndDown
f_defval	Default value (reference dimension) for the stretch.
f_minval	Minimum value for the stretch.
f_maxval	Maximum value for the stretch. Use ${\tt nil}$ if no maximum is specified.
g_stretchRepeated	Boolean expression indicating whether to stretch shapes repeated in the direction parallel to the stretch.

Value Returned

d_StretchId	Group ID used to store stretch parameter details.
nil	Returned if d_1ineId is not defined as a stretch control line.

Graphical Parameterized Cell Functions

Example

pcRedefineStretchLine(stretchLine 'nfetWidth "rightAndLeft" 1.00 1.00 25 nil)

Redefines the stretch control line stretchLine as controlled by the parameter nfetWidth. The stretch direction is rightAndLeft. The default and minimum values are 1.00, and the maximum value is 25. Horizontally repeated shapes are not affected.

Graphical Parameterized Cell Functions

pcRestrictStretchToObjects

Description

Lets you specify the objects affected by a particular stretch control line. Objects not specified are not moved or stretched by this stretch control line.

Arguments

$d_stretchId$	The database ID of the stretch control line.
l_objlist	List of objects whose location can be affected by this stretch control line. If nil , the stretch applies to all objects.

Value Returned

d_stretchId	Group ID used to store the stretch details.
nil	Returned if $d_stretchId$ is not defined or if there are no
	objects in the list of objects.

Example

```
pcRestrictStretchToObjects( stretchLine
geGetSelSet( getCurrentWindow( ) ) )
```

Restricts the effect of the stretch control line to only the selected objects in the cellview in the current window.

Graphical Parameterized Cell Functions

pcRound

Description

Lets you round a number to the closest integer, using the value of the decimal place specified by $x_tolerance$; additional decimal places are ignored. If the value of the specified decimal place is less than 5, the system drops all decimal places; if the value of the specified decimal place is greater than or equal to 5, the system drops all decimal places and adds one to the integer.

Arguments

f_precision Floating-point number specifying number of decimal places to

the right of the decimal point to use as a range for determining

whether n_num is close to a whole number.

Default: 0.001

x_tolerance Positive integer specifying the decimal place to use for

rounding. For example, a value of 1 specifies 0.5, 2 specifies 0.05, 3 specifies 0.005, 4 specifies 0.0005, and so on. The

numbers in other decimal places are ignored.

Default: 1

Value Returned

 x_result An integer. If n_num does not contain a number, an error

occurs; look in the CIW or at the CDS.log file for a message

about the error.

Example

The examples below show numbers rounded using pcRound.

Graphical Parameterized Cell Functions

```
pcRound( 1.49 ) results in 1
pcRound( -1.49) results in -1
pcRound( 1.59 ) results in 2
pcRound( -1.59 ) results in -2
pcRound( 5.4993 0.001 1 ) results in 6
pcRound( 5.4993 0.001 2 ) results in 5
pcRound( 5.4993 0.002 1 ) results in 6
pcRound( 5.4993 0.002 1 ) results in 5
```

Graphical Parameterized Cell Functions

pcSetFTermWidth

```
pcSetFTermWidth(
    t_baseName
    x_width
)
=> t_baseName_width / nil
```

Description

Creates a net or terminal name and assigns a width.

Arguments

t_baseName	String specifying the base name for the net or terminal.
x_width	Integer specifying the width of the net or terminal.

Value Returned

t_baseName_width	String specifying the base name followed by the width, in the following format:
	"baseName <n1:n2>"</n1:n2>
nil	Returned if the function does not complete successfully.

Example

Creates a net or terminal with the base name "test" and assigns a width of 20.

Graphical Parameterized Cell Functions

pcSetParamSlotsFromMaster

```
pcSetParamSlotsFromMaster(
    g_device
    d_cv
)
=> t / nil
```

Description

Sets the class slot values of a specified device to the corresponding Pcell parameter values on a specified Pcell super master or sub master.

Arguments

g_device	An object of the SKILL++ Pcell class, which is inherited from the
	class pcParamClass.
d cv	A Pcell super master ID or Pcell sub master ID.

Value Returned

t	If the class slot values of the specified device are set.
nil	Unable to set the device's class slot values.

Example

```
pcell = makeInstance( 'CORE )
pcSetParamSlotsFromMaster( pcell pcCellView )
```

In this example, pcCellView is either a Pcell super master ID or sub master ID.

Graphical Parameterized Cell Functions

pcSetParamSlotValue

```
\begin{array}{c} {\rm pcSetParamSlotValue} \\ {\it g\_device} \\ {\it s\_propName} \\ {\it g\_value} \\ ) \\ {\it => g\_value} \end{array}
```

Description

Sets the value of the specified parameter slot, propName, of the given device.

Arguments

g_device	A SKILL++ Pcell class object that is inherited from class pcParamClass.
s_propName	A Pcell slot name of the given device.
g_value	The value of a parameter slot.

Value Returned

g_value The value of the parameter slot, propName, of a given device.

Example

```
pcell = makeInstance( 'CORE )
pcSetParamSlotValue( pcell 'cyanW 2.0 )
```

Sets the cyanW parameter slot value of the Pcell to 2.0.

Graphical Parameterized Cell Functions

pcSkillGen

```
pcSkillGen(
    d_cellViewId
    t_outputFile
    g_isSkillFile
    [ 'disablePrompt ]
    )
    => t / nil
```

Description

Converts a specified cellview into a SKILL file. A SKILL file can be edited and loaded back to a cellview after modification. Loading a SKILL file generates a SKILL master; however, the cellview contains only a label with the text: Warning: The master is defined by the SKILL procedure associated with the cellview.

Prerequisites

You must have defined the parameters in this cellview.

Arguments

d_cellViewId	Cellview to be converted to SKILL.
t_outputFile	The destination text file.
g_isSkillFile	If t, generates a pcGenCell procedure. If nil, generates a SKILL function.
'disablePrompt	If set to $ t$, a prompt, which is displayed during the Pcell master compilation, gets disabled whenever no parameter is specified in the cell.

Value Returned

t The SKILL file was created.

nil The SKILL file was not created.

Example

```
pcSkillGen(cv ~/mySkillCell t)
```

Graphical Parameterized Cell Functions

Puts the SKILL code that creates the cellview cv in the ~/mySkillFile file. For example:

```
let( ( pcMember pcStretchGroup stretchOffsetX stretchOffsetY pcLib
pcMaster pcInst pcTerm pcPin pcPinName
       pcNet pcTermNet pcNetName pcTermNetName pcMosaicInst
       tpcParameters pcParamProp pcStep pcStepX pcStepY
       pcRepeat pcRepeatX pcRepeatY pcIndexX pcIndexY
       pcLayer pcPurpose pcLabelText pcLabelHeight pcPropText
       pcParamText pcCoords pcPathWidth pcPolygonMargin )
pcLib = pcCellView~>lib
pcParameters = pcCellView~>parameters~>value
; generate all the cv's properties
; -----
; generate all the primitive shapes in layer "pwell (drawing)"
pcLayer = 6
pcPurpose = "drawing"
pcInst = dbCreateRect(pcCellView list(pcLayer pcPurpose) list(2:0.5 6.5:7.5))
pcSkillGen(cv ~/mySkillCell nil)
```

Puts the SKILL code that creates the cellview cv inside a pcGenCell procedure and writes it to the ~/mySkillFile file. For example:

Graphical Parameterized Cell Functions

pcStepAlongShape

Description

Replicates a shape $(d_shape1Id)$ along a second shape $(1_shape2Points)$ by specifying a disembodied property list to define the stepping distance, gap between successive replications, starting offset, ending offset, and object type. The pitch is determined by the offset of the origin of $d_shape1Id$ from the point 0:0. You specify the second shape $(1_shape2Points)$ with a list of coordinates.

Graphical Parameterized Cell Functions

Arguments

 d_shape1

The database ID of the shape to be replicated.

1_stepDetails

Disembodied property list, which is a list that starts with a SKILL data object, in this case, nil, followed by alternating symbol name/value pairs, and is not attached to a specific object or symbol. The attributes contained in the list are:

List of coordinates specifying the second shape, in one of the following formats:

```
list('(x1 y1)'(x2 y2)...'(xn yn))'(x1:y1 x2:y2 ... xn:yn)
```

Value Returned

t

The shape, *d_shape1Id*, was replicated successfully.

ni1

The shape, $d_shape1Id$, was not replicated successfully.

Example

Replicates shape1, a polygon, along shape2, a rectangle, with a stepping distance of 1.5, gap of 2, starting offset of 0, and ending offset of 2.

Graphical Parameterized Cell Functions

auHiUltraPCell

```
auHiUltraPCell(
    [ t_filename ]
)
    => t / nil
```

Description

Displays the <u>Ultra Pcell</u> form to let you create an Ultra Pcell by compiling multiple Pcells into one cell. Optionally, you can save the Ultra Pcell SKILL code in a file by specifying the $t_filename$ argument. For a description of Ultra Pcells, see the <u>Make Ultra Pcell</u> Command in the *Virtuoso Parameterized Cell Reference*.

Prerequisites

Ultra Pcells have the following requirements:

- Multiple Pcell layouts need not be in the same cell, although they must be in the same library as the completed ultra Pcell.
- Each Pcell must compile successfully.
- Each Pcell must have identical parameters and default values. No Pcell can have more or fewer or different parameters from the other Pcells. When the Ultra Pcell is compiled, it has all of the parameters, which work as designed in each Pcell.
- The selector parameter must be unique. It cannot match any other parameter.
- type, objType, name, cell, and status are reserved words and cannot be used as selector parameters.

Graphical Parameterized Cell Functions

Arguments

t_filename Filename (or path and filename) in which you want to save the

SKILL code output by the *Make Ultra Pcell* command.

Value Returned

t The form opened, and optionally, the SKILL file was created.

nil The form did not opened or the SKILL file was not created;.

Example

```
auHiUltraPCell( "myUltraPcell.il" )
```

Creates an Ultra Pcell, saving the Pcell code in the file named myUltraPcell.il.

Graphical Parameterized Cell Functions

Pcell Compiler Customization SKILL Functions

This section provides syntax, descriptions, and examples for the SKILL functions associated with customizing the Pcell compiler. Refer to "Customizing the Pcell Compiler" in the Parameterized Cell Reference Guide for more information.

Graphical Parameterized Cell Functions

pcUserAdjustParameters

Description

A user-defined procedure called by the compiler before it processes any objects. The procedure is normally used to generate code to transform user-specified parameter values, such as to snap them to an even value. Parameters can then be referenced as variables in the SKILL code that is generated.

Arguments

p_port

Port to which the output code is generated.

Value Returned

t | nil

Return value is not relevant.

Example

```
procedure( pcUserAdjustParameters( port )
; stretch implemented by 2 stretch control lines \Rightarrow
divide parameter value by 2
fprintf(port "ch_width = ch_width/2\n")
)
```

Generates a call to a SKILL procedure to divide the ch_width parameter value by 2.

Graphical Parameterized Cell Functions

pcUserGenerateArray

Description

A user-defined procedure called by the compiler before it processes any simple arrays (mosaics) in a master Pcell. The procedure is normally used to suppress array generation or to modify arrays.

Arguments

d_mosaic	Database ID of array.
t_masterTag	Name for the master Pcell of the array that can be used in the generated SKILL code.
p_port	Port to which the output code is generated.

Value Returned

t	Compiler does not generate the code to reproduce the array in the submaster Pcell.
nil	Compiler generates the code to reproduce the array in the submaster Pcell as if the procedure were not called.

Example

```
procedure( pcUserGenerateArray( mosaic master port )
if( mosaic~>name == \"userSpecial\" t nil)
)
```

Suppresses code generation for the array named userSpecial.

Graphical Parameterized Cell Functions

pcUserGenerateInstance

```
pcUserGenerateInstance(
    d_inst
    t_masterTag
    p_port
)
=> t / nil
```

Description

A user-defined procedure called by the compiler before it processes any instances in a master Pcell. The procedure is normally used to suppress instance generation or to modify instances.

Arguments

d_inst	Database ID of instance.
t_masterTag	Name for the master Pcell that can be used in the generated SKILL code.
p_port	Port to which the output code is generated.

Value Returned

t	Compiler does not generate the code to reproduce the instance in the submaster Pcell.
nil	Compiler generates the code to reproduce the instance in the submaster Pcell as if the procedure were not called.

Example

```
procedure( pcUserGenerateInstance( inst master port )
  if( inst~>name == \"userSpecial\" t nil)
)
```

Suppresses code generation for an instance named userSpecial.

Graphical Parameterized Cell Functions

pcUserGenerateInstancesOfMaster

Description

A user-defined procedure called by the compiler for every master Pcell in a master Pcell. The compiler calls the procedure before it generates code for instances (but not arrays) for the master. The procedure is normally used to generate code to switch masters.

Arguments

d_masterCV	Database ID of master Pcell.
l_instanceList	List of database IDs for all instances of $d_{masterCV}$ in the master Pcell.
t_tag	Name of the master that can be used in SKILL code for placing instances of the master.
p_port	Port to which the output code is generated.

Value Returned

t	Compiler does not generate the code to reproduce the instances of this master Pcell in the submaster Pcell.
nil	Compiler generates code to reproduce the instances of this master Pcell in the submaster Pcell as if the procedure were not called.

Example

```
procedure( pcUserGenerateInstancesOfMaster(master instances tag port )
if( master~>cellName == \"userSpecialNand\" then
; switch master to generic one
fprintf(port %s = dbOpenCellViewByType(pcLib \"nand\" \"%s\")\n"
tag master~>viewName)
)
; always want code for instances to be generated by
```

Graphical Parameterized Cell Functions

```
; compiler
nil
)
```

Replaces instances of userSpecialNand cell with instances of nand cell.

Graphical Parameterized Cell Functions

pcUserGenerateLPP

```
pcUserGenerateLPP(
    d_lpp
    p_port
)
=> t / nil
```

Description

A user-defined procedure called by the compiler before it processes shapes belonging to layer-purpose pairs in the master Pcell. The procedure is normally used to suppress shapeset generation.

Arguments

d_1pp	Database ID of layer-purpose pair.
p_port	Port to which the output code is generated.

Value Returned

t	Compiler does not generate the code to reproduce any shapes belonging to the layer-purpose pair in the submaster Pcell.
nil	Compiler generates the code to reproduce shapes belonging to the layer-purpose pair in the submaster Pcell as if the procedure were not called.

Example

```
procedure( pcUserGenerateLPP( lpp port )
if( lpp~>layerName == \"userSpecial\" t nil)
)
```

Suppresses code generation for all shapes on a layer called userSpecial.

Graphical Parameterized Cell Functions

pcUserGeneratePin

```
pcUserGeneratePin(
    d_pin
    p_port
)
=> t / nil
```

Description

A user-defined procedure called by the compiler before it processes pins on any terminals in the master Pcell. The procedure is normally used to suppress pin generation or to modify pins.

Arguments

d_pin	Database ID of pin on Pcell.
p_port	Port to which output code is generated.

Value Returned

t	Compiler does not generate code to reproduce the pin in the submaster Pcell.
nil	Compiler generates code to reproduce the pin in the submaster Pcell as if the procedure were not called.

Example

```
procedure( pcUserGeneratePin( pin port )
     if( pin~>term~>name == \"userSpecial\" t nil )
)
```

Suppresses code generation for the pin if the terminal is called userSpecial.

Graphical Parameterized Cell Functions

pcUserGenerateProperty

```
pcUserGenerateProperty(
    d_object
    d_prop
    t_tag
    p_port
)
=> t / nil
```

Description

A user-defined procedure called by the compiler before it processes properties on any objects. The procedure is normally used to suppress property generation in the master Pcell.

Arguments

d_object	The database ID of the object to which the property is attached.
d_prop	The database ID of the property.
t_tag	Name for the object that can be used in any SKILL code generated.
p_port	Port to which the output code is generated.

Value Returned

t	Compiler does not generate code to reproduce the property in the submaster Pcell.
nil	Compiler generates code to reproduce the property in the submaster Pcell as if the procedure were not called.

Example

```
procedure( pcUserGenerateProperty( obj prop tag port )
if( prop~>name == \"userSpecial\" t nil)
)
```

Suppresses code generation for a property called userSpecial.

Graphical Parameterized Cell Functions

pcUserGenerateShape

```
pcUserGenerateShape(
    d_shape
    p_port
)
=> t / nil
```

Description

A user-defined procedure called by the compiler before it processes any shapes in the master Pcell. The procedure is normally used to *suppress* shape generation or to modify shapes.

Arguments

d_shape	Database ID of shape.
p_port	Port to which the output code is generated.

Value Returned

t	Compiler does not generate the code to reproduce the shape.
nil	Compiler generates the code to reproduce the shape as if the procedure were not called.

Example

```
procedure( pcUserGenerateShape( shape port )
if( cond = shape~>userSpecialProp then
; generate conditional code
fprintf(port "if( %L then\n" cond)
)
; always generate code for this shape
nil
)
```

Looks for the property userSpecialProp for the shape. If the property exists, the compiler generates SKILL code to test the results of evaluating the property value when an instance is placed. The code to reproduce the shape is generated by the compiler within a conditional block, so the shape is reproduced in the submaster Pcell only if the condition evaluates to a nil value.

You need to close the condition properly (generating closing parentheses) in the call to pcUserPostProcessObject.

Graphical Parameterized Cell Functions

pcUserGenerateTerminal

```
pcUserGenerateTerminal(
    d_terminal
    p_port
)
    => t / nil
```

Description

A user-defined procedure called by the compiler before it processes any terminals in the master Pcell. The procedure is normally used to suppress terminal generation or to modify terminals.

Arguments

d_terminal	The database ID of the terminal on the Pcell.
p_port	Port to which the output code is generated.

Value Returned

t	Compiler does not generate code to reproduce the terminal in the submaster Pcell.
nil	Compiler generates code to reproduce the terminal in the submaster Pcell as if the procedure were not called.

Example

```
procedure( pcUserGenerateTerminal(term port )
    if( term~>name == \"userSpecial\" t nil)
)
```

Suppresses code generation for a terminal called userSpecial.

Graphical Parameterized Cell Functions

pcUserInitRepeat

Description

A user-defined procedure called by the compiler before it processes any repetitions. The procedure is normally used to generate code to set the values of variables for repetition parameters.

Arguments

l_stepX	SKILL list for the expression governing the X-stepping distance of the repetition.
l_stepY	SKILL list for the expression governing the Y-stepping distance of the repetition.
l_repeatX	SKILL list for the expression governing the number of repetitions in the X direction.
l_repeatY	SKILL list for the expression governing the number of repetitions in the Y direction.
p_port	Port to which the output code is generated.

Value Returned

```
t | nil Return value is not relevant.
```

Example

```
procedure( pcUserInitRepeat( sX sY rX rY port )
    ; keep record of step distance and repetitions
    fprintf(port "pcUserStep = %L\n" sY)
    fprintf(port "pcUserRepeat = %L\n" rY)
)
```

Generates a call to SKILL procedures to record repetition parameters.

Graphical Parameterized Cell Functions

pcUserPostProcessCellView

Description

A user-defined procedure called by the compiler after it processes any object in a Pcell. The procedure is normally used to generate code to process a list of objects that was built during compilation.

Arguments

d_cv	The database ID of the master Pcell being processed.
t_tag	Name that can be used to refer to the Pcell in the SKILL code output by the procedure.
p_port	Port to which the output code is generated.

Value Returned

```
t | nil Return value is not relevant.
```

Example

```
procedure( pcUserPostProcessCellView( cv tag port )
    ; adjust contacts up by half "slop" amount
fprintf(port "foreach( contact PCUserContacts \n")
fprintf(port " dbMoveShape(contact pcCellView
list( 0:(width - PCUserRepeat*PCUserStep) / 2
\"R0\"))\n")
fprintf(port ")\n")
)
```

Generates a call to a SKILL procedure to move the list of database objects.

Graphical Parameterized Cell Functions

pcUserPostProcessObject

Description

A user-defined procedure called by the compiler after it processes any object (instance, shape, terminal, and so forth) in a master Pcell. The procedure is normally used to generate code to modify a generated object.

Arguments

d_obj	Database ID of object.
t_tag	Name for the object in the generated SKILL code.
p_port	Port to which the output code is generated.

Value Returned

```
t | nil Return value is not relevant.
```

Example

```
procedure( pcUserPostProcessObject(obj tag port )
if( obj~>objType == "inst"
    && obj~>userSpecialProp then
        ; generate code to change its magnification
fprintf(port "%s~>mag = pcUserMagScale\n" tag)
)
)
```

Checks to see if the object is an instance and has a property userSpecialProp. If so, code is generated to change the magnification of the instance to pcUserMagScale (which was defined using pcUserPreProcessCellView).

Graphical Parameterized Cell Functions

pcUserPreProcessCellView

Description

A user-defined procedure called by the compiler before it processes any objects in a Pcell. The procedure is normally used to generate code to initialize variables before the compiler processes individual objects.

Arguments

d_cv	The database ID of the master Pcell being processed.
t_tag	Name that can be used to refer to the Pcell in the SKILL code output by the procedure.
p_port	Port to which the output code is generated.

Value Returned

```
t / nil Return value is not relevant.
```

Example

```
procedure(pcUserPreProcessCellView( cv tag port )
    ; Initialize list to store the contacts
fprintf(port "PCUserContacts = nil\n")
)
```

Generates a call to a SKILL procedure to initialize a list of database objects.

Graphical Parameterized Cell Functions

pcUserSetTermNetName

```
pcUserSetTermNetName(
    d_pinFig
    p_port
)
    => t / nil
```

Description

A user-defined procedure called by the compiler before it processes any pins on any terminals that are part of a repetition group in the master Pcell. The procedure is normally used to customize the connectivity of replicated pins. SKILL code generated by this procedure should assign the net name to the SKILL variable pcTermNetName. This is the net name used in the code generated by the compiler to create terminals in the submaster Pcell. The SKILL variables pcIndexX and pcIndexY are available for incorporation into pcTermNetName if you need to make different nets for each different repeated pin.

Arguments

d_pinFig	The database ID of the figure associated with the pin.
p_port	Port to which the output code is generated.

Value Returned

t	Compiler does not generate code to define the terminal net name in the submaster Pcell.
nil	Compiler generates code to name the terminal net in the submaster Pcell as if the procedure were not called.

Example

```
procedure( pcUserSetTermNetName( fig port )
if( fig~>pin~>term~>name == \"userSpecial\" then
fprintf( port "pcTermNetName = get_string( concat(
\"userSpecial\" pcIndexX ) ) \n" )

t
else; let compiler generate net name
nil
)
)
```

Generates code to define a net name for the terminal.

Graphical Parameterized Cell Functions

Parameterized Cell SKILL Cross-Reference Table

This table summarizes the procedural and interactive pc SKILL functions associated with Parameterized Cell Compiler (Pcell) menu commands. A complete listing of the syntax, descriptions, and examples for the Pcell SKILL functions follows this table.

Interactive SKILL Function	Procedural SKILL Function	Menu Command
<u>pcHIDefineParamCell</u>	<u>pcDefinePCell</u>	Compile – To Pcell
<u>pcHICompileToSkill</u>	<u>pcSkillGen</u>	Compile – To Skill File
pcHIDefineCondition	pcDefineCondition pcGetConditions pcGetParameters	Conditional Inclusion – Define
<u>pcHIDeleteCondition</u>	<u>pcDeleteCondition</u>	Conditional Inclusion –
	<u>pcDefineCondition</u>	Delete
	<u>pcGetConditions</u>	
pcHIModifyCondition	No procedural function	Conditional Inclusion – Modify
pcHIDisplayCondition	No procedural function	Conditional Inclusion – Show
pcHIDefineInheritedParameter	<u>pcDefineInheritParam</u>	Inherited Parameters – Define/Modify
	pcGetInheritParamDefn	
	<u>pcGetParameters</u>	
pcHIDisplayInheritedParameter	No procedural SKILL function	Inherited Parameters – Show
<u>pcHIDefineLabel</u>	<u>pcDefineParamLabel</u>	Parameterized Label –
	<u>pcGetParameters</u>	Define
	pcGetParamLabelDefn	
	pcGetParamLabels	
<u>pcHIModifyLabel</u>	No procedural function	Parameterized Label – Modify

Interactive SKILL Function	Procedural SKILL Function	Menu Command
pcHIDefineLayer	pcDefineParamLayer	Parameterized Layer –
	<u>pcGetParameters</u>	Define
	pcGetParamLayers	
	pcGetParamLayerDefn	
pcHIDeleteLayer	<u>pcDeleteParamLayer</u>	Parameterized Layer –
	<u>pcDefineParamLayer</u>	Delete
<u>pcHIModifyLayer</u>	No procedural function	Parameterized Layer – Modify
pcHIDisplayLayer	No procedural function	Parameterized Layer – Show
pcHIDefineProp	<u>pcDefineParamProp</u>	Parameterized
	<u>pcGetParameters</u>	Property – Define/Modify
	<u>pcGetParamProps</u>	
<u>pcHIDeleteProp</u>	<u>pcDeleteParamProp</u>	Parameterized Property – Delete
<u>pcHIDisplayProp</u>	No procedural function	Parameterized Property – Show
pcHIDefineParameterizedShape	<u>pcDefineParamPolygon</u>	Parameterized Shapes
	pcDefineParamPath	– Define/Modify
	<u>pcDefineParamRect</u>	
	<u>pcGetParameters</u>	
	pcGetParamShapeDefn	
	<u>pcGetParamShapes</u>	
pcHIDeleteParameterizedShape	<u>pcDeleteParamShape</u>	Parameterized Shapes – Delete
pcHIDisplayParameterizedShape	No procedural function	Parameterized Shapes – Show
pcHIEditParameters	<u>pcModifyParam</u>	Parameters – Edit Parameters

Interactive SKILL Function	Procedural SKILL Function	Menu Command
pcHIModifyParams	<u>pcModifyParam</u>	Parameters – Edit Parameters
<u>pcHIDisplayParams</u>	No procedural function	Parameters – Show
<u>pcHISummarizeParams</u>	No procedural function	Parameters – Summarize
pcHIDefineParamRefPointObject	$\underline{pcDefineParamRefPointObject}$	
	<u>pcGetParameters</u>	Define by Parameter
	<u>pcGetRefPointDefn</u>	
	<u>pcGetRefPoints</u>	
<u>pcHIDefinePathRefPointObject</u>	<u>pcDefinePathRefPointObject</u>	Reference Point -
	<u>pcGetParameters</u>	Define by Path Endpoint
	<u>pcGetRefPointDefn</u>	,
	<u>pcGetRefPoints</u>	
<u>pcHIDeleteRefPointObject</u>	<u>pcDeleteRefPoint</u>	Reference Point –
	<u>pcDefinePathRefPointObject</u>	Delete
	$\underline{pcDefineParamRefPointObject}$	
pcHIModifyRefPointObject	No procedural function	Reference Point – Modify
pcHIDisplayRefPointObject	No procedural function	Reference Point – Show
<u>pcHIDeleteRepeat</u>	pcDeleteRepeat	Repetition – Delete
	pcDefineRepeat	
	<u>pcGetRepeats</u>	
pcHIModifyRepeat	No procedural function	Repetition – Modify

Interactive SKILL Function	Procedural SKILL Function	Menu Command
pcHIDefineRepeat	pcDefineRepeat	Repetition
	<u>pcGetParameters</u>	– Repeat in X
	pcGetRepeatDefn	– Repeat in Y
	pcGetRepeats	– Repeat in X and Y
<u>pcHIDisplayRepeat</u>	No procedural function	Repetition – Show
<u>pcHIDefineSteppedObject</u>	pcDefineSteppedObject	Repetition Along
	<u>pcGetParameters</u>	Shape – Define
	<u>pcGetSteppedObjectDefn</u>	
	pcGetSteppedObjects	
<u>pcHIDeleteSteppedObject</u>	pcDeleteSteppedObject	Repetition Along
	<u>pcDefineSteppedObject</u>	Shape – Delete
<u>pcHIModifySteppedObject</u>	No procedural function	Repetition Along Shape – Modify
pcHIDisplaySteppedObject	No procedural function	Repetition Along Shape – Show
pcHIModifyStretchLine	pcRedefineStretchLine	Stretch – Modify
pcHIQualifyStretchLine	pcRestrictStretchToObjects	Stretch – Qualify
pcHIRedefineStretchLine	No procedural function	Stretch – Redefine
	pcGetStretchSummary	Parameters – Summarize
<u>pcHIDefineStretch</u>	<u>pcDefineStretchLine</u>	Stretch
	<u>pcGetParameters</u>	– Stretch in X
	<u>pcGetStretchDefn</u>	– Stretch in Y
	<u>pcGetStretches</u>	
	pcRedefineStretchLine	
	pcGetOffsetPath	
	pcGetOffsetPolygon	

Interactive SKILL Function	Procedural SKILL Function	Menu Command
—	_	Connectivity – Nets –
		Add Shape Connectivity –
<u>auHiUltraPCell</u>	No procedural function	Nets – Remove Shape Make Ultra Pcell

3

Express Pcells Data Management Functions

This chapter describes SKILL functions for Express Pcells data management. These functions require the VLS L license in IC6.1.8 and the VLS XL license in ICADVM20.1 (for both reading and writing the cache). Additionally, these SKILL functions operate only when the Express Pcell feature is enabled by setting the CDS_ENABLE_EXP_PCELL environment variable to true.

Express Pcells Data Management Functions

dbClearPcellCache

```
dbClearPcellCache(
    [ t_libName ]
    [ t_cellName ]
    [ t_viewName ]
    )
    => t / nil
```

Description

Deletes all the submasters of the cellview specified by $t_libName$, $t_cellName$, and $t_viewName$ from the Express Pcell cache on disk at the location specified by the CDS_EXP_PCELL_DIR environment variable. If no argument is specified then it deletes the complete cache.

Arguments

t_libName	Specifies the name of the library
t_cellName	Specifies the name of the cell
t_viewName	Specifies the name of the view

Express Pcells Data Management Functions

dbSavePcellCache

```
dbSavePcellCache(
    )
    => t / nil
```

Description

Saves the submasters that exist in virtual memory of the current Virtuoso session to the Express Pcell cache on disk at the location specified by the CDS_EXP_PCELL_DIR environment variable.

If there is a mismatch in the timestamps of the supermaster, the existing submasters in the cache are deleted, and only the new submasters generated in virtual memory are saved to the Express Pcell cache on disk.

Express Pcells Data Management Functions

dbSavePcellCacheForCV

```
dbSavePcellCacheForCV(
    t_libName
    t_cellName
    t_viewName
    [ n_openLevels ]
    )
    => t / nil
```

Description

Opens the cellview specified by $t_libName$, $t_cellName$, and $t_viewName$ and saves all the existing submasters generated or updated in virtual memory to the Express Pcell cache (including any other pre-existing submasters in virtual memory) on disk at the location specified by the CDS_EXP_PCELL_DIR environment variable.

If there is a mismatch in the timestamps of the supermaster, the existing submasters in the cache are deleted, and only the new submasters generated in virtual memory are saved to the Express Pcell cache on disk.

Arguments

t_libName	Specifies the name of the library
t_cellName	Specifies the name of the cell
t_viewName	Specifies the name of the view
n_openLevels	Is an optional argument. The default value of this argument is 32. Therefore, the complete cellview hierarchy opens by default.

Express Pcells Data Management Functions

dbSavePcellCacheForCVOnly

```
dbSavePcellCacheForCVOnly(
    t_libName
    t_cellName
    t_viewName
    [ n_depth ]
)
    => t / nil
```

Description

Opens the cellview specified by $t_1ibName$, $t_cellName$, and $t_viewName$ and saves all the Pcell submasters specified in the given cell in the Express Pcell Cache.

Arguments

t_libName	Name of the library.
t_cellName	Name of the cell.
t_viewName	Name of the view.
n_depth	An optional argument. It specifies the level in the hierarchy of the given lib/cell/view till where the instantiated Pcell submaster should be saved. If not specified, then the command saves all the submasters including the leaf level.

Value Returned

t	Successfully saved all the submasters to the cache.
nil	Unable to save the submasters to the cache.

Example

```
dbSavePcellCacheForCVOnly( lib cell view 3 )
```

Saves all the Pcell submasters in the lib/cell/view hierarchy till the depth of 3.

Express Pcells Data Management Functions

dbUpdatePcellCache

```
dbUpdatePcellCache(
    [ t_libName ]
    [ t_cellName ]
    [ t_viewName ]
    [ g_checkTimeStamp ]
    )
    => t / nil
```

Description

Updates and saves the submasters that exist in cache by re-evaluating the Pcells. If Library, cell, and view is specified, it updates the submasters only for the specified supermaster.

Note: It does not consider any existing submaster in virtual memory.



If the number or type of Pcell parameters get changed, all the submasters corresponding to that Pcell supermaster are deleted from the cache.

Arguments

t_libName	Specifies the name of the library.
t_cellName	Specifies the name of the cell.
t_viewName	Specifies the name of the view.
g_checkTimeStamp	Whether to check the time stamp for updating the cache. If set to true, then it will update only for those super masters whose time stamp have been changed. Else, it will update for all the supermasters.
	Default: False.

Express Pcells Data Management Functions

xpcEnableExpressPcell

```
xpcEnableExpressPcell(
    g_enable
)
```

Description

Enables or disables the Express Pcell cache.

Argument

g_enable

When t, the express Pcell cache is enabled irrespective of the previous cache state.

When $\[\mathrm{nil}\]$, the express Pcell cache is disabled irrespective of the previous cache state.

Express Pcells Data Management Functions

xpcDumpCache

```
xpcDumpCache(
    g_detailReport
    [ filename ]
)
```

Description

This SKILL API dumps the Express Pcell cache information on CIW and the file, which is specified as an argument.

Note: The value that you specify for this argument should be enclosed in quotation marks.

Arguments

g_detailReport Whens et to t, a <u>Detailed Report</u> is generated.

When set to nil, the **Short Report** is generated.

filename This is an optional argument. If the file name is specified and is

in the write mode then the cache information is dumped on

both CIW and the file specified. Otherwise, the cache

information is dumped only on CIW.

Note: Ensure that environment variables, CDS_ENABLE_EXP_PCELL and CDS_EXP_PCELL_DIR are set appropriately.

Short Report

It lists all supermasters represented in cache, followed by the number of submasters (stored in the cache) for each supermaster as shown in the following examples:

Example 1

```
xpcDumpCache(
nil "file1.dump"
)
```

In this example the cache information is dumped in both CIW and the file1.dump file as shown below.

Express Pcells Data Management Functions

PDKLIB/p/layout	1
PDKLIB/n/layout	1

Example 2

```
xpcDumpCache( nil )
```

In this example the cache information is dumped only in CIW as shown below.

```
Express PCell Cache Dump Report:
------
SuperMaster(lib/cell/view) Number of submasters
testLib/customCell/layout 5
```

Detailed Report

In addition to the information provided in the short report, it lists each submaster in the cache with the list of parameter names and values as shown in the example below:

Example

```
xpcDumpCache(
t "file2.dump"
)
```

In this example, the cache information is dumped in both CIW and the file2.dump file as shown below.

```
Express PCell Cache Dump Report:
_____
                                                   Number of submasters
SuperMaster(lib/cell/view)
PDKLIB/p/layout
                                                   1
Parameter values (<Parameter Name> = <Parameter Value>) are:-
cntOffsetR=0.000000
                    drainStrap=none drawDNW=0 drawGuard=1
                                                                 drawWell=1
rmRightSD=0
                    sa=130n
                                   sb=130n
                                                 sc=400n
                                                                 sd=0.14u
sourceStrap=none
                    strap=0
                                   strapGate=none strapGateTop=1
                                                                 swapSD=0
```

Express Pcells Data Management Functions

topStrapExt=0.0 wf=1u

PDKLIB/n/layout 1

Parameter values (<Parameter Name> = <Parameter Value>) are:-

drawGuard=1 drawWell=1 dualStrapGate=0 enableMfactor=0 extendLeftGate=0

sc=400n sd=0.14u strap=0 strapGate=none strapGateTop=1