boot parameters for debugging kernel ignore_loglevel initcall debug for example: # mmc dev 1;ext2load mmc 1:2 0x400000 /boot/ulmage;ext2load mmc 1:2 0xf00000 /boot/mv6220toc.dtb;setenv bootargs \$bootargs root=/dev/mmcblk1p2 uio_pdrv_genirq.of_id=generic-uio rootwait ignore loglevel initcall debug; bootm 0x400000 - 0xf00000 尤其是initcall_debug,对调试built-in driver的初始化很有用 initcall blk_ioc_init+0x0/0x40 returned 0 after 0 usecs calling blk_softirq_init+0x0/0x80 @ 1 initcall blk softirg init+0x0/0x80 returned 0 after 0 usecs calling blk iopoll setup+0x0/0x80 @ 1 initcall blk iopoll setup+0x0/0x80 returned 0 after 0 usecs calling blk mq init+0x0/0x1c @ 1 initcall blk_mq_init+0x0/0x1c returned 0 after 0 usecs calling genhd_device_init+0x0/0x80 @ 1 initcall genhd device init+0x0/0x80 returned 0 after 0 usecs

calling gpiolib_debugfs_init+0x0/0x38 @ 1

calling pwm debugfs init+0x0/0x38 @ 1

initcall gpiolib_debugfs_init+0x0/0x38 returned 0 after 0 usecs

initcall pwm_debugfs_init+0x0/0x38 returned 0 after 0 usecs

calling pwm_sysfs_init+0x0/0x14 @ 1

initcall pwm_sysfs_init+0x0/0x14 returned 0 after 0 usecs