

ATS Mini WSJT-X Proxy 1

User guide. M Benton.

This program lets WSJT-X or MSHV control an ATS Mini over Hamlib NET rigctl. The radio stays on USB, and the computer listens on 127.0.0.1 port 4532. One running copy can be used by either program.

32-bit and 64-bit versions

Two Windows executables are published. They behave the same. Pick the one that matches Windows, not the radio.

- 64-bit Windows 11 or 10: atsmine-bridge-1.exe
- 32-bit Windows: atsmine-bridge-1-win32.exe
- No installer is required. Run the exe directly.
- Do not run both at once. They both listen on port 4532.

Radio firmware

Use official ATS Mini firmware 2.34 or newer. Version 2.34 added Settings, USB Port, Ad hoc, which this program needs. The current release is 2.42, dated 30 September 2026.

- Releases: <https://github.com/esp32-si4732/ats-mini/releases>
- Flash instructions: <https://esp32-si4732.github.io/ats-mini/flash.html>
- Manual: <https://esp32-si4732.github.io/ats-mini/manual.html>
- On 2.39 or newer, Settings, Update FW can install a later build over Wi-Fi.

After flashing, set USB Port to Ad hoc. Leave it on that setting. The computer program cannot see the tuning knob if USB Port is Off.

Before you start

- Connect the ATS Mini by USB. On the radio, set USB Port to Ad hoc.
- The window finds a USB serial port, opens it at 115200, and listens for Hamlib.

WSJT-X

- Settings, Radio. Rig: Hamlib NET rigctl.
- Network Server: 127.0.0.1:4532
- PTT Method: VOX, or None if you do not transmit.
- Mode: USB. Split: None, unless you use Fox/Hound.
- Press Test CAT. The status list should show the frequency.

MSHV

- Interface Control, Network. Host 127.0.0.1, port 4532, Hamlib NET rigctl.
- Connect once. A later Settings, Restart in this program reopens the radio only.
- The Hamlib socket stays open, so MSHV does not have to connect again.
- Changing the listen address or TCP port does close Hamlib. Connect MSHV again after that.

What the window does

There is no Start or Stop button. The program starts when the window opens and retries every few seconds if the radio is not plugged in yet. The status list is newest at the bottom, with the time on each line. It scrolls so

the latest line stays visible.

On connect it steps the radio to band ALL and mode USB. Turning the radio knob updates the status list and the frequency reported to WSJT-X or MSHV.

Settings menu

Item	Effect
COM port	Auto-detect, or a chosen port. Saved at once, then the radio is reopened.
Listen address / TCP port	Default 127.0.0.1 and 4532. Changing either closes Hamlib. Reconnect WSJT-X or MSHV.
Use system theme	Follows Windows light or dark, including a later Windows theme change.
Light mode / Dark mode	Forces that appearance. Saved at once.
Restart	Reopens the COM port only. The Hamlib connection is kept.

Radio power-on

The radio does not have a separate boot profile. Set band ALL and USB, then leave it idle until the save icon finishes, about 10 seconds. Those choices are written to flash and used at the next power-on. If it still returns to 11 m and AM, set the mode and band again and wait for the save.

Saved computer settings

COM port, listen address, TCP port and theme are stored in %APPDATA%\ATSMiniBridge\settings.ini as soon as you change them.

If the status says no radio log

- On the radio, set USB Port to Ad hoc, not Off or Debug.
- Confirm the firmware is 2.34 or newer.
- Unplug and plug the USB lead, then use Settings, Restart.
- Confirm the port in Settings, COM port, if auto-detect picked another device.

ATS Mini WSJT-X Proxy 1. 64-bit and 32-bit builds. M Benton.