

common problem

Program the default system

- Refer to the operation demonstration video tutorial

<https://player.bilibili.com/player.html?aid=677495111&bvid=BV1Rm4y1X7GZ&cid=462849541&page=1>

Preparation

The programming system is operated under the uboot command line. Before operation, you need to confirm the following questions:

1. The development board can be booted into the uboot command line, if not, please click the page to [compile](#) and burn the Boot chapter to update the program.
2. Since the Dongshan Pi One development board does not have a network card interface, the programming is done through an SD card.
 - a. So you need to prepare in advance a TF card with a partition format of `FAT32` `32GB` and below, as well `读卡器`.
3. The default system for programming is to program all partitions, so it will erase and rewrite files to all partitions, please copy important files in advance.

Flash update

- Download the default system image
- Click the download link: <https://cowtransfer.com/s/c82c42aabbf041> After downloading, you will get `images.zip` a , which needs to be decompressed with a compression tool. The decompressed file list is as follows.

```
appconfigs.ubifs
auto_update.txt
auto_update_bin.txt
boot/
cis.bin
customer.ubifs
ipl_cust_s.bin
ipl_s.bin
kernel
logo
miservice.ubifs
rootfs.ubifs
scripts/
scripts_bin/
uboot_s.bin
```

- Copy to tf card First, connect the prepared TF card with FAT32 partition format to the computer, and copy all the above decompressed files to the tf card. After the copy is completed, you can eject the TF card from the computer, insert the card into the TF card socket of the Dongshan Pi development board, and press it in completely (note that the TF card cannot exceed 32G).
- Enter the uboot command line to execute the programming command. At this point, make sure that the development board can interact through the serial port tool, press the reset button, and then keep pressing the `enter` enter Release, you can enter Inside the uboot command line interface. After entering the uboot command line, you can directly enter `dstar` the command , and the update will be performed automatically. After the update is

completed, the system can be automatically restarted.

[illegible]

Update the complete log output of the system, for reference only:

Other FAQs

No serial output information

- Check whether the connection is successful and whether the serial port driver is installed on the computer
- Check whether the serial port baud rate is set correctly
- Check if the serial port is blocked by other tools

Unable to program system

- Check if the development board enters uboot mode
- Is it possible to load the SD card image to the system?
- Check if it can be programmed

nothing on the screen

- Check that the connection is stable.
- Check to see if the screen backlight is on.
- Check that an operation screen is displayed.