

Compile and burn the Kernel

Brief description: The kernel used by the Dongshan Pi No. 1 development board is based on the Linux Kernel mainline version 4.9 for adaptation support, and supports some proprietary processing units and other driver modules such as its own controllers.

Compile Kernel

First enter the kernel root directory. Before compiling, you still need to confirm whether the cross-compilation toolchain and other environments have been successfully configured. If you are not sure, you can refer to [the](#) section Configuring the Cross-compilation Toolchain.

```
make infinity2m_spinand_ssc011a_s01a_minigui_defconfig;
```

Execute make clean; make -j8 (according to the server configuration, it can support multi-threaded compilation) to generate an image, if you need to package it, you need to Release to the corresponding directory of the project.

Nand Flash

```
arch/arm/boot/uImage.xz
```

If you need to package the compiled image into a complete image, you need to copy it to the project directory:

```
project\release\nvr\i2m\011A\glibc\8.2.1\bin\kernel\spinand
```

Check the build environment

Specify the configuration file

build system

Program Kernel

programming in uboot

```
fatload mmc 0:1 0x21000000 uImage.xz  
nand erase.part KERNEL
```

```
nand write.e 0x21000000 KERNEL ${filesize}  
nand erase.part RECOVERY  
nand write.e 0x21000000 RECOVERY ${filesize}
```