

Mstar Tools

Programming tool support

- I2C chip programmer <https://github.com/harbaum/I2C-Tiny-USB/tree/master/digispark>
- Burning tool source code warehouse address
<https://github.com/fifteenhex/SNANDer/tree/mstar>

Install SNANDer

- Download and get SNANDer: <https://cowtransfer.com/s/a6f7006b4fd64f> After the download is successful, copy it directly to the home directory of the Ubuntu system. Then refer to the following example and copy it to the system directory

```
chmod +x SNANDer
sudo cp SNANDer /usr/bin/
sudo apt install udev libusb
```

Instructions for use

```
SNANDer - Serial Nor/nAND/Eeprom programmeR v.1.7.2 by McMCC <mcmcc@mail.ru>

Usage:
-h                display this message
-p                programmer {ch341a|mstarddc} (default ch341a)
-c                programmer connection string
-d                disable internal ECC(use read and write page size + 00B size)
-I                ECC ignore errors(for read test only)
-L                print list support chips
-i                read the chip ID info
-E                select I2C EEPROM
{24c01|24c02|24c04|24c08|24c16|24c32|24c64|24c128|24c256|24c512|24c1024}
                  select Microwire EEPROM
{93c06|93c16|93c46|93c56|93c66|93c76|93c86|93c96} (need SPI-to-MW adapter)
-8                set organization 8-bit for Microwire EEPROM(default 16-bit)
and set jumper on SPI-to-MW adapter
-f <addr len>    set manual address size in bits for Microwire EEPROM(default
auto)
-e                erase chip(full or use with -a [-l])
-l <bytes>        manually set length
-a <address>      manually set address
-w <filename>     write chip with data from filename
-r <filename>     read chip and save data to filename
-v                verify after write on chip
```

Program the Linux board u-boot

*Refer to this page <http://linux-chenxing.org/infinity2/dongshanpione/>

Write the original boot example

Note: The `-l` parameter specifies the length (size) of the programming file. If you modify the `u-boot_spinand.xz.img.bin` file, please confirm whether the size is within this area.

```
sudo SNANDer -p mstarddc -c /dev/i2c-0:49 -e

sudo SNANDer -p mstarddc -c /dev/i2c-0:49 -w GCIS.bin

sudo SNANDer -p mstarddc -c /dev/i2c-0:49 -a 0x140000 -l 0x6000 -w IPL.bin

sudo SNANDer -p mstarddc -c /dev/i2c-0:49 -a 0x200000 -l 0x5800 -w
IPL_CUST.bin

sudo SNANDer -p mstarddc -c /dev/i2c-0:49 -a 0x2C0000 -l 0x3B800 -w u-
boot_spinand.xz.img.bin
```