

Uboot Q&A

 **Q1: When using SD card to upgrade, CONFIG_MS_SDMMC has been enabled, enter sdstar under uboot, and prompt unknow command 'sdstar' - try help?**

uboot does not open the sdmmc configuration by default. After opening, recompile and burn, and check the uboot compilation time on the board to confirm that the update is successful.

 **Q2: What method should I use if I want to re-burn uboot?**

If you can still enter uboot, you can use tftp, and use the separate burning command under uboot `estar scripts/[[uboot.es`. This command can be found in the auto_update.txt file of the image. If the chip is empty or cannot enter uboot, it can be burned through the ISP tool. Please refer to the development environment of Sigdoc.

 **Q3: SSD261Q default boot parameters are nand, no nor?**

SigmaStar # printenv baudrate=115200 bootdelay=3 stderr=serial stdin=serial stdout=serial

Environment size: 80/4092 bytes SigmaStar #

In the above case, please refer to the development environment construction document under sigdoc, and use the corresponding config when compiling alkaid. In the above case, please use the "dispcam_m6_nor.glibc-9.1.0-squashfs.019a.256.bga1.demo_defconfig" config .