

Miyoo283 Firmware Release 20220408 features description

1. LCD driver updated, frame rate 59.8Hz.
2. Audio Server for pop-noise fixes, with switch 'Settings - Fixes - AudioFix'.
3. FrameBuffer 'Autoflip when Pan' support.
4. Customized theme and switching in Settings.
5. Game list snapshot preview.
6. Power off function in settings
7. Loading animation in "ra32.ss" for big game (kof2003/mslug3)
8. Bug fix: Main UI graphic tearing.
9. Bug fix: Game list extension name filter not work. (config.json "extlist")

Miyoo283 Emulators update

1. [PSX] Pcsx-rearmed : add audio server support, add chd support, add internal audio 44.1k resampler support.
2. [MD] Picodrive: add audio server support
3. [SMS] SmsPlus: change audio driver to OSS
4. [Retroarch] retroarch original: update version 1.9.6-> 1.10.2, add audio server support
ra32.ss lite version: add loading animation, add audio server support

Miyoo283 Audio server description:

audioserver is running for fix MI_AO **open/close** pop-noise.

It will handle the **open/close/write/ioctl** operation for '/dev/dsp' using internal socket.

MainUI will add [LD_PRELOAD=/customer/lib/libpadsp.so](#) for all app to grab it before libc.

All PCM data will convert and actually write in **audioserver** process.

This server will block all the sound API in the machine include MI_AO / OSS / ALSA.

If you want to keep conventional compatibility for old 3rd-party MIYOO Mini audio application , you can turn off this server in "Settings - Fixes - AudioFix".

You can also make specify config.json to close audio server when launch.

The json key is "[noaudiofix](#)"

Example:

```
{
  "label": "SoundTest",
  "icon": "SoundTest.png",
  "iconsel": "SoundTest_sel.png",
  "launch": "launch.sh",
  "description": "Sound test",
  "noaudiofix": 1
}
```

This option will kill audio server and release sound device then run your app.(noises in this app only)

Miyoo283 Framebuffer auto flip when pan description:

Auto flip function is made for developers want to rotate 180 in framebuffer and won care how fb0 works.

It works also rely on 'LD_PRELOAD'.

MainUI will add [LD_PRELOAD=/customer/lib/libpadsp.so](#) for all app to grab “open/close/ioctl” before libc.

How to enable: The json key is “autoflip”

Example:

```
{
  "label": "LCD Test",
  "icon": "lcd.png",
  "iconsel": "lcd_sel.png",
  "launch": "launch.sh",
  "description": "lcd test",
  "autoflip": 1
}
```

This lib will handle ioctl **FBIOPAN_DISPLAY**, do GFX HW rotate and continue to pan.

Audioserver and autoflip use the same library libpadsp.so, the two json key will appear in Linux Environment:

export PADSP_NO_DSP=1

export PADSP_EN_FLIP=1

More Information please contact MIYOO and refer to audio server and auto flip test case.

Miyoo283 Theme description:

Main UI search directories in **/mnt/SDCARD/Theme/**.

Please refer to demo theme ZIP, it provides 2 themes.

Things can be replaced:

Picture file: png/jpg

BGM and sound effect: mp3/wav

Font: type face in ttf/ttc file, color/size in config.json