Underwater Hand Held Gold Detector User Manual

Product Features:

- Gold discrimination— Double coils using Very Low Frequency (VLF) detection allows the detector to discriminate between gold and other metals.
- User notification by vibration and light— The detector will vibrate and the LED embedded in the detector's head will illuminate once gold is detected.
- Detects gold at a maximum range of meters.
- Detects gold nuggets as small as grams.
- Used in freshwater— The detector can function in saltwater environments, but will degrade faster.
- Cheap—Competing underwater gold detectors cost at least \$1000.
- Lightweight & mobile— The detector weighs pounds

Battery Installation:

- To open the battery compartment, turn the knob counterclockwise several times, then pull to remove the knob.
- Connect an *Energizer Ultimate Lithium Battery* to the battery clip and insert the battery into the detector, clip side first.
 - Other 9V batteries may be used to power the detector, but battery life will vary.
 Lithium-ion batteries are recommended.
- To replace the knob, insert all the way in. Then turn the knob clockwise until sufficiently tight to ensure the seal is watertight.



Operating Instructions:

- Hover the head of the detector to check areas for gold.
- The detector will remain inert until gold is detected. Upon detection, the detector will vibrate and an LED located on the head of the detector will turn on.
- The detector becomes inert again when gold is no longer detected.

Important Notes:

- The detector will turn on and remain on as long as a battery is connected.
- The detector can only turn off by disconnecting the battery. Caution is advised when disconnecting the battery, especially if the detector or your hands are still wet.

Detector Specifications

Weight	2.35 Pounds
Overall Length	24 Inches
Coil Enclosure Diameter	8 Inches
Detection Method	Very Low Frequency
Power	9V Lithium-ion Battery
Battery Life	3.5 Hours
User Feedback	Vibration & White LED Light