AsterEdge X100 - Demonstration Field Guide

Original fictional sample for this open-source portfolio project.

Model: X100 Version: 1.0 Document type: service guide

Fault code E-17: amber status LED flashes twice every five seconds.

Meaning: the sensor is not receiving a stable 12 V DC supply.

Check 1: disconnect power before touching the terminal block.

Check 2: verify the supply at the X100 input is 11.5 to 12.5 V DC.

Check 3: inspect the power cable and terminal screws for looseness.

Check 4: restore power and wait 30 seconds before checking the LED.

If E-17 remains, record the measured voltage and escalate to support.

Safety: this fictional guide is a software demo, not real repair advice.