Távirányító segédlet

Varga András Távirányító Specialista

Tel.: (06-1) 338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	ORION HT800A							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
ப	Power	Open						
ΑV	Source							
TEXT	Prog/Memo	Title/Band						
TV	Usb/Card							
Ō								
	Subtitle							
≡♦	Zoom	Angle						
Back		Repeat						
≣X Epg∢I	0.							
≣.>	Step	А-В						
₩	Stop							
i II	Pause							
Red Green	Davi						1	-
Green ✓ Yeijow	Rev						1	-
Yeilow ►	Play							
Blue ▶▶	Fwd	Dualogia						
	Audio	Prologic						
Pict	Cotup							
Fict ◀	Setup							
OK	Enter							
→ OK	Enter			+		+	+	
MENU	Menu/Pbc			+		+	+	
₩ENO	₩IEHU/I DC							
EXIT	•							
VOL+	Vol+			_				
i+	Display					+		
CH+	Next	Tuner+		+		1		
	Vol-	1 0.1101 1						
MUTE	Mute	Channel						
CH-	Prev	Tuner-						
1	1							
2	2							
3	3							
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
Guide 1.	-/							
0/10	0/10							
Fav 2.		Goto						