Távirányító segédlet

Varga András Távirányító Specialista

Tel.: (06-1) 338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	ORION HT500							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
ம	Power	Eject						
ΑV	Input							
TEXT	Prog	Title						
TV	P/N							
Ō								
	Subtitle							
≡≑	Zoom	Angle						
Back	Repeat	A-B						
≣X Epg ∢ l	Slow	Clear						
≣.								
■X	Stop							
in	Pause	Mark						
Red								
Green ←	Rev							
Yeilow	Play							
Blue ▶▶	Fwd							
日	Audio	Prologic						
Pict	Setup	Pscan						
◀	◀							
OK	Enter							
	•							
MENU	Menu	PBC						
•	•							
EXIT	Return							
VOL+	Volume+							
i +	OSD							
CH+	Next							
VOL-	Volume-							
MUTE	Mute	CH						
CH-	Prev	1						
1	1	Shuffle						
2	2	L/R						
3	3	3D						
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
Guide 1.	10+							
0/10	0							
Fav 2.	Search							