Távirányító segédlet

Varga András Távirányító Specialista

Tel.: (06-1) 338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	ORION DVD6000							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
ن	Power	Open/Close						
ΑV								
TEXT	Prog	Title						
TV	USB/Card	N/P						
Û								
	Subtitle	PBC						
≡≑	Zoom	Angle						
Back	Repeat	A-B						
≡X Epg ∢ I	Slow	Clear						
≣.º	Step							
¥	Stop							
in	Pause							
Red		1						
Green ←	Rev	1						
Yeilow	Play							
Blue	Fwd							
A	Language							
_	_							
Pict	Setup	V-Mode						
◀	◀							
OK	Enter							
>	>							
MENU	Menu							
•	•							
EXIT	Return							
VOL+	Volume+							
i+	OSD							
CH+	Next							
	Volume-	<u> </u>						
MUTE	Mute	R/L						
CH-	Prev	1						
1	1	 						
2	2	<u> </u>						
3	3							
4	4	 						
5	5	1						
6	6	1						
7	7							
8	8	<u> </u>						
9	9	1						
Guide 1.	10+	1						
0/10	0/10	1						
Fav 2.	Goto	1						