SOFTWARE SCPECIFICATION

Railway Control Center

Author: Group 29 Yang Fuyi


Table of Contents

SOFTWARE SCPECIFICATION


```
Table of Contents
System Architecture
Software Specifications
   S1 Floor UI
        S1.1 Target Direction Button
            S1.1.1 Basement UI
            S1.1.2 MidFloor UI
            S1.1.3 Top UI
        S1.2 Floor display
   S2 Elevator UI
        S2.1 Open and Close door
        S2.2 Target Floor Button
            S2.2.1 Floor 1,2,3 Button
            S2.2.2 Basement Button
        S2.3 Elevator Display
   S3 Controller
        S3.1 Door State
            S3.1.1 automatically open
            S3.1.2 automatically close
        S3.2 Elevator movement
            S3.2.1 moved when door closed
            S3.2.2 Corresponding physical constraints
            S3.2.2 Height and Speed
        S3.3 Scheduling algorithm
            S3.3.1 FloorRequests
            S3.3.2 ElevatorRequests
```

S3.3.3 Meet Requests in one service cycle

System Architecture



Software Specifications




S1 Floor UI

S1.1 Target Direction Button


By pressing **Up/Down/B Button**, Floor UI can send **UpRequest/DownRequest** to controller by **addFloorRequest()** function, then Controller will add the requiement into its UpRequest/DownRequest array by **getRequest()** and **getNextTarget()**.

S1.1.1 Basement UI




At Basement, user can only press Up Button to go up, Basement UI will send this request to controller.

S1.1.2 MidFloor UI




At Middle Floors, user can press Up or Down Button to go up or go down, Floor UI will send this request to controller.

S1.1.3 Top UI



At Top Floor, user can press Down Button to go down, Floor UI will send this request to controller.


S1.2 Floor display




To show the floor and movestate of the elevator, elevator will first use the function move() to renew its position according to its speed(according to the speed and physics formula). Then controller will receive the data, and use function update() to update the data. After that, controller will use loadUI function(print data information on UI displayers) to renew all elevators floor and movestate based on timer. This can have two results: the displayer will show the floor and the movestate.

S2 Elevator UI

S2.1 Open and Close door



In the elevator, users can press the OpenButton to Open the door when the elevator is standby. The elevator UI will change the DoorState to "Opening" by controller and then calling the OpenDoor() function.




In the elevator, users can press the CloseButton to close the door when the door is Opened. The elevator UI will change the DoorState to "Closing" by controller and then calling the CloseDoor() function.

S2.2 Target Floor Button


By pressing **Floor Button**, Elevator UI can send **Request** to controller by **addElevatorRequest()** function, then Controller will send the Target to the elevator by calling **getNextTarget()** function and then use **goNextTarget** to change Elevator's move state.

S2.2.1 Floor 1,2,3 Button




In the elevator, user can choose the floor he wants to go by pressing Button.

S2.2.2 Basement Button



In the Left elevator, user have one more button selection: Basement Button, which let the UI give the Basement Request to Controller.

S2.3 Elevator Display




To show the floor and movestate of the elevator, elevator will first use the function move() to renew its position according to its speed(according to the speed and physics formula). Then controller will receive the data, and use function update() to update the data. After that, controller will use loadUI function(print data information on UI displayers) to renew all elevators floor and movestate based on timer. This can have two results: the displayer will show the floor and the movestate.

S3 Controller


S3.1 Door State

S3.1.1 automatically open



The door will be automatically open as soon as the elevator stopped at the target floor, after judging its speed and state, the controller will change the doorstate to **Opening** and calling the function **OpenDoor()** to open the door;


S3.1.2 automatically close



The door will be automatically open as soon as the elevator stopped and have opened for some moments, the controller will change the doorstate to **Closing** and calling the function **CloseDoor()** to close the door;


S3.2 Elevator movement

S3.2.1 moved when door closed



At the beginning of every timer function updating, the controller will check if the **doorstate == "Closed"** is true, if true, then the evelator can call the function **move()**, which based on its speed and accertation and obey the physics formula.

S3.2.2 Corresponding physical constraints



When the door is closed, controller have the ability to change the move state of elevators by calculating the distance with the targets floor. Elevator has 4 move states:**Start**, **Stop**, **Run and Standby**.

- Start: The elevator begins to accelerate uniformly, and this time its accerlation is 0.5m/s^2;
- **Stop**: The elevator begins to disaccelerate uniformly, and this time its accerlation is **0.5m/s^2** but has a direction **-1**, which means the acceration is in the opposite direction to speed. When the controller finds the "elevator.v^2 ==dis(elevator,targetfloor)" is true, it will change the elevator move state to Stop and make sure it will stop at the target floor;
- **Run**: The elevator begins to move at a constant speed, when the elevator has speeded up to **1m/s**, and will keep on this speed.
- **Standby**: The elevator don't move and stop at the floors.


S3.2.2 Height and Speed


The top Floor is Floor3 and the lowest is Basement, so the elevators heights should no more than 9m and no less than -3m. In our code, we will met the elevator stop at every floor so it won't cross the line.

S3.3 Scheduling algorithm

S3.3.1 FloorRequests


Every moment the FloorUI send request to controller will send the service direction at the same time. The request will be first saved in controller's array and to find the objected elevator to take the target every moment. We decide to let the elevator who has the same **serviceState** has the priority, then the others.





S3.3.2 ElevatorRequests

Every moment the ElevatorUI send request to controller, controller will decide the service direction depends on their heights. Easier than FloorRequests, the request ElevatorUI sends will be immediately turn in to elevators' service array.




S3.3.3 Meet Requests in one service cycle

The Elevator has 2 state:**moveState and serviceState**. MoveState is only decide the elevator is speed up/down, constant moving or standby while the serviceState decides how the elevator system scheduling algorithm works.

(Definition: We say elevators finish one one service cycle when elevators finish one such service state transition cycle: standby->served all up-direction requests -> served all down-direction requests->standby).

Elevators have 2 array to store the targetFloors they need to go, one is **Upservice** and another is **Downservice**. The controller is scanning one of the two elevators' service array every moment to decide whether their serviceState needs to change or not.Like this:



Every moment, if the controller find there is a target in service(direction is the same to elecator's serviceState)array, the elevator's nextTarget will be it and go to it; and when there is no target in the same service direction, controller will change the elevator's serviceState for one more scanning.

So on, the elevator won't miss the same serviceState target floor and will change the state if there is no target. By this way, we can meet all requests in one service cycle.