

GoSure Telematics

Pvt Ltd

Command list

Quick Start

Set domain/IP & Port

SERVER,1,domain,port#	example: SERVER,1,gateway.test.com,11139#
SERVER,0,IP,port#	example: SERVER,0,120.234.211.110,11139#
SERVER#	query the current setting

Set APN

APN,apn name#	example: APN,cmnet#
APN,apn name,username,password#	example: APN,cmnet,test,test#
APN#	query the current setting

Note: After configuring the APN, device will restart after 10 seconds.

After completing the settings of server and APN, the device will connect to the platform.

General Parameter Configuration

Upload interval

TIMER,T1,T2#	example: TIMER,10,300# T1=0, 5~18000 seconds; ACC ON upload interval. T2=0, 5~18000 seconds; ACC OFF upload interval.
TIMER#	query the current setting.

Upload distance (If it is TIMER mode, DISTANCE mode will auto OFF)

DISTANCE,D#	example: DISTANCE,300# D=0, 50~10000 meters. unit: meter. Default:300 meters.
DISTANCE#	query the current setting.

Heartbeat interval

HBT,T1,T2#	example: HBT,6,8# T1: ACC ON heartbeat packet upload interval, range 1-10 minutes. T2: ACC OFF heartbeat packet upload interval, range 1-10 minutes.
HBT#	query the current setting.

Angle report

ANGLEREP,X,A,B#	example: ANGLEREP,ON,20,3# X=ON/OFF, default value: ON A=5~180 degrees deflection angle; default value: 20 degrees. B=2~5 seconds detection time; default value: 3 seconds. ANGLEREP,OFF# Turn off the feature.
ANGLEREP#	query the current setting.

SOS number settings

SOS, A,Number1,Number 2,Number 3#	Add SOS number
SOS,D,N1,N2,N3#	Delete SOS number by serial
SOS,D,SOS number#	Delete by number
SOS,U,N,SOS number#	SOS number modification command N: Serial number 1/2/3

Center number setting

CENTER,A,center number#	Add center number
CENTER,D#	Delete center number

External power voltage reporting (Requires hardware support)

ADT,SW,T#	SW= ON or OFF. T: Upload interval, range 5-3600 seconds. Default value (OFF ,600#)
ADT#	query the current setting.

Alarm Parameter Configuration

Over Speeding alarm

SPEED,A,B,C,M#	A=ON/OFF; overspeed alarm; default value: ON B=5~600 seconds; detection time range; default value: 20 seconds C=1 ~255km/h; overspeed threshold range; default value: 50km/h M=0/1; alarm reporting method, 0 GPRS only, 1 SMS+GPRS;
SPEED#	query the current setting.

Vibration alarm

SENALM,A,M#	A=ON/OFF, default value: ON M=0~3; Alarm reporting method 0 GPRS only 1 SMS+GPRS 2 GPRS+SMS+CALL 3 GPRS+CALL
SENALM#	query the current setting.

Power failure alarm

POWERALM,A,M,T1,T2,T3#	A=ON/OFF; Default value: ON M=0~3; 0 GPRS only, 1 SMS+GPRS; 2 GPRS+SMS+CALL, 3 GPRS+CALL; T1=2~3600 seconds; power failure detection time, default value: 10 seconds; T2=1-3600 seconds; minimum charging time, default: 1 second. T3=0-3600 seconds; ACC ON to OFF transition prohibition alarm time, default: 0 seconds.
POWERALM#	query the current setting.

Low battery alarm

BATALM,A,M#	A=ON/OFF; Default value: ON M=0~1; 0 GPRS only, 1 SMS+GPRS;
BATALM#	query the current setting.

External power low battery alarm

EXBATALM,SW,M, V1, V2,T#	SW=ON/OFF; Default value: OFF M=0~1; Alarm mode. 0 GPRS only, 1 SMS+GPRS. V1: low battery alarm threshold, range 10-1000. V2: threshold voltage to release prohibition alarm, range 10-1000. T: is the detection time, ranging from 1-300 seconds. Default value (OFF,0,128,138,10#)
EXBATALM#	query the current setting.

External low power protection voltage reminder (Requires hardware support)

EXBATCUT,<SW>[,M][,V1][,V2][,T]#	SW: switch, ON/OFF. M: Alarm reporting method, 0 GPRS only, 1 SMS+GPRS. V1: low battery alarm threshold, range 10-360. V2: threshold voltage to release prohibition alarm, range 10-360. T: is the detection time, ranging from 1-300 seconds. Default value (OFF,0,115,120,10#)
EXBATCUT#	query the current setting.

Low battery protection triggers flight mode setting

FLYCUT,SW#	SW:ON/OFF Example: FLYCUT,ON#
FLYCUT#	query the current setting.

Displacement alarm

MOVING,A,R,M#	A=ON/OFF; default value: OFF R=100~1000; displacement radius, unit meter, default value: 300; M=0~3; 0 GPRS only , 1 SMS+GPRS, 2 GPRS+SMS+CALL, 3 GPRS+CALL;
MOVING#	query the current setting.

Violent driving alarm

SPEEDCHECK,A,M,T,ΔV1,ΔV2#	A=ON/OFF, default: OFF. M=0-1 alarm type, default: 0 GPRS only. T=1-30 seconds, detection time, default: 4 seconds.
---------------------------	---

	$\Delta V1=10-300\text{km/h}$, acceleration threshold (speed change), default: 30km/h. $\Delta V2=10-300\text{km/h}$, deceleration threshold (speed change), default: 50km/h.
SPEEDCHECK#	query the current setting.

Sharp turn alarm

SWERVE,A,M, ΔC ,V,T#	A=ON/OFF, sharp turn detection function switch, the default is off. M=0-1, alarm type, default M=0 GPRS only. $\Delta C=10-180$ degrees, heading angle change threshold, default 30 degrees. V=10-200KM/H, speed threshold, default 60km/h. T=1-30 seconds, sharp turn detection time, default 3 seconds.
SWERVE#	query the current setting.

Collision alarm (Requires hardware support)

COLLIDE,A,M,N#	A=ON/OFF, collision switch, default OFF. M=0~1, reporting mode, default 0 GPRS. N=10-1024, collision level, default: 800
COLLIDE#	query the current setting.

Rollover alarm (Requires hardware support)

ROLLOVER,SW,M,N,T#	SW: switch, ON/OFF. M: Alarm reporting method, 0 GPRS only, 1 SMS+GPRS. N: average value change threshold, range 1-40, unit 0.1g (g represents gravity acceleration). T: The continuous sampling time of three-axis data after a valid collision alarm is generated, ranging from 1-90 seconds.
ROLLOVER#	query the current setting.

Removal alarm (Requires hardware support)

PULLALM,A,M,T,A#	A=ON/OFF, default OFF. M=alarm reporting method, M=0 GPRS only; M=1 SMS+GPRS, M=2 GPRS+SMS+CALL, M=3 GPRS+CALL; default 0. T=power outage detection time, range: 2-60 seconds, default 20 seconds.
------------------	--

	A=1-100, use 10 times the A value as the acceleration judgment value, default =30.
PULLALM#	query the current setting.

Falling off alarm (Requires hardware support)

TURNOVER,A,M,N,T1,T2,T3#	A=ON/OFF, alarm switch, default OFF. M=Alarm reporting method. M=0 GPRS only, M=1 SMS+GPRS, M=2 GPRS+SMS+CALL, M=3 GPRS+CALL. Default 0. N: calibration value three-axis comparison phase difference intensity: range: 1~20, unit: 0.1g, default 7. T1: Time to collect three-axis calibration values: Range: 3~60, unit: seconds, default 30. T2: Determine the duration of the trigger condition, range: 3~90, unit; second, default 5; (T1+30 must be greater than T2) T3: Silent time, range: 1~60, unit; minutes, default 10;
TURNOVER#	query the current setting.

ACC alarm (Requires hardware support)

ACCALM,SW,M, T, N#	SW= ON/OFF. M: Alarm reporting method, 0 GPRS only, 1 SMS+GPRS. T: detection time, range 5-60 seconds. N: Report type, 0 is an alarm for ACC status change; 1 is an alarm for ACC turning OFF; 2 is an alarm for ACC turning
ACCALM#	ON. query the current setting.

SOS alarm (Requires hardware support)

SOSALM,ON,M,T#	ON=turn on SOS alarm, default is ON. M=alarm reporting method, M=0 GPRS only; M=1 SMS+GPRS; M=2 GPRS+SMS+telephone; M=3 GPRS+CALL. T=Alarm trigger delay, range 1 00 ~ 10000, unit ms, default value 3000 ms. Default alarm mode: reporting mode is 2.
SOSALM#	query the current setting.

Query commands

Function	Command
Query device version	VERSION
Query device status	STATUS
Device self-check	CHECK
Longitude and latitude position query	WHERE
Location link query	URL
ICCID query	ICCID
IMSI query	IMSI

Other commands

Function	Command
Restore factory settings	FACTORY
Restart command	RESET,A# A= 1-60s, the terminal restarts after A seconds.
Password switch	Turn on command password function command: PWDSW,ON# //Default OFF Turn off the command password function command: PWDSW,P,OFF# P: Password. After turning it on, the SMS command setting and query must have a password, such as SEVER,666666#
Change password	PASSWORD,P1,P2# P1: old password. P2: New password. Note: The password is factory set to "666666". Example: PASSWORD,666666,888888# PASSWORD set OK!