

Instrução	Opcode [4..0]					WrPC	SelA1	SelA0	SelB	WrAcc	OpSel	RdRam	WrRam
HLT	0	0	0	0	0	0	X	X	X	0	X	1	0
STO	0	0	0	0	1	1	X	X	X	0	X	0	1
LD	0	0	0	1	0	1	0	0	X	1	X	1	0
LDI	0	0	0	1	1	1	0	1	X	1	X	1	0
ADD	0	0	1	0	0	1	1	0	0	1	0	1	0
ADDI	0	0	1	0	1	1	1	0	1	1	0	1	0
SUB	0	0	1	1	0	1	1	0	0	1	1	1	0
SUBI	0	0	1	1	1	1	1	0	1	1	1	1	0

