How to configure the Wi-Fi function for the device

Before configuration

The Device serve as a station in the wireless network, before the Device apply to Network, another physical component of that 802.11 network consist Distribution system, Access Point, Wireless Medium must exist.

You must know the SSID (name of network) of local network you want to connect to.

Please note:

When you finish the WIFI setting and device restarted, please change the device wired network IP address to another network segment.

Example: WIFI IP 192.168.1.97, the device wired

network IP: 192.168.0.201.


You should make the device wired IP address and your computer IP address not in the same network segment, but the WIFI IP address and your computer IP address should in the same network segment.

Operation step

Step 1. Unzip the file to your pc from WIFIConfigTool.zip.

Step 2. Connect the Device fingerprint machine with the PC over the Ethernet or RS 232

Step 3. Double-click WIFIConfigTool.exe to open this file, the following windowing appear.



Step 4.Activate the software

There are two options Active Active, isable Obisable on the interface, for wireless End (station) the two options must to be set down.

If you select the Active item, this wireless-end will be activated, you can configure the AP (Access Point) of 802.11 network.

If you select the Disable, this wireless-end will be invalid, you can set the connection way of the fingerprint machine, and its configuration of IP address.


Step5 Confirm Network ID

Full the blank of local wireless Network ID you want to connect with any character or figure (capital letter and small letter is different)

Note: must fulfill the blank that is marked with "*"

Step6 Determine Network model

there are two option , Infrastructure Model, and Ad - hoc Model, shown as following figure



Hub-and-spoke wireless network



Ad-hoc (peer-to-peer) wireless network

click the draw -down box Infrastructrue Model
to select the wireless network model, depending on the
different topology of network, this Infrastructure Model will
apply to Hub and Spoke wireless network, the Ad - hoc Model

Step 7. Select the Authentication Type,

is used in the peer to peer wireless network...

the Infrastructure Model include five Authentication Type that are OPEN, SHARED, WEPAUTO, WPAPSK, WPA2PS. the Ad - hoc Model include OPEN, SHARED, WEPAUTO, WPANONE four type of Authentication Type.

Click the draw-down box

to select the Authentication Type

Step 8.Select Encrypt Type

When the item NONE of encrypt Type is selected, then the password in WEP (Wired equivalent privacy) and WPA (WiFi

protested access) item is not permitted to modify it, it is not need to input password too.

According to Authentication Type, and Encrypt Type ,Click
draw down box NONE to input the password, password comply with the criterion set down by the

Note: there are four group passwords in the WEP column, till the all password have been set up is correct, the current password is valid

Step 9Set Connection Parameter

software


The fingerprint machine fully support two connection ways, one TCP/IP, anther one is RS 232,.

If you select TCP/IP, here the IP and Port value must to be assigned, its value is same with one in the communication option of the fingerprint machine. Set the option Ethernet in the fingerprint machine to "Yes".

If you selectRS232, must configure these parameter ,DeviceID, COMPort, Baud rate same with one in the communication option of the fingerprint machine.

Step10. Configure the wireless Network IP address

Click configMchine this button, the following menu will pop-up



If there is the DHCP function in the 802.11 network Distribution system, you may choose DHCP, press OK to exit.

Otherwise, full the IP Address, Subnet Mask blank with the correct figure, press OK to exit to main interface.

After all setting for wireless network is completed, single –click SETbutton on the MODEMConfigTool interface, the prompt "in working" will appear on the fingerprint machine.

After configure successfully, the corresponding message will inform you, click OK to close the message.

Be sure to shut down and restart the machine, so the configureation change take effect.

View the fingerprint machine Wireless Setting

You can view the B&W fingerprint machine Wireless Setting to get the information of the wireless network communication

Power on the Fingerprint Machine, press menu → System Info→ Dev Info → wirlesscard→ rausb0: