

Section 1: Overview

- Model: TitanX 4000
- Engine Type: Diesel, 6-cylinder
- Fuel Capacity: 300 liters
- Normal Engine Temperature Range: 80°C – 95°C

Section 2: Daily Checks

- Check fuel level before starting the engine.
- Ensure tire pressure is between 90–100 PSI.
- Verify coolant level is above minimum mark.

Section 3: Troubleshooting

Tracker Reset:

1. Press and hold the *Reset* button for 5 seconds.
2. Wait for LED to blink twice.
3. Reconnect to the fleet dashboard.

Low Fuel Warning:

- If fuel level < 15%, refuel immediately.
- Avoid running below 10% to prevent pump damage.

Section 4: Maintenance

- Oil change every 10,000 km.
- Engine diagnostics every 30,000 km.
- Replace air filter every 15,000 km.

Section 5: Safety

- Always engage parking brake before leaving the vehicle.
- Do not exceed 120 km/h.
- Follow IoT dashboard alerts for temperature or pressure anomalies.