



Homework


Name: Yaseen Riyadh Bandar

College: Engineering

Department: Petroleum


Stage: 4th

The mean horizontal permeability for all cells:



The mean: 1275.3541

The mean horizontal permeability for cells in zone 1:



The mean: 983.0811

The mean horizontal permeability for cells in segment 3:

The screenshot shows the 'Settings for 'Permeability'' dialog. At the top, there are tabs for Style, Info, Statistics, Histogram, Colors, Operations, More, Variogram, Quality attributes, and Structural analysis. The 'Statistics' tab is selected. A dropdown menu 'For zone:' is set to 'Zone 1'. Below the tabs is a table with columns 'Axis', 'Min', 'Max', and 'Delta'. The data is as follows:

Axis	Min	Max	Delta
X	1268.84	10373.37	9104.53
Y	3372.02	13815.63	10443.61
Z	-2858.83	-1682.15	1176.68
Permeability	10.0000	4905.0000	4895.0000

Below this is a section titled 'Description' with various properties and their values:

- Unit: mD
- Is upscaled (U): No
- Total number of defined cells in filtered area: 15837
- Total number of upscaled cells: 0
- Have the upscaled cell values been edited?: No
- Number of edited upscaled cells: 0
- Grid cells (nI x nJ x nK): 80 x 83 x 28
- Total number of grid cells: 185920
- Property resolution: Per cell with volume (c...)

At the bottom is a table for 'Property' with columns Name, Type, Min, Max, Delta, N, Mean, Std, Var, and Sum. The data is:

Name	Type	Min	Max	Delta	N	Mean	Std	Var	Sum
Property	Cont.	10.0000	4905.0000	4895.0000	15837.0000	1376.4774	1660.2791	2756526.5499	21799273.25...
Upscaled									
Well logs									

The mean: 1376.4774

The mean horizontal permeability for cells in channel sand cells in segment 4 & 2:

The screenshot shows the 'Settings for 'Facies'' dialog. At the top, there are tabs for Variogram, Quality attributes, and Structural analysis. The 'Quality attributes' tab is selected. A dropdown menu 'For zone:' is set to 'Zone 1'. Below the tabs is a section titled 'Entire property statistics:' with a table:

Co...	Name	%	N	Intervals	Min	Mean	Max	Std
0	Background flood...	48....	18322	3603	0.0 (1)	25.2 (5.09)	99.0 (20)	24.76
1	Channel sand	29....	11020	3228	0.0 (1)	17.1 (3.41)	100.4 (20)	17.38
2	Levee sand	21....	8188	2966	0.0 (1)	13.8 (2.76)	60.7 (12)	10.59

Below this is a section titled 'Upscaled cells statistics:' with a button icon.

The mean: 17.1(3.41)

Number of cells in model: **94391.0000**

Settings for 'Permeability'

For zone: Zone 1

Axis	Min	Max	Delta
X	1268.84	10373.37	9104.53
Y	3372.02	13815.63	10443.61
Z	-2858.83	-1682.15	1176.68
Permeability	10.0000	4905.0000	4895.0000

Description Value

Unit mD

Is upscaled (U) No

Total number of defined cells in filtered area: 94391

Total number of upscaled cells: 0

Have the upscaled cell values been edited? No

Number of edited upscaled cells: 0

Grid cells (nl x nJ x nK) 80 x 83 x 28

Total number of grid cells: 185920

Property resolution: Per cell with volume (c...)

Name	Type	Min	Max	Delta	N	Mean	Std	Var	Sum
Property	Cont.	10.0000	4905.0000	4895.0000	94391.0000	1275.3541	1608.0237	2585740.3449	120381953.2...
Upscaled									
Well logs									

Number of horizons: **4**

Settings for 'Horizons'

Operations

Axis	Min	Max	Delta
X	1268.84	10373.37	9104.53
Y	3382.40	13815.63	10433.22
Z	-2858.83	-1682.15	1176.68
Lat	-	-	-
Long	-	-	-

Description Value

Number of horizons: 4

Nodes (nl x nJ) 81 x 84

Cells (nl x nJ) 80 x 83

Total number of 2D nodes: 6804

Total number of 2D cells: 6640

Cells dimensions:

Settings for 'Edges'

This screenshot shows the 'Settings for Edges' dialog. At the top, there are three tabs: 'Style', 'Info', and 'Statistics'. The 'Statistics' tab is selected. Below the tabs is a table with four columns: 'Axis', 'Min', 'Max', and 'Delta'. The data rows are as follows:

Axis	Min	Max	Delta
X	1268.84	10373.37	9104.53
Y	3372.02	13815.63	10443.61
Z	-2858.83	-1682.15	1176.68
Lat	-	-	-
Long	-	-	-

At the bottom of the dialog, there are two buttons: 'Description' and 'Value'.

Number of channel sand cells in model: **25131**

Settings for 'Facies'

This screenshot shows the 'Settings for Facies' dialog. At the top, there are several tabs: 'Variogram', 'Quality attributes', 'Structural analysis', 'Style', 'Info', 'Statistics', 'Discrete statistics', 'Histogram', 'Colors', and 'Operations'. The 'Statistics' tab is selected. Below the tabs is a section titled 'For zone:' with a dropdown menu set to 'Zone 1'. Underneath this is a section titled 'Entire property statistics:'.

Below this section is a table showing property statistics for three zones:

Co...	Name	%	N	Intervals	Min	Mean	Max	Std
0	Background floodplain	50...	47473	9421	0.0 (1)	24.9 (5.04)	103.9 (21)	24.45
1	Channel sand	26...	25131	7828	0.0 (1)	16.1 (3.21)	100.9 (21)	16.5
2	Levee sand	23...	21787	8244	0.0 (1)	13.1 (2.64)	140.4 (28)	10.06

Below the table is another section titled 'Upscaled cells statistics:' with a button icon.