Maintenance Start

Disconnect power before maintenance.

Maintenance Finish

Inspect every month.

Printed page 7