

1. Overview

TerraDry D400 Industrial Dehumidifier - User Manual (Model D400, Revision 2026-A).

The TerraDry D400 is a three-phase, floor-standing industrial dehumidifier designed for larger enclosed spaces such as warehouses, parking garages, and server rooms. It uses a scroll compressor with R-410A refrigerant and includes a built-in condensate pump.

This manual covers setup, operating limits, and safety exceptions for the D400. For the smaller single-phase D200 model, see its separate manual.

2. Setup Steps

1. Position the unit on a level, hard floor with at least 60 cm clearance on all sides for airflow.
2. Have a licensed electrician connect the unit to a grounded three-phase 380-415V, 16A supply. A dedicated circuit breaker is required.
3. Connect the built-in condensate pump's 8mm discharge tube to a drain point up to 5 meters vertically; continuous drainage is mandatory (there is no internal tank).
4. Power on via the main isolator switch, then press POWER on the control panel.
5. Set the target humidity (30 percent to 80 percent RH) via the touchscreen and press START.

The unit performs a 3-minute self-test before beginning dehumidification.

3. Specifications and Limits

Maximum coverage area: 90 square meters (969 sq ft) at 3m ceiling height.

Water removal capacity: up to 55 liters per day at 30C, 80 percent RH.

Drainage: continuous only via built-in condensate pump (no internal tank).

Operating temperature range: 5C to 40C.

Operating humidity range: 30 percent to 90 percent RH.

Sound level: 58 dB(A) at 1 meter.

Power consumption: 1450W nominal.

4. Exceptions and Safety

The D400 has no low-temperature exception mode: it must not be operated below 5C ambient temperature under any configuration, including with third-party defrost accessories, as this will void the warranty and may damage the scroll compressor.

Do not operate the unit outdoors or in direct rain. Do not connect the condensate pump to a shared drain line without a check valve.