

- 1. Vision kit 실행
 - 1. 안드로이드 휴대폰에 AIY 설치 후 아래와 같은 사진으로 접속
 - 2. vision kit 연결 후 동그란 버튼 약 5초 이상 누름 -> 버튼 옆 초록등 켜짐
 - 3. 앱 wifi 연결 후 ip확인









2. IP로 접속

- 1. Shell 창 혹은 putty로 접속 (아래는 shell)
- 2. 초기 id: pi / password: raspberry

Secure shell app install url

https://chrome.google.com/webstore/detail/secure-shell-app/pnhechapfaindjhompbnflcldabbghjo



3. VNC 연결

1. vnc 뷰어 설치를 위해 명령어 입력

vnc url

https://sunshinebunnysoftware.tech/2019/05/30/connecting-to-vision-kit-using-vnc-connect/

```
raspberrypi:~ $ sudo apt-get update
Get:1 http://archive.raspberrypi.org/debian_stretch_InRelease [25.3 kB]
Get:2 http://raspbian.raspberrypi.org/raspbian_stretch_InRelease [15.0 kB]
gn:3 https://dl.google.com/aiyprojects/deb stable InRelease
Get:4 https://dl.google.com/aiyprojects/deb stable Release [934 B]
Get:5 https://dl.google.com/aiyprojects/deb stable Release.gpg [819 B]
Get:6 http://raspbian.raspberrypi.org/raspbian stretch/main armhf Packages [11.7 MB]
Get:7 http://archive.raspberrypi.org/debian stretch/main armhf Packages [192 kB]
Get:8 http://archive.raspberrypi.org/debian stretch/ui armhf Packages [44.6 kB]
lgn:5 https://dl.google.com/aiyprojects/deb stable Release.gpg
Get:9 https://dl.google.com/aiyprojects/deb stable/main armhf Packages [2,840 B]
Get:10 http://raspbian.raspberrypi.org/raspbian stretch/contrib armhf Packages [56.9 kB]
Get:11 http://raspbian.raspberrypi.org/raspbian stretch/non-free armhf Packages [98.9 kB]
Fetched 12.1 MB in 35s (339 kB/s)
Reading package lists... Done
W: GPG error: https://dl.google.com/aiyprojects/deb stable Release: The following signatures were invalid: EXPKEYSIG 6494C6D6997C215E Google Inc. (Linux Packages Signing Authority) <linux-packages-keymaster@google.com>
W: The repository 'https://dl.google.com/aiyprojects/deb stable Release' is not signed.
  Data from such a repository can't be authenticated and is therefore potentially dangerous to use.
   See apt-secure(8) manpage for repository creation and user configuration details
```

```
sudo apt-get update
sudo apt-get install realvnc-vnc-server realvnc-vnc-viewer
```

4. VNC 활성화

1. 아래 명령어 입력 후 vnc 활성화 5번 -> 3번 sudo raspi-config

| 1 Change User Passwor | rd Change password for the current user |
|-----------------------|---|
| | Configure network settings |
| 3 Boot Options | Configure options for start-up |
| 4 Localisation Option | ns Set up language and regional settings to match your location |
| 5 Interfacing Options | s Configure connections to peripherals |
| 6 Overclock | Configure overclocking for your Pi |
| 7 Advanced Options | Configure advanced settings |
| 8 Update | Update this tool to the latest version |
| 9 About raspi-config | Information about this configuration tool |
| | |
| | |
| | |
| | ect> <finish> </finish> |
| | |
| L | |
| | |

| | | Raspberry Pi Software Configuration Tool (| raspi-config) |
|--------------|------------------------------|--|---------------|
| | | | |
| P1 Camera | | n to the Raspberry Pi Camera | |
| P2 SSH | Fnahle/Nisahle remote com | mmand line access to vour Pi using SSH | |
| P3 VNC | Enable/Disable graphical | remote access to your Pi using RealVNC | |
| P4 SPT | Enable/Disable automatic | loading of SPI kernel module | |
| P5 12C | | loading of I2C kernel module | |
| P6 Serial | | kernel messages on the serial connection | |
| P7 1-Wire | Enable/Disable one-wire | interface | |
| P8 Remote GP | 10 Enable/Disable remote acc | | |
| | · | · | |
| | | | |
| | | | |
| | | | |
| | <select></select> | <back></back> | |
| | -001000- | -Duoite | |
| | | | |
| | | | |

5. VNC 접속

1. vnc 접속 후 ip 입력 -> id, password 입력하면 접속 완료

