

UART Protocol - Message Structure and Commands

Message	Message Type	Message Data								
		START	CODE	D5	D4	D3	D2	D1	D0	CSUM
	Byte	0	1	2	3	4	5	6	7	8

Version	Request	0x89	0x00	n/a	n/a	n/a	n/a	n/a	n/a	Varies
	Response	0xEE	0x80	STATUS	n/a	n/a	TYPE	MAJOR	MINOR	Varies

Parameter Read	Request	0x89	0x05	PARM	n/a	n/a	n/a	n/a	n/a	Varies
	Response	0xEE	0x85	STATUS	n/a	Data (32b)				Varies

Parameter Write	Request	0x89	0x06	PARM	n/a	Data (32b)				Varies
	Response	0xEE	0x86	STATUS	n/a	n/a	n/a	n/a	n/a	Varies

Motor Control Read	Request	0x89	0x07	n/a	n/a	n/a	n/a	n/a	n/a	Varies
	Response	0xEE	0x87	STATUS	n/a	n/a	n/a	n/a	CTL	Varies

Motor Control Write	Request	0x89	0x08	n/a	n/a	n/a	n/a	n/a	CTL	Varies
	Response	0xEE	0x88	STATUS	n/a	n/a	n/a	n/a	n/a	Varies

CAFÉ Register Read	Request	0x89	0x09	n/a	n/a	Reg Addr				Varies
	Response	0xEE	0x89	STATUS	n/a	Reg Value				Varies

Comments:

- 1) PARM - Parameter Value Definitions: See tab for Parameter IDs
- 2) CTL - Motor Control Bit Definitions:
 - b0: 1=Start Motor / 0=Stop Motor
 - b3: 1=Reset OverCurrent

Green highlight indicates commands that are normally used while controlling the motor. When loading values using hardcoded default settings in firmware, it is usually not necessary to use commands other than the ones highlighted in green.