

write open-loop form
in type-standard form



identify system
type



choose $K_p/K_v/K_a$
from input type



compute error or
solve parameter range