


# **Owners Manual**

# **INSTALLATION, OPERATION, & PARTS**



# Models C2025 C3025 C4025 C5025 C7000 SWIMCLEAR™ CARTRIDGE FILTERS

MODEL		FILTRATION ATE	DESIGN F Residential	LOW RATE Commercial
	FT <sup>2</sup>	M <sup>2</sup>	GPM	LPM
C2025	225	20.9	84	318
C3025	325	30.2	122	462
C4025	425	39.5	150	568
C5025	525	48.8	150	568
C7000	680	63.2	150	568
MAXIMU	JM WORKING F	RESSURE FOR	ALL MODELS 50 I	PSI (3.45 BAR)

ATTENTION INSTALLER: THIS MANUAL CONTAINS IMPORTANT INFORMATION
ON THE OPERATION, AND SAFE USE OF THIS EQUIPMENT.
THIS MANUAL IS INTENDED FOR THE END USER OF THIS PRODUCT



A This is the safety-alert symbol. When you see this symbol on your equipment or in this manual, look for one of the following signal words and be alert to the potential for personal injury or death.

WARNING Warns about hazards that **could** cause serious personal injury or, death, and or major property damage and if ignored presents a potential hazard.

CAUTION Warns about hazards that **will** or **can** cause minor or moderate personal injury and/or property damage and if ignored presents a potential hazard. It can also make consumers aware of actions that are unpredictable and unsafe. The **NOTICE** label indicates special instructions that are important but not related to hazards.



READ, UNDERSTAND, AND FOLLOW ALL SAFETY AND OPERATION INSTRUCTIONS. FAILURE TO FOLLOW SAFETY AND OPERATION INSTRUCTIONS CAN RESULT IN SEVERE PERSONAL INJURY OR DEATH.

CAUTION To reduce risk of injury, do not permit children to use or climb on this product. Closely supervise children at all times. The ANSI/NSPI-4 Standard (above-ground and on-ground pools) advises that components such as the filtration system, pumps, and heaters be positioned to prevent their being used as a means of access to the pool by young children.



# **M** WARNING **COMPONENT SEPARATION HAZARD**

Pool and spa water circulation systems operate under hazardous pressure during start up, normal operation, and possibly after pump shut off. Pressure in system can cause explosive component separation of the upper filter body if safety and operation instructions are not followed. Severe personal injury or death can result.

This product should be installed and serviced only by a qualified pool professional.

#### TO AVOID COMPONENT SEPARATION

- Follow all safety and operation instructions.
- Do not operate water circulation system if a system component is assembled improperly, damaged, missing, or not a genuine Hayward component.
- Before performing maintenance on the water circulation system, verify all system and pump controls are in OFF position and filter manual air relief valve is in the OPEN position.
- Use ONLY Hayward clamp system components: DEX2421JKIT clamp assembly, DEX2421J2 nut/bolt assembly, and a DEX2422Z2 metal reinforced seal.
  - Non-Hayward components may fail in use and cause explosive separation.
- Never rely on hand tightening the clamp nut to the clamp bolt. Using a ¾" socket on a torque wrench, torque clamp nut and clamp bolt to 150 inch-lbs.
- Before starting system pump, insure filter manual air relief valve body is in LOCK position in filter upper body.
- Before starting the system pump, verify that all system valves are set in a position to allow water from the filter to return back to the pool.
- Before starting the system pump, the manual air relief valve must be in the OPEN position.
- When starting pump, do not stand over or near filter.
- If water leakage appears in the area of the filter tank clamp, immediately turn off all system circulation pumps and electrical power. Do not return to the filter until all water flow has stopped. Reassemble the clamp system per the instructions in this owner's manual to stop the leak.
- Return to filter to close manual air relief valve only when a steady stream of water (Not air or air and water mix) is discharged from the manual air relief valve.
- Do not change filter control valve position while system pump is running.



# A WARNING EXCESS PRESSURE HAZARD

Pressure testing of the pump and filter system in excess of the 50 PSI can cause explosive separation of the components. Component separation can result in severe personal injury or death.





High Voltage electricity is present in the pool and spa equipment. High voltage electricity can cause shock and electrocution. Shock and electrocution can result in severe personal injury or death.

- All electrical wiring MUST be in conformance with applicable local codes, regulations and the National Electrical Code (NEC).
- Before performing any service or maintenance on electrical equipment turn off all electrical power.
- Contact a licensed electrician or building inspector for information on local electrical codes for bonding requirements.
- Verify water discharge from the filter manual air relief valve is directed away from electrical devices.
- Do not locate pump controls over or near filter.





# **A** WARNING-**SUCTION ENTRAPMENT HAZARD.**



Suction in suction outlets and/or suction outlet covers that are, damaged, broken, cracked, missing, or unsecured can cause severe injury and/or death due to the following entrapment hazards:

**Hair Entrapment**- Hair can become entangled in suction outlet cover.



Limb Entrapment- A limb inserted into an opening of a suction outlet sump or suction outlet cover that is damaged, broken, cracked, missing, or not securely attached can result in a mechanical bind or swelling of the limb.

Body Suction Entrapment- A negative pressure applied to a large portion of the body or limbs can result in an entrapment.



Evisceration/ Disembowelment Entrapment- A negative pressure applied directly to the intestines through an unprotected suction outlet sump or suction outlet cover that is, damaged, broken, cracked, missing, or unsecured can result in evisceration/ disembowelment entrapment.

**Mechanical Entrapment-** There is potential for jewelry, swimsuit, hair decorations, finger, toe or knuckle to be caught in an opening of a suction outlet cover resulting in mechanical entrapment.



# TO REDUCE THE RISK OF ENTRAPMENT HAZARDS:

- A minimum of two functioning suction outlets per pump must be installed. Suction outlets in the same plane (i.e. floor or wall), must be installed a minimum of three feet (3') [1 meter] apart, as measured from near point to near point.
- Dual suction outlets shall be placed in such locations and distances to avoid "dual blockage" by a user.
- Dual suction outlets shall not be located on seating areas or on the backrest for such seating areas.
- The pool or spa circulation system shall be designed to comply with ANSI/APSP-7 2006.
- Suction outlet covers shall conform to ANSI/ASME A112.19.8
- Never use Pool or Spa if any suction outlet component (cover/grate) is damaged, broken, cracked, missing, or not securely attached.
- Immediately replace damaged, broken, cracked, missing, or not securely attached suction outlet components.
- The CPSP as well as the ICC International Residential Code Part IX, Appendix G, Section AG106 specifies the installation of a safety vacuum release system conforming to ASME A112.19.17, or an approved gravity drain system.
- Failure to remove pressure test plugs and/or plugs used in winterization of the pool/spa from the suction outlets can result in an increased potential for suction entrapment.
- Failure to keep suction outlet components clear of debris, such as leaves, dirt, hair, paper and other material can result in an increased potential for suction entrapment.

Suction outlet covers and grates have a finite life. They should be inspected frequently and replaced within specified life.


ARD Pool Products A Hayward Industries, Inc. Company

## **GENERAL INFORMATION**

Your **Hayward SwimClear**<sup>TM</sup> cartridge filter combines superior water filtration with ease of operation and totally corrosion-free construction. With filtration ratings to 9000 gallons (34,000 liters) per hour, they are designed for continuous or intermittent operation, for installation above or below the pool water line, for fresh or salt water swimming pools or spas. SwimClear<sup>TM</sup> filters utilize multiple reusable, reinforced polyester filter cartridge elements to provide a high degree of water clarity and long filter cycles with minimum care.

	,	\	RE	QUIRED (	CLEARAN	CE
	<i>'</i>	1	"B" S	SIDE	"C" Al	BOVE
	IN	CM	IN	CM	IN	CM
C2025	32.5	83	18	46	15	38
C3025	34.5	88	18	46	16	41
C4025	40.5	103	18	46	18	46
C5025	46.5	118	18	46	22	56
C7000	52.5	133	18	46	28	71

# INSTALLATION







This product should be installed and serviced only by a qualified pool professional.

- 1. The filter system should be installed on a level concrete slab or other rigid base. Select a well drained and vented area, one that does not flood when it rains. Position the filter so that the piping connections, and winter drain are convenient and accessible for operation, service, maintenance and winterizing.
- Position filter body such that all operation and safety labels are visible.
- 3. Position filter so the filter will drain by gravity.
- 4. If practical, place pump and filter in the shade to shield it from continuous, direct heat from the sun.
- Connect the pool suction plumbing between the skimmer, pool outlet (from the pool) and the pump.
- 6. Install the plumbing from the filter to the pool (return to the pool).
- 7. Do not locate pump controls over or near filter.
- 8. Verify water discharge from the manual air relief valve(MAR) is directed away from electrical devices.



# STARTING THE PUMP and FILTER SYSTEM






#### **Before Starting the Pump**

- 1.Use ONLY Hayward clamp system components; DEX2421JKIT clamp system, DEX2421J2 nut/bolt assembly, DEX2422Z2 metal reinforced seal. Non-Hayward clamp components may fail in use and cause explosive component separation. Verify that upper and lower filter bodies are properly secured with the filter body clamp. Never rely on hand tightening the clamp nut to the clamp bolt. Using a ¾" socket on a torque wrench, torque clamp nut to clamp bolt to 150 inch-lbs. Verify that the filter manual air relief body is in the LOCK position, and no filter components are missing, damaged or not genuine Hayward components. (See Fig 2)
- 2. Close filter drain. Note: Filter plug requires an o-ring seal. (See Fig 4)
- 3. Open all system valves to allow water from the pool to the filtration system and from the filter to return to the pool.
- 4. Place the manual air relief valve in OPEN position. (See Fig 2)

#### **Starting Pump**

- When starting system pump, do not stand over or near filter. If water leakage appears at filter tank clamp, immediately turn off all system circulation pumps and all electrical power. Do not return to the filter until all water leakage has stopped.
  - Reassemble the clamp system per the instructions on page 7 in this owner's manual to stop leak.
- 2. Return to filter to CLOSE manual air relief valve only when a steady stream of water (not air or, air and water mix) is discharged from the manual air relief valve.




# **OPERATION**






#### **FILTERING**

Filtration starts as soon as flow is steady through the filter. As the filter removes dirt from the pool water, the accumulated dirt causes a resistance to flow. As a result, the gauge pressure will rise and the flow will decrease. When the pressure rises 7-10 psi (.49-.69 bar) above the starting pressure, or when the flow decreases below the desired rate, clean or replace the filter cartridge elements. Once your filter is running and there is a pressure reading, line up the green arrow with the current reading. (See Fig 3) When the pressure rises to or above the red or second arrow, it is time to clean or replace your filter cartridge elements.



By recording the initial starting pressure (with clean filter elements) a determination can be made when the filter cartridge elements should be replaced rather than cleaned. After the filter elements have been cleaned and reinstalled if the starting pressure is higher than 6 PSI above the starting pressure with the new filter cartridge elements, the filter cartridge elements should be replaced the next time the gauge arrow reaches the red arrow.





# MAINTAINING YOUR FILTER


**A** WARNING




This product should be installed and serviced only by a qualified pool professional.

#### FILTER DISASSEMBLY INSTRUCTIONS

- 1. Turn off all system circulation pumps and all electric power on the equipment pad.
- Set all system valves in a position to prevent water flow to the filter
- The manual air relief valve must be placed in the OPEN position. (Fig 6)
- 4. Remove filter drain plug (Fig 4) and drain water from filter.
- 5. Using 3/4" wrenches, loosen and remove the clamp nut and the clamp bolt. (Fig 5)
- 6. Holding both ends of the filter clamp carefully spread the clamp ends. Remove the clamp by lifting over the upper filter body. Do not to drop the clamp during removal, because the clamp could be damaged. Do not strike the clamp with metal tools as they can damage the clamp.
- 7. Lift off upper filter body. Do not use the pressure gauge to lift the upper filter body.





#### **REMOVING CARTRIDGES**

- 1. Remove the top closure plate, which is exposed when the upper filter body is removed. (Fig 4)
- Remove the filter cartridge elements by using slight rocking motion and lifting up.
- 3. Clean filter cartridge elements.

#### **CLEANING CARTRIDGES**

The Cartridge filter element can be cleaned by washing inside and outside with a garden hose. After hosing cartridge, for best results, carefully brush the pleated surface to remove fine particles. Do not pressure wash as it can damage the filter element.

You may find some debris on the cartridge pleats, which may not have been removed with hosing.





# FILTER RE-ASSEMBLY INSTRUCTIONS



**▲** WARNING



# **RE-INSTALLING CARTRIDGES**

- Flush and drain any dirt or debris from the bottom of the lower filter
- 2. Flush any dirt or debris from the upper filter body and from around the manual air relief area.
- Carefully replace the cartridges over the hubs on the bottom 3.
- Place top closure plate securely on top of cartridges. 4.

## **CLEAN SEAL RING AND SEAL SURFACE**

- 1. Remove filter tank seal.
- 2. With a clean cloth, wipe the lower filter body seal surface and clean seal of all dirt and debris. (Fig 4) Do not use a solvent.
- 3. With a clean cloth wipe the upper filter body seal surface.



Notice: • Do not use any petroleum solvents to clean filter components.

• Do not lubricate DEX2422Z2 seal.

Place the metal reinforced seal on lower filter

body. (Fig 4) Place upper filter body on metal

position which allows all operation and safety

labels to be clearly visible and the upper filter body to be centered on the lower filter body.

Press down firmly and evenly on the upper

reinforced seal and lower filter body in a



2.


M WARNING

**BODY AND CLAMP RE-ASSEMBLY** 



This product should be installed and serviced only by a qualified pool professional.

# Clamp Bolt Clamp Nut




- Insert clamp bolt through the clamp ends and thread the clamp nut onto clamp bolt with rounded end of the nut 3. (Fig 8) towards the ends of the clamp.
- Never rely on hand tightening of clamp nut to clamp bolt. Using a 3/4" socket on a torque wrench, torque clamp nut 4. to clamp bolt to 150 inch-lbs. (Fig 9)


# $f \lambda$ DO NOT HIT OR STRIKE CLAMP WITH HAMMER OR METAL TOOLS.

Follow Operation Instructions for "Starting the Pump and Filter System" (Page 5). 5.

### **VACUUMING POOL**

Vacuuming can be performed directly into the filter whenever needed. Clean cartridges after vacuuming, if required.









Tighten clamp

wrench to 150

bolt and nut

using a

torque

inch-lbs.

#### REMOVING THE MANUAL AIR RELIEF VALVE






This product should be installed and serviced only by a qualified pool professional.

Your Filter comes with a Manual Air Relief Valve (MAR) preinstalled from the factory.

For Qualified pool professionals only: If MAR valve needs to be serviced, follow these instructions carefully.

- 1. Turn off all system circulation pumps and all electric power on the equipment pad.
- 2. Set all system valves in a position to prevent water from flowing to the filter.
- 3. The manual air relief valve must be placed in the OPEN position.
- 4. Wait until all water leakage has stopped.
- Grasp the MAR body at the flats, turn the MAR counterclockwise until the indicator on the on the MAR flange is aligned with the "UNLOCK" position on the upper filter body.



Manual Air relief Shown Open In Locked Position Rotate counterclockwise to UNLOCK

6. Pull straight up to remove the MAR, a slight rocking motion may help.

This product should be installed and serviced only by a qualified pool professional.

#### RE-INSTALLATION OF THE MANUAL AIR RELIEF VALVE

- 1. Check the o-ring seals, replace as needed.
- 2. With a clean cloth, wipe upper filter body and o-ring groove. Remove all dirt and debris.
- 3. Align the notch in the MAR Flange with notch on top of the upper filter body.
- 4. Press the MAR straight down into the upper filter body.
- 5. Turn the MAR clockwise until the indicator is aligned with the "LOCK" position on the upper filter body.
- 6. Verify the MAR discharge points away from all electrical connections.

#### WINTERIZING FILTER









 $m{m{\Lambda}}$  This product should be installed and serviced only by a qualified pool professional.

In areas where subfreezing temperatures can be expected, the filter should be drained to protect the filter from damage.

- 1. The filter should be disassembled and the filter cartridges elements cleaned or replaced.
- Follow directions under FILTER DISASSEMBLY INSTRUCTIONS
- 3. Then follow REMOVING CARTRIDGES per instructions
- 4. Reassemble per FILTER RE-ASSEMBLY INSTRUCTIONS.
- 5. Be sure to leave the drain plug unattached during the winter season to avoid cracking the filter body.




#### **SERVICE AND REPAIRS**

Consult your local authorized Hayward dealer or service center. No returns may be made directly to the factory without the expressed written authorization of Hayward Pool Products.

SUGGESTED I	POOL CHEMISTRY LEVELS
рН	7.2 to 7.8
TOTAL ALKALINITY	80 to 120 ppm
CALCIUM HARDNESS	200 to 400 ppm
COMBINED CHLORINE	.2 ppm Maximum
CHLORINE (STABILIZED)	1.0 to 3.0 ppm
CHLORINE STABILIZER (Cyanuric Acid)	60 to 80 ppm


# PROBLEM SOLVING LIST

	LOW WATER FLOW	SHORT FILTER CYCLES	POOL WATER WON'T CLEAR UP
REMEDY	Check skimmer and pump strainer baskets for debris.	Check for algae in pool and super-chlorinate as required.	<ol> <li>Check chlorine, pH and total alkalinity levels and adjust as required.</li> </ol>
	Check for restrictions in intake and discharge lines.	<ol> <li>Be sure chlorine and pH levels are in proper range (adjust as required).</li> </ol>	Be sure flow rate through filter is sufficient.
	3. Check for air leak in intake line (indicated by bubbles returning to pool).	(03,101.00.00,100,100,100,100,100,100,100,1	Operate filter for longer periods.
	4. Clean Filter Cartridges, (see Page 6)		





Item	Part No.	Description
1	ECX2712B1	Pressure Gauge
2	DEX2420Z8A	O-Ring Kit (Set of 2)
3	CCX1000N	Air Relief Valve Nut
4	CCX1000V	Manual Air Relief w/O-Ring
5	DE2420MAR2	Manual Air Relief Assembly
6a	DEX2420BT	Upper Filter Body C2025
6b	DEX3620BT	Upper Filter Body C3025
6c	DEX4820BT	Upper Filter Body C4025
6d	DEX6020BT	Upper Filter Body C5025
6e	DEX7220BT	Upper Filter Body C7000
7	DEX7220B1	Clamp Bolt & Nut
/	DEAZ4Z1JZ	
8	DEX2421JKIT	Clamp System including: Clamp, Clamp Nut and Bolt, Hang tag, Metal Reinforced Seal, and Labels
9	DEX2422Z2	Metal Reinforced Seal
10a	CX2020DA	Top Closure Plate C2025
10b	CX3020DA	Top Closure Plate C3025,C4025
10c	CX5020DA	Top Closure Plate C5025
10d	CX3020D4	Top Closure Plate C7000 Series
11a	CX800Z4	Air Relief Tube Assy C2025
11b	CX3000Z3	Air Relief Tube Assy C3025
11c	CX4000Z3	Air Relief Tube Assy C4025
11d	CX5000Z3	Air Relief Tube Assy C5025
11e	CX7000Z3	Air Relief Tube Assy C7000
12a	CX480XRE	Cartridge Element C2025 4 Required
12b	CX580XRE	Cartridge Element C3025 4 Required
12c	CX880XRE	Cartridge Element C4025 4 Required
12d	CX875RE	Cartridge Element C4520 Series 4 Required
12e	CX1280XRE	Cartridge Element C5025 4 Required
12f	CX1380RE	Cartridge Element C5520 Series 4 Required
12g	CX590XRE	Cartridge Element C7000 Series 8 Required
-	CX7020M	Mid plate Connector C7000 only
13	CX3000F1	Inlet Elbow
14	CX3020FB	Outlet Elbow
15	DEX360M	O-Ring
16	CX3000C	Bottom Collector Manifold
17	DEX2420AT	Lower Filter Body
18	SP1022C	1 1/2" Drain Plug w/O-Ring
19	DEX2420DCKIT	Strap kit (Optional)
20	SX220Z2	O-ring
21	DEX2420F	Bulkhead Fitting
22	DE2400PAK2CS	Cartridge Filter Plumbing Kit
		Label Pack: Includes all
23	DEX2420LA6PAK	Warning and Operation Label's Hang Tag, Wire Tie and Owner's Manual
24	DEX2420LA6PAK	Complete as listed above
25	DEX2420LA6PAK	Complete as listed above





# HAYWARD® LIMITED WARRANTY

To Buyer, as original purchaser of this equipment, Hayward Pool Products, 620 Division Street, Elizabeth, New Jersey, warrants its products free from defects in materials and workmanship for a period of **ONE** (1) year from the date of purchase.

Parts which fail or become defective during the warranty period, except as a result of freezing, negligence, improper installation, use, or care, shall be repaired or replaced, at our option, without charge, within 90 days of the receipt of defective product, barring unforeseen delays.

To obtain warranty replacements or repair, defective components or parts should be returned, transportation paid, to the place of purchase, or to the nearest authorized Hayward service center. For further Hayward dealer or service center information, contact Hayward customer service department. No returns may be made directly to the factory without the express written authorization of Hayward Pool Products.

To original purchasers of this equipment, Hayward Pool Products warrants its products to be free from defects in materials and workmanship for a period of **ONE** (1) year from the date of purchase.

Filters which become defective during the warranty period, except as a result of freezing, negligence, improper installation, use or care, shall be repaired or replaced, at our option, without charge.

All other conditions and terms of the standard warranty apply.

Hayward shall not be responsible for cartage, removal and/or reinstallation labor or any other such costs incurred in obtaining warranty replacements.

The Hayward Pool Products warranty does not apply to components manufactured by others. For such products, the warranty established by the respective manufacturer will apply.

Some states do not allow a limitation on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

\*Supersedes all previous publications.

Hayward Pool Products 620 Division Street Elizabeth, NJ 07207



PRODUCT REGISTRATION (R	Retain For Your Records)
DATE OF INSTALLATION	
INITIAL PRESSURE GAUGE READIN	NG (CLEAN FILTER)
PUMP MODEL	HORSEPOWER
FILTER MODEL	SERIAL NUMBER
▲Retain this Warranty Certificate in a safe and con	evenient location for your records
	ys of purchase/installation.
r Fill out bottom portion completely and mail within 10 day	ys of purchase/installation
T Fill out bottom portion completely and mail within 10 day  HAYWARD  Mail to: Hay  Please F	vs of purchase/installation.
T Fill out bottom portion completely and mail within 10 day  HAYWARD   Mail to: Hay  Please F	vs of purchase/installation.
T Fill out bottom portion completely and mail within 10 day  HAYWARD  Mail to: Hay Please F	ward Pool Products, 620 Division Street, Elizabeth, NJ 07207, Attn: Warranty Dept.  Print Clearly: Warranty Registration Cal  Purchased Date:  Purchased from:  Company name
T Fill out bottom portion completely and mail within 10 day  HAYWARD   Mail to: Hay  Please F	ward Pool Products, 620 Division Street, Elizabeth, NJ 07207, Attn: Warranty Dept.  Print Clearly: Warranty Registration Cal  Purchased Date:  Purchased from:  Company name  Address
T Fill out bottom portion completely and mail within 10 day  HAYWARD  Mail to: Hay Please F	ward Pool Products, 620 Division Street, Elizabeth, NJ 07207, Attn: Warranty Dept.  Print Clearly: Warranty Registration Cal  Purchased Date:  Purchased from:  Company name  Address  City  State  Zip
T Fill out bottom portion completely and mail within 10 day  HAYWARD  Mail to: Hay  Please F  State Zip  il Address	ward Pool Products, 620 Division Street, Elizabeth, NJ 07207, Attn: Warranty Dept.  Print Clearly: Warranty Registration Cal  Purchased Date:  Purchased from:  Company name  Address  City  State  Zip
T Fill out bottom portion completely and mail within 10 day  HAYWARD  Mail to: Hay  Please F  State Zip  It Address  It Purchased	ward Pool Products, 620 Division Street, Elizabeth, NJ 07207, Attn: Warranty Dept.  Print Clearly: Warranty Registration Cal  Purchased Date:  Purchased from:  Company name  Address  City  State  Zip
AAYWARD  Mail to: Hay Please F  State Zip  It Address  It Purchased  It Serial No.	ward Pool Products, 620 Division Street, Elizabeth, NJ 07207, Attn: Warranty Dept.  Print Clearly: Warranty Registration Cal  Purchased Date:  Purchased from:  Company name  Address  City  State  Please send me more information on these other
AAYWARD  Mail to: Hay Please P  State Zip  Ict Purchased  Ict Serial No.  Replacement	Purchased Date:  Company name  Address  City  Please send me more information on these other products from Hayward:

AYWARD Pool Products A Hayward Industries, Inc. Company

# **USE ONLY HAYWARD GENUINE REPLACEMENT PARTS**

Pomona, CA Clemmons, NC Nashville, TN West Palm Beach, FL www.haywardpool.com

North Kingstown, RI Oakville, ON, Canada

St. Vulbas, France Wuxi, China