5G Core Ops Guide

4 SMF

4.2 Restarting SMF pods

Restart SMF pods one at a time and wait for readiness before continuing to the next pod.

```
        interface ge-0/0/1
            unit 0
                family inet address 10.0.0.1/24
```

Node	IP	Port
smf-1	10.0.0.1	8805
smf-2	10.0.0.2	8805

5 UPF

The UPF restart procedure drains user plane sessions gracefully before the upgrade starts.