Front view   Back view

Joystick 1 for moving the robot

On switch

Off switch

Joystick 2 for turning the robot

Batteries

Command Button 1

Command Button 2

Hand grips

Audio Button 1

Audio Button 2