



ColourSpace Secondary Execution Protocol

When ColourSpace is installed an example .bat Batch File is also installed in the installation folder, as well as within the download .zip file that contains this document.

The Batch File can be used to demonstrate the use of the new Secondary Execution capability of ColourSpace.

```
@rem /*******
@rem /**
@rem /**      Copyright (c) Light Illusion Ltd. 2020
@rem /**
@rem /**      All rights reserved Used under authorization. This material contains the
@rem /**      confidential and proprietary information of Light Illusion Ltd
@rem /**      and may not be copied in whole or in part without the express written
@rem /**      permission of Light Illusion Ltd.
@rem /**      This copyright notice does not imply publication.
@rem /**
@rem /*******

@echo off

set fileName="%\Users\%USERNAME%\Desktop\csMeasurmentLogFile.txt"

set /a counter=1
:ARGLBEG
if "%1"==" " goto ARGLEND
set ag%counter%=%1
goto ARGNEXT

:ARGNEXT
shift
set /a counter=%counter%+1
goto ARGLBEG

:ARGLEND
echo %ag1% %ag2% %ag3% %ag4% %ag5% %ag6% %ag7% %ag8% %ag9% %ag10% %ag11% %ag12%
%ag13% %ag14% %ag15% %ag16% %ag17% %ag18% %ag19% %ag20% %ag21% %ag22% %ag23%
%ag24% >> %fileName%
goto end

:end
```



To use the Batch File first copy it onto your Desktop.

In the ColourSpace Options menu, navigate to the .bat file on the desktop, and activate Secondary Execution.

Do a few measurements, or run a Quick Profile or Characterisation.

A log file called 'IsMeasurementLogFile.txt', will be generated, located on the desktop.

During measurement, Secondary Execution will append a line of data for every measurement made by ColourSpace.

The values in the .txt file should be self-explanatory.

Each one corresponds to a specific parameter passed from ColourSpace.

It should be simple to extend this .bat file to do whatever actual process is needed, or a .exe could be called if desired, for specific data processing.

The following is an example line from the log file:

```
RGB 1.000000 1.000000 1.000000 XYZact 148.636274 160.183947  
172.448753 XYZidl 95.050547 100.000000 108.896869 de76 20.334291  
de20 12.075840 deICtCp 34.648375 minLum 0.100000 maxLum 100.000000  
std Rec709
```

There are 24 separate parameters passed to the program selected for secondary execution. All 24 are displayed above.

Note: It is important to remember that any dE or target values reported from ColourSpace during continuous measurement will not be accurate unless the Minimum and Maximum luminance values are set correctly in the Options page before measurements are taken. This is no different to when using the interactive measurement tools within ColourSpace.



- 1 RGBpre text label
- 2 Normalised R value before any active LUT
- 3 Normalised G value before any active LUT
- 4 Normalised B value before any active LUT
- 5 XYZact text label
- 6 Actual CIE X value read by the probe, NITs
- 7 Actual CIE Y value read by the probe, NITs
- 8 Actual CIE Z value read by the probe, NITs
- 9 RGBpst text label
- 10 Normalised R value after any active LUT
- 11 Normalised G value after any active LUT
- 12 Normalised B value after any active LUT
- 13 XYZidl text label
- 14 Ideal CIE X value calculated from min, max luminance and the current selected standard, NITs
- 15 Ideal CIE Y value calculated from min, max luminance and the current selected standard, NITs
- 16 Ideal CIE Z value calculated from min, max luminance and the current selected standard, NITs
- 17 dE76 text label
- 18 DeltaE 1976 value
- 19 dE20 text label
- 20 DeltaE 2000 value
- 21 dEIcTp text label
- 22 DeltaE ICtCp value
- 23 minLum text label
- 24 Minimum luminance NITs
- 25 maxLum text label
- 26 Maximum luminance NITs
- 27 std text label
- 28 Name of the current selected text label