SkyHawk Pro

User Manual

Model SH-P4K | Firmware 2.1 | 4K camera, 3-axis gimbal, 28-minute flight time

1. Product overview

SkyHawk Pro is a foldable consumer drone with a 4K camera and a 3-axis gimbal. It uses GPS and GLONASS for stable hovering and automatic return to home. The aircraft weighs 249 grams, flies for up to 28 minutes, and has a control range of up to 8 kilometres in open areas.

Key specifications

Weight: 249 g

Max flight time: 28 minutes

Max speed: 16 m/s in Sport mode

Max control range: 8 km

Camera: 12 MP photos, 4K video at 30 or 60 fps

Battery: 3500 mAh, about 90 minutes to charge

Operating temperature: 0 to 40 C

The aircraft is not waterproof. Do not fly in rain or snow.

2. Box contents

SkyHawk Pro aircraft x1

Controller x1

Intelligent flight battery x1

Charger and USB-C cable x1

Spare propellers x4

Gimbal cover x1

Quick start guide x1

3. Charging and battery care

Charge the battery with the included charger or a 5V/3A USB-C adapter. A full charge takes about 90 minutes. The battery LED is solid green when full, blinks green while charging, and turns red when the charge is low.

Do not charge a battery that is still warm. Wait at least 30 minutes after a flight. Do not discharge the battery below 10 percent. If you will not fly for more than 10 days, store the battery at 40 to 60 percent charge. Replace the battery after 200 charge cycles, or sooner if it swells or shows damage.

4. Pre-flight checklist

- Remove the gimbal cover before powering on.
- Check that all four propellers are tight and undamaged.
- Charge the battery to at least 30 percent.
- Power on the aircraft and wait for a GPS lock. The status light turns green.
- Calibrate the compass if the app asks you to.
- Update the firmware before the first flight.
- Check the no-fly zone map for your area.
- Confirm that the home point is recorded in the app.

5. Controller setup and pairing

Power on the aircraft first, then the controller. Hold the pairing button on the controller for 3 seconds. The controller LED turns solid green when pairing is complete. The controller battery lasts about 6 hours and charges over USB-C. The phone mount fits phones up to 7 inches wide.

6. Flight modes

Normal mode

Normal is the default mode. Top speed is 10 m/s and obstacle avoidance is on. Use this mode for everyday flying and for learning the controls.

Sport mode

Sport mode raises the top speed to 16 m/s and turns obstacle avoidance off. Flight time is shorter and the aircraft needs more space to stop.

Cine mode

Cine mode keeps movements slow and smooth. Use it for stable video shots.

Return to Home

Press the RTH button, or hold the landing button, to start Return to Home. The aircraft climbs to 30 m, flies back to the home point at 10 m/s, and lands. Press RTH again to cancel. Low battery RTH starts automatically at 15 percent battery.

Follow Me and Circle

Follow Me keeps the aircraft at a set distance from the controller. Circle makes the aircraft fly around a point of interest at a set radius. Both modes need a strong GPS signal.

7. Camera and gimbal

The camera has a 1/2.3-inch sensor and takes 12 MP photos. It records 4K video at 30 or 60 fps, and 1080p at 120 fps for slow motion. The 3-axis gimbal keeps the camera steady. Do not move the gimbal by hand.

Tap the screen to focus. Use the dial to tilt the camera from -90 to 0 degrees. Use a microSD card up to 256 GB, UHS-I Speed Class 3 or faster. Format the card in the app before the first use.

8. SkyHawk Go app

The SkyHawk Go app is available for iOS 13 and later and Android 8 and later. Connect your phone to the aircraft Wi-Fi, then open the app. Use the app for live view, firmware updates, flight logs, and no-fly zone maps. Flight logs stay on the phone for 30 days.

9. Maintenance

Clean the lens with a microfiber cloth. Do not use solvents.

Inspect the propellers before every flight. Replace any propeller with cracks or chips.

Clean the vents with a soft brush every 10 flights.

Keep the aircraft dry. It is not waterproof.

Store the aircraft in the case at room temperature.

10. Troubleshooting

The drone will not take off

Check for a GPS lock, a battery level above 30 percent, undamaged propellers, and the current firmware version. The aircraft also refuses to take off inside a no-fly zone.

Weak GPS signal

Move to an open area away from tall buildings, then recalibrate the compass.

Video lag or stutter

Lower the video resolution to 1080p, close other apps on the phone, and keep the aircraft within 2 km.

Battery overheating

Land, power off, and let the battery cool for 30 minutes. Do not charge a hot battery.

Lost connection

If the signal is lost for 10 seconds, the aircraft returns home automatically. Do not turn off the controller while it is returning.

Compass error

Recalibrate the compass away from metal objects, cars, and power lines.

Gimbal stuck

Remove the gimbal cover and restart the aircraft. Do not force the gimbal by hand.

11. Safety and regulations

Register the aircraft if your local authority requires it.

Keep the aircraft within visual line of sight at all times.

Do not fly above 120 m or near airports, hospitals, or crowds.

Do not fly in rain, snow, or winds above 10 m/s.

Keep at least 30 m away from people and animals.

The minimum age for operation is 16.

Fly only in daylight.

12. Warranty and support

SkyHawk Pro comes with a 12-month limited warranty from the purchase date. The warranty covers manufacturing defects. It does not cover crash damage, water damage, or repairs by unauthorized service centres.

The serial number is inside the battery compartment. For help, contact support@company.com or visit support.skyhawk.com. Include the serial number and a short description of the issue.

This document is a sample created for a demo. It is not legal or safety advice.