Hydraulic Press HP-200 Maintenance Manual, Revision B.

Daily inspection: Check the hydraulic oil level in the reservoir sight glass before the first shift. Inspect hoses and fittings for leaks. Verify that the emergency stop button functions.

Lubrication and filters: Replace the hydraulic oil filter every 500 operating hours. Use ISO VG 46 hydraulic oil only. Drain and replace the reservoir oil every 2000 operating hours. Normal operating pressure is 180 bar; never exceed 210 bar.