Hydraulic Press HP-200 Safety Supplement, Revision A.

Lockout procedure: Before servicing, switch off and lock the main electrical isolator, release stored hydraulic pressure using the relief valve, and attach a personal lockout tag.