RK3308 语音模块 32 位系统编译指南

发布版本:1.40

日期:2018.08

免责声明

本文档按"现状"提供,福州瑞芯微电子股份有限公司("本公司",下同)不对本文档的任何陈述、信息和内容的准确性、可靠性、完整性、适销性、特定目的性和非侵权性提供任何明示或暗示的声明或保证。本文档仅作为使用指导的参考。

由于产品版本升级或其他原因,本文档将可能在未经任何通知的情况下,不定期进行更新或修改。

商标声明

"Rockchip"、"瑞芯微"、"瑞芯"均为本公司的注册商标,归本公司所有。 本文档可能提及的其他所有注册商标或商标,由其各自拥有者所有。

版权所有 © 2018 福州瑞芯微电子股份有限公司

超越合理使用范畴,非经本公司书面许可,任何单位和个人不得擅自摘抄、复制本文档内容的部分或全部,并不得以任何形式传播。

福州瑞芯微电子股份有限公司

Fuzhou Rockchip Electronics Co., Ltd.

地址: 福建省福州市铜盘路软件园 A 区 18 号

网址:www.rock-chips.com客户服务电话:+86-591-83991906客户服务传真:+86-591-83951833客户服务邮箱:www.rock-chips.com

前言

概述

本文主要针对 RK3308 linux 系统编译做全变讲述

产品版本

芯片名称	内核版本
RK3308	4.4

读者对象

本文档(本指南)主要适用于以下工程师:

- 技术支持工程师
- 软件开发工程师

修订记录

日期	版本	作者	修改说明
2018.7.14	1.10	sch	初始版本
2018.7.27	1.20	zyz	修改文档中说明不清楚的地方
2018.8.1	1.30	sch	强调使用 RTL8723DS 修改相关
			DTS
2018.8.24	1.40	sch	增加 WIFI DTS 配置说明,增加蓝牙
			编译说明

<u>目录</u>

2
2
2
3
3
4
4
4
5
6
7
7

1 32 位系统一键编译

32bit 默认配置存放在 device/rockchip/rk3308/BoardConfig_32bit.mk 使用下列命令切换为 32bit 配置:

cp device/rockchip/rk3308/BoardConfig_32bit.mk device/rockchip/rk3308/BoardConfig.mk

以上配置已经 32bit 系统完成了默认配置,在根目录使用以下下列命令,就可以启动编译: ./build.sh

2 配置

如果一键编译之前,需要更改配置,请先按照如下方式进行操作,然后再进行编译。

2.1 Rootfs 配置

在根目录下,执行命令:

source buildroot/build/envsetup.sh

```
You're building on Linux
Lunch menu...pick a combo:

    rockchip_rk3308_release

    rockchip_rk3308_32_release
    rockchip_rk3308_32_debug

rockchip_rk3308_robot_release

    rockchip_rk3308_mini_release
    rockchip_rk3308_32_mini_release

7. rockchip_rk3308_pcba
rockchip_rk3308_recovery
rockchip_rk3326
rockchip_rk3326_recovery
rockchip_rk3326_rebot_release
rockchip_rk3326_nano
rockchip_rk3326_audio
rockchip_rk3399
15. rockchip_rk3399_recovery
rockchip_rk3288
rockchip_rk3288_recovery
rockchip_px30
rockchip_px30_recovery
rockchip_px3se
21. rockchip_px3se_recovery
22. rockchip_rk3328
23. rockchip_rk3328_recovery
Which would you like? [1]
```

选择需要的目标,例如:

输入 3: 选择 "rockchip_rk3308_32_debug"

执行 menconfig 命令,打开菜单配置选项,根据需求进行选项配置:

make menuconfig

配置完成后保存配置文件:

make savedefconfig

2.2 Kernel 配置

进入 Kernel 目录下:

cd kernel

执行命令,配置 rk3308 defconfig:

make ARCH=arm rk3308 linux aarch32 debug defconfig

执行 menconfig 命令,打开菜单配置选项,根据需求进行选项配置:

make ARCH=arm menuconfig

配置完成后保存配置文件:

make ARCH=arm savedefconfig

备份保存修改的配置选项:

cp defconfig arch/arm/configs/rk3308_linux_aarch32_debug_defconfig

Kernel 32 位 指定 DTS 单独编译的方法:

make ARCH=arm rk3308-voice-module-board-v10-aarch32.img -j20

单独编译后, 目录下的 zboot.img 替换固件中的 boot.img 即可。

3 BoardConfig.mk 配置说明

Uboot defconfig

UBOOT_DEFCONFIG=evb-aarch32-rk3308

Kernel defconfig(2选1)

KERNEL_DEFCONFIG=rk3308_linux_aarch32_debug_defconfig(支持 ADB、及一些调试选项)

KERNEL_DEFCONFIG=rk3308_linux_aarch32_defconfig (不支持 ADB,编译的配置最简)

Kernel dts (3 选 1)

KERNEL_DTS=rk3308-voice-module-board-v10-aarch32(核心板)

KERNEL DTS=rk3308-voice-module-amic-mainboard-v10-aarch32.dts(底板+ 核心板 + AMIC 线麦板)

KERNEL_DTS=rk3308-voice-module-pdm-mainboard-v10-aarch32.dts(底板+ 核心板 + PDM 线麦板)

Buildroot config

CFG_BUILDROOT=rockchip_rk3308_32_release

Recovery config

CFG_RECOVERY=rockchip_rk3308_recovery

Pcba config

CFG_PCBA=rockchip_rk3308_pcba

#OEM config (3选 1)

OEM_PATH=oem (最小系统的 OEM 如果有 WIFI 信息,开机将自动连上 WIFI)

OEM_PATH=dueros (dueros)

OEM_PATH=aispeech-2mic-32bit (32 位思必驰 2MIC)

4 WIFI 模组配置

4.1 Kernel 配置

参考 2.2 Kernel 配置方法,打开配置菜单,参照以下方式配置:

```
שבמו נוו
 Symbol: WL_ROCKCHIP [=y]
 Type : boolean
Prompt: Rockchip Wireless LAN support
   Location:
     -> Device Drivers
        -> Network device support (NETDEVICES [=y])
   .) -> Wireless LAN (WLAN [=y])

Defined at drivers/net/wireless/rockchip_wlan/Kconfig:2

Depends on: NETDEVICES [=y] && WLAN [=y]

Selects: WIRELESS_EXT [=y] && WEXT_PRIV [=y] && CFG80211 [=y] && MAC80211 [=y]
1) 核心板 WIFI RTL8189FS 配置如下:
     --- Rockchip Wireless LAN support
     [ *]
             build wifi ko modules
            Wifi load driver when kernel bootup
             ap6xxx wireless sdio cards support
     < >
     < >
[ ]
               Cypress wireless sdio cards support
             Realtek Wireless Device Driver Support
            Realtek 8189F SDIO WiFi
             Realtek 8723B SDIO or
                                        SPI WiFi
     < >
             Realtek 8723C SDIO or SPI WiFi
     < >
            Realtek 8723D SDIO or SPI WiFi
     < >
            Marvell 88W8977 SDIO WiFi
2) 底板 WIFI RTL8723DS 配置如下:
     --- Rockchip Wireless LAN support

[ ] build wifi ko modules

[*] Wifi load driver when kernel bootup
             ap6xxx wireless sdio cards support
      < >
     < >
[ ]
               Cypress wireless sdio cards support
             Realtek Wireless Device Driver Support
             Realtek 8189F SDIO WiFi
             Realtek 8723B SDIO or SPI WiFi
      < >
             Realtek 8723C SDIO or SPI WiFi
             Realtek 8723D SDIO or SPI WiFi
             Marvell 88w8977 SDIO WiFi
```

4.2 Rootfs 配置

参考 2.1 rootfs 配置方法,打开配置菜单,按照以下方式配置:

```
Symbol: BR2_PACKAGE_RKWIFIBT [=n]
Type : boolean
Prompt: rkwifibt
  Location:
    -> Target packages
(1)    -> rockchip BSP packages (BR2_PACKAGE_ROCKCHIP [=n])
  Defined at package/rockchip/rkwifibt/Config.in:1
  Depends on: BR2_PACKAGE_ROCKCHIP [=n]
```

1) 核心板 WIFI RTL8189FS 配置如下:

```
--- rkwifibt
wifi chip support (RTL8189FS) --->
(ttyS4) bt uart (NEW)
```

2) 底板 WIFI RTL8723DS 配置如下:

```
--- rkwifibt
wifi chip support (RTL8723DS) --->
(ttyS4) bt uart (NEW)
```

4.3 DTS 的配置

RTL8189FS DTS 配置在

kernel/arch/arm/boot/dts/rk3308-voice-module-board-v10-aarch32.dts 中, 如下图:

```
mireless-wlan {
    compatible = "wlan-platdata";
    rockchip,grf = <&grf>;
    rockchip,grf = <default";
    pinctrl-names = "default";
    pinctrl-0 = <&wifi_wake_host>;
    wifi_chip_type = "rtl8189fs";
    wifi_host_wake_irq = <&gpio0_RK_PAO_GPIO_ACTIVE_LOW>;
    status = "okay";
};
```

RTI 8723DS DTS 配置在

kernel/arch/arm/boot/dts/rk3308-voice-module-mainboard-v10-aarch32.dtsi 中,如下图:

```
wireless-wlan {
    compatible = "wlan-platdata";
    rockchip,grf = <&grf>;
    clocks = <&cru SCLK_WIFI>;
    clock-names = "clk_wifi";
    ref-clock-frequency = <24000000>;
    pinctrl-names = "default";
    pinctrl-0 = <&wifi_wake_host>;
    wifi_chip_type = "rtl8723ds";
    wIFI,host_wake_irq = <&gpio0_RK_PAO_GPIO_ACTIVE_LOW>;
    status = "okay";
};
```

RTL8723DS WIFI 模组使用 24M 的晶振,因此 RTL8723DS 可以不用独立晶振,但必须打开 DTS 以下配置信息:

```
clocks = <&cru SCLK_WIFI>;
clock-names = "clk_wifi";
ref-clock-frequency = <24000000>;
pipctpl pames = "default";
```

5 编译 32 位 aispeech-2mic

编译 32 位思必驰-mic,不需要配置 rootfs,只需要将

device/rockchip/rk3308/BoardConfig_32bit.mk 中的 OEM_PATH 改为 aispeech-2mic-32bit 即可,如下:

#!/bin/bash #============== # Compile Config # Target arch ARCH=arm # Uboot defconfig UBOOT_DEFCONFIG=evb-aarch32-rk3308 # Kernel defconfig KERNEL_DEFCONFIG=rk3308_linux_aarch32_debug_defconfig # Kernel dts KERNEL DTS=rk3308-voice-module-board-v10-aarch32 # Buildroot config CFG_BUILDROOT=rockchip_rk3308_32_release # Recovery config CFG_RECOVERY=rockchip_rk3308_recovery # Pcba config CFG_PCBA=rockchip_rk3308_pcba # Build jobs JOBS=12 # Platform Target #============== TARGET_PRODUCT=rk3308 # Set rootfs type, see buildroot. # ext4 squashfs ROOTFS_TYPE=squashfs # Set data partition type. # ext2 squashfs OEM_PARTITION_TYPE=ext2

Set flash type.

support <emmc, nand, spi_nand, spi_nor>

FLASH_TYPE=nand

#OEM config: /oem/dueros/aispeech/iflytekSDK/CaeDemo_VAD

OEM_PATH=aispeech-2mic-32bit

MIC_NUM=6

6 编译 32 位 dueros-6mic

编译 32位 dueros-6mic, 首先需要进行 rootfs 配置, 选择 dueros client sdk, 再配置 BoardConfig.mk 文件,将 OEM_PATH 配置修改改为 dueros。

6.1 dueros rootfs 配置

```
参考 2.1 rootfs 配置方法,打开配置菜单,按照以下方式配置:
```

6.2 BoardConfig.mk 配置

将 OEM_PATH 改为 dueros, 以下是配置

```
#!/bin/bash
# Compile Config
#================
# Target arch
ARCH=arm
# Uboot defconfig
UBOOT_DEFCONFIG=evb-aarch32-rk3308
# Kernel defconfig
KERNEL_DEFCONFIG=rk3308_linux_aarch32_debug_defconfig
# Kernel dts
KERNEL DTS=rk3308-voice-module-board-v10-aarch32
# Buildroot config
CFG_BUILDROOT=rockchip_rk3308_32_release
# Recovery config
CFG RECOVERY=rockchip rk3308 recovery
# Pcba config
CFG_PCBA=rockchip_rk3308_pcba
# Build jobs
JOBS=12
#================
```

Platform Target

TARGET_PRODUCT=rk3308

Set rootfs type, see buildroot.

ext4 squashfs

ROOTFS_TYPE=squashfs

Set data partition type.

ext2 squashfs

OEM_PARTITION_TYPE=ext2

Set flash type.

support <emmc, nand, spi_nand, spi_nor>

FLASH_TYPE=nand

#OEM config: /oem/dueros/aispeech/iflytekSDK/CaeDemo_VAD

OEM_PATH=dueros

MIC_NUM=6

7 蓝牙编译及其测试

蓝牙使用 RTL8723DS, 详细配置请参考 RK3308_RTL8723DS_WIFI_BT_说明文档.pdf

8 BLE 蓝牙配网

RTL8723DS 使用 bluez 其启动脚本在 usr/bin/bluez5_utils_wifi_config.sh, 使用命令

/usr/bin/bluez5_utils_wifi_config.sh start 启动后,可以通过相关 APP 去配网。