ESP32 LIBRARY — USER MANUAL

DualSense32 Manual

DualSense PS5 **DualShock 4** PS4

A library for using a PlayStation controller from an ESP32. The name says DualSense, but **a DualShock 4 (PS4) works just as well** — either pad, on any of the three links described below. Buttons, sticks, touchpad and gyro all read back, and the light bar colour, rumble and, on a DualSense, the adaptive triggers (the resistance in the trigger pull) all go out. This document walks through everything **from unzipping the release** to the first sketch running and your own code taking over.

Version 1.7.0 Arduino ESP32 core 3.3.11 PolyForm Noncommercial 1.0.0

01

Choosing a link

There are three ways to reach the pad. **Your board decides which.**

1_Dongle

ESP32-S3 / S2

A Bluetooth dongle in the USB port becomes the radio, separate from the ESP32's own WiFi.

Needs: a standard HCI dongle (USB class `E0/01/01`) + a USB-C to USB-A adapter

2_USBDirect

ESP32-S3 / S2

The pad connects straight over a cable. No pairing.

Needs: a USB-C cable (C to C)

3_BTClassic

original ESP32 only

Wireless over the board's own Bluetooth radio. Nothing extra to buy.

Needs: nothing




Figure 1-1 — the board you have decides the route

WHY THE S3 HAS NO RADIO FOR THIS

The ESP32-S3 / C3 / C6 / H2 **have no Bluetooth Classic radio** (BLE only), and both pads speak Bluetooth Classic. So wireless on an S3 means an external dongle. The original ESP32 is the other way round: it has Classic, but no USB host, so a dongle is not an option there.

Which controller

Both pads work on all three links. The route is chosen by your board, not by which controller you own.

A DualShock 4 is the smaller instrument. It has no adaptive triggers, no microphone and no mute button, and no player LEDs. What it has instead is a **light bar it can blink by itself**, and a touchpad that is shorter than the DualSense's. The full list is in 6-8, and how a sketch says which pad it was written for is in chapter 5.

Nothing in this manual needs reading twice for the second pad. Where a difference exists it is called out where that feature is explained.

What has been checked on hardware

Worth stating plainly, because "supported" covers a lot of ground.

The DualShock 4 has been run on an **ESP32-S3**, over both the wired link and the dongle, with a **CUH-ZCT2** pad: connected, read, driven, reconnected. The accelerometer came out at 1.001 g and a resting gyro stayed within half a degree per second. Those two numbers only come out right if the DualShock 4's own offsets were used **and** the calibration was read a second time, once the pad had said which pad it was — over Bluetooth the calibration arrives before the pad is identified, so the link keeps the bytes and reads them again. `5_SelfTest > Ds4Core` passes **162 protocol assertions** on the device.

The original ESP32 route (3_BTClassic) has the code but has not been confirmed on hardware with a DualShock 4. It identifies the pad and decodes its reports the same way the other links do, and nobody has yet run it with that pad in hand. Untested rather than known broken.

02

Installing

2-1 Unzip the release

Unzipping the distributed `DualSense32-1.7.0.zip` gives you this.

```
DualSense32/              ← use it as is
├── Open the manual.html  ← in a browser
├── Manual.pdf             ← for printing
├── src/
├── examples/
├── docs/
│   ├── DualSense32-manual-en.html
│   ├── MANUAL-en.md
│   └── figures
├── library.properties
├── README.md
└── LICENSE
```

2-2 Hand it to the IDE

Without unzipping, **Sketch** > **Include Library** > **Add .ZIP Library** and handing over the ZIP as-is works too.

2-3 Or drop it straight into the library folder

Move the whole `DualSense32` folder to:

OS	PATH
Windows	`Documents\Arduino\libraries\DualSense32\`
macOS	`~/Documents/Arduino/libraries/DualSense32/`
Linux	`~/Arduino/libraries/DualSense32/`

```
Documents/Arduino/libraries/
└── DualSense32/
    ├── src/                  ← the library itself
    ├── examples/             ← the example sketches
    │   ├── 1_Dongle/
    │   ├── 2_USBDirect/
    │   ├── 3_BTClassic/
    │   ├── 4_Troubleshooting/
    │   └── 5_SelfTest/
    ├── docs/
    └── library.properties    ← this file marks the right level
```

`library.properties` **sits directly inside** `DualSense32/`. One level deeper, as in `DualSense32/DualSense32-main/library.properties`, is not recognised.

2-4 Restart the IDE and check

After restarting, open **File** > **Examples**. Success looks like `DualSense32` near the bottom of the list.

```
File
└── Examples
    └── DualSense32
        ├── 1_Dongle
        │   ├── Basics
        │   ├── DualShock4
        │   ├── ReceiveData
        │   └── SendData
        ├── 2_USBDirect
        ├── 3_BTClassic
        ├── 4_Troubleshooting
        └── 5_SelfTest
```

2-5 ESP32 board definitions

Skip this if already installed. Add this URL under **File** > **Preferences** > **Additional Board Manager URLs**, then

```
https://espressif.github.io/arduino-esp32/package_esp32_index.json
```

search for `esp32` under **Tools** > **Board** > **Boards Manager** and install it.
Developed and tested against **3.3.11**.

03

Board settings

Settings live in the **Tools** menu, and differ by link.

3-1 Original ESP32 (3_BTClassic)

ITEM	VALUE	WHY
Board	ESP32 Dev Module	
Partition Scheme	**Huge APP (3MB No OTA/1MB SPIFFS)**	**Required.** Does not fit in the default 1.25MB
Erase All Flash	depends	see 3-3

Forgetting the partition scheme fails the upload with `text section exceeds available space`.

3-2 ESP32-S3 (1_Dongle / 2_USBDirect)

ITEM	VALUE	WHY
Board	ESP32S3 Dev Module, or whatever matches your board	
Partition Scheme	the default fits	
USB CDC On Boot	**Enabled**	fixes a silent serial monitor

> IF THE SERIAL MONITOR IS COMPLETELY SILENT
>
> USB CDC is disabled by default on some boards (LOLIN S3 Mini and others). Suspect this first.

3-3 Erase All Flash — matters for any wireless link

The ESP32 remembers pairing information in flash. **This setting decides whether to erase that memory.**




Figure 3-1 — what Erase All Flash erases

THE KEY SURVIVES ON EITHER SIDE

Set it to Enabled the first time you connect, or any time it stops connecting. If only one side is holding an old key, authentication keeps failing from then on. When that happens, the sure fix is **Erase All Flash on the ESP32 and CREATE + PS on the pad** — make both sides forget. A pad **remembers exactly one host**.

3-4 What makes a dongle usable

ITEM	REQUIREMENT
USB class	`E0/01/01`. This is the mark of a standard HCI dongle
Radio	Bluetooth Classic (BR/EDR). **BLE-only will not work**
Firmware	built in. Ones that stay inert until a host driver uploads firmware are out of scope
Power / speed	bus powered, ~100 mA, full speed
Plug	USB-A, so an S3 needs an adapter

The Bluetooth 5.x / 6.0 printed on the box is irrelevant. Both pads speak Classic, so the only thing to avoid is one explicitly marked BLE-only.

DEVELOPED AGAINST

A **UGREEN Bluetooth 6.0 adapter** (EDR & BLE, Windows 11 / 10 / 8.1). Windows Device Manager calls it `BARROT Bluetooth 6.0 Adapter`. What the ESP32-S3 saw is below, and it needed no firmware upload.

```
vid:pid        33FA:0012
device class   E0/01/01
product        UGREEN BT6.0 Adapter
speed          full
configuration: 2 interfaces, 100 mA
```

That is the output of `4_Troubleshooting > WhatIsOnUSB`. Your dongle is a match if it reports something like this.

3-5 Where the dongle goes

The S3 has two USB-C ports. **The dongle goes in the native USB one.** Leave the other plugged into the PC — flashing, the serial monitor, and the dongle's own power all come through it.




Figure 3-3 — plugging in the dongle. The board pictured is a Freenove ESP32-S3-WROOM

> CAN'T TELL WHICH PORT IS NATIVE USB
>
> Flash **4_Troubleshooting** > **WhatIsOnUSB** and move the dongle between the two ports. The one that reports the dongle's own descriptors is the native USB port.

04

Running the first sketch

Open **File** > **Examples** > **DualSense32** > (**your route**) > **Basics**.

4-1 Flash it

Finish the board settings from chapter 3, then flash. **The serial monitor runs at 115200 bps.**

4-2 Connect the pad

On a wire (2_USBDirect), just plug it in. Everything from here is about wireless.

1. **Hold down CREATE**, the small button at the top left of the touchpad.
2. Press **PS** while still holding it.
3. Let go once **the light bar flashes quickly**. That is pairing mode.
4. The ESP32 finds it and connects on its own. Just wait.

> AFTER THE FIRST TIME
>
> If the ESP32 still remembers it, **the PS button alone** connects.

On a DualShock 4 that button is called SHARE, and the sequence is the same one: hold SHARE, then press PS while still holding it, and let go once the light bar flashes quickly. SHARE is the small button left of the touchpad — the same place a DualSense puts CREATE, with Sony's older name printed on it.

4-3 Did it work?

ACTION	WHAT HAPPENS
Hold ✕ down	the light bar turns red, both motors spin
Let go	back to light blue, vibration stops
Push the left stick	a line like `left stick 45,-12` appears in the serial monitor

---

05

Reading the code

This is the whole of `Basics`. **It is all of it** — every other example just adds display on top of this.

```ino
#include <DualSense32.h>

DualSense32 pad;                        // ① set it up

void setup() {
  Serial.begin(115200);
  if (!pad.begin()) Serial.println("begin failed");   // ② start it
}

void loop() {
  pad.update();                         // ③ call this every time
  if (!pad.connected()) return;

  if (pad.pressed(DS_CROSS))  Serial.println("cross down");   // ④ listen
  if (pad.released(DS_CROSS)) Serial.println("cross up");

  if (pad.down(DS_CROSS)) {
    pad.lightbar(255, 0, 0);            // ⑤ command it
    pad.rumble(120, 120);
  } else {
    pad.lightbar(0, 160, 255);
    pad.rumble(0, 0);
  }
}
```

① Set it up — this line alone decides the link

```ino
DualSense32 pad;                        // automatic: the built-in radio on an
                                        // original ESP32, a dongle on an S3/S2
DualSense32 pad(ds_link_usb_hid());     // wired (S3)  + #include <ds_link_usb_hid.h>
```

No argument is the ordinary form, and `#include <DualSense32.h>` is then the only include needed. An original ESP32 has a Bluetooth Classic radio and no USB host controller; an S3 or S2 is the other way round. Once the chip is known, there is only one way to reach a pad wirelessly, and the library takes it.

Only the cable needs saying out loud. On an S3 a dongle and a pad go into the same USB port, and nothing at compile time distinguishes them; the dongle is the default.

Naming a link explicitly always works:

```
DualSense32 pad(ds_bt_bluedroid());    // original ESP32  + #include <ds_bt_bluedroid.h>
DualSense32 pad(ds_link_usb_hci());    // dongle          + #include <ds_link_usb_hci.h>
```

The three routes differ by this one line. Nothing below it changes, not even a character.

② Start it

```
pad.begin();                       // search on its own; finds a pad in pairing mode
pad.begin("AA:BB:CC:DD:EE:FF");    // connect only to this one pad
```

`pad.begin()` alone is enough unless several pads are nearby. A mistyped address shows up immediately as `false`.

The address can be read back once connected. After pairing and connecting once,

```
char who[18];
if (pad.address(who)) Serial.println(who);   // 24:A6:FA:23:12:64
```

With `pad.printEvents(Serial)` running, the moment it connects prints one line: `link: connected 24:A6:FA:23:12:64`. Identical on all three routes.

③ Call this every time

> Forget this one line and **buttons stop responding and the light bar stops changing colour**, because talking to the controller only happens here. Nothing errors.




Figure 5-1 — everything update() does in one call

Data from the controller arrives on a **communication task running in the background**. Reading it directly gives a mix — the stick from this instant, a button from a moment ago. `update()` copies that instant, so everything read afterwards **comes from the same moment**.

④ Listen / ⑤ Command

Outputs are **just set**. There is no need to call `send()` — `update()` sends them.

Which controller — the two ways to say it

Everything above is identical on a DualSense and a DualShock 4. What is not identical is the hardware: a DualShock 4 has no adaptive triggers, no microphone and no player LEDs. A sketch has to decide what to do about that, and there are two answers. **Pick one on purpose** — they fail in completely different places.

	`DUALSENSE32` + `SUPPORTS()`	`#INCLUDE <DUALSHOCK4.H>`
decided	while it runs	when it compiles
takes	whichever pad turns up	one pad
a call the pad cannot honour	returns false, is counted, and is reported	does not build

One binary, either pad

Keep `DualSense32` — nothing changes — and ask the pad what it has.

```
if (pad.supports(DS_CAP_ADAPTIVE_TRIGGERS)) pad.triggerRight(block);
```

```
if (pad.supports(DS_CAP_PLAYER_LEDS))       pad.playerLeds(10101);
```

Ask what the sketch needs rather than which pad it is. `supports()` describes the hardware, so code written against it keeps working when a pad this library predates turns up. The full flag list is in 6-8.

The setters that touch optional hardware return `bool`, a refused call changes nothing, and the refusals are counted so they cannot pass unnoticed (7-5).

One pad, named at compile time

```
#include <DualShock4.h>
#include <ds_link_usb_hid.h>

DualShock4 pad(ds_link_usb_hid());
```

`DualShock4` is the same class with the missing hardware taken away rather than left to fail quietly. The calls that would have been refused **do not build**, and the error names the line:

```
error: use of deleted function 'bool DualShock4::triggerRight(...)'
error: use of deleted function 'bool DualShock4::micLed(uint8_t)'
error: use of deleted function 'bool DualShock4::playerLeds(...)'
```

Buttons can use the shared `DSButton` names (`DS_CROSS`, `DS_CREATE`) or the `DS4Button` aliases when you want Sony's printed names (`DS4_SHARE`). There is no `DS4_MUTE` at all, because there is no microphone and no button for one, so reaching for the mute button is not a call that answers false for ever — it is:

```
error: 'DS4_MUTE' was not declared in this scope
```

Writing `DS5_CROSS` here fails too. The shared spelling is `DS_CROSS`; using the pad-specific DualSense alias says the sketch was written against the other controller, which is worth catching while it is still cheap.

> WHY A #DEFINE CANNOT DO THIS JOB
>
> The Arduino builder compiles a library's `.cpp` files on their own, separately from the `.ino`. A macro set in the sketch never reaches them, so it cannot change what the library is. A **type** is the one thing that crosses that boundary — which is why this is a class and not a switch.

One check has to stay at run time, because **a USB port cannot be asked in advance what will be plugged into it**. So `connected()` is true only once a real DualShock 4 is on the other end, and `mismatched()` is true when a DualSense turned up instead.

```
void loop() {
  pad.update();
  if (pad.mismatched()) return;      // a DualSense turned up: wrong sketch
  if (!pad.connected()) return;

  if (pad.pressed(DS_CREATE)) Serial.println("share");
}
```

Without that check a DualSense's reports would be decoded as a DualShock 4's: no crash, no error, just a sketch that never sees a button.

06

Every input

6-1 What the buttons are called




Figure 6-1 — the controls and their names in code. L1 / L2 / R1 / R2 are on the far side

THE CONTROL	NAME IN CODE
↑ → ↓ ←	`DS_UP` `DS_RIGHT` `DS_DOWN` `DS_LEFT`
□ ✕ ○ △	`DS_SQUARE` `DS_CROSS` `DS_CIRCLE` `DS_TRIANGLE`
L1 / R1	`DS_L1` `DS_R1`
L2 / R2 pulled **all the way**	`DS_L2_CLICK` `DS_R2_CLICK`
CREATE / OPTIONS	`DS_CREATE` `DS_OPTIONS`
stick click	`DS_L3` `DS_R3`
PS / touchpad click / mute	`DS_PS` `DS_TOUCHPAD` `DS5_MUTE`

Those names are the ones to use on **either** pad while the sketch is a `DualSense32`. Write it as a `DualShock4` instead (chapter 5) and the shared `DS_*`

names still work. Use the `DS4_*` aliases only when you want the names printed on that controller:

	DUALSENSE	DUALSHOCK 4
the small button left of the touchpad	`DS_CREATE`	`DS_CREATE`
the mute button	`DS5_MUTE`	there is none, and no name for one
everything else	`DS_CROSS`, `DS_L1` ⋯	`DS_CROSS`, `DS_L1` ⋯ the same list

On a DualShock 4 read through `DualSense32`, `pad.down(DS5_MUTE)` is always false. That is not a pad holding still: there is no mute button, and the bits in that position carry a report counter, so decoding them as a button would give a mute that flickers on its own. The read is counted as a refusal (7-5).

6-2 down / pressed / released

Write `down()` where `pressed()` belongs and the code runs continuously while the button is held. **What was meant to happen once now happens hundreds of times a second.**





Figure 6-2 — the three, compared. The coloured span is true

```
// spin a motor while held → down
if (pad.down(DS_R1)) motorOn(); else motorOff();

// fire exactly once per press → pressed
if (pad.pressed(DS_R1)) fire();
```

```
// down here fires continuously while held (hundreds of times a second)
```

6-3 Sticks



Y is positive downward
to drive forward, use -pad.leftY()

drifts even with your hand off it
ignore it and a robot creeps
`pad.deadzone(8); // the default`

Figure 6-3 — stick coordinates and the deadzone

```
int x  = pad.leftX();    // -128..127, 0 in the middle
int y  = pad.leftY();
int rx = pad.rightX();
int ry = pad.rightY();

pad.deadzone(8);         // within ±8 counts as 0 (the default)
pad.deadzone(0);         // disabled, if you want the raw value
```

6-4 Triggers

L2 / R2 give **two** readings: how far in it is pressed, and whether it has been pulled all the way.

```
uint8_t r    = pad.r2();                 // 0..255, analogue
bool clicked = pad.down(DS_R2_CLICK);    // pulled all the way

analogWrite(motorPin, pad.r2());         // the throttle itself
```

A DualShock 4 reads exactly the same way. Its triggers are springs, so what it does not have is the resistance on the way in (7-3).

6-5 Touchpad

Read from `raw()`. **Up to two fingers** are tracked at once.




Figure 6-4 — the touchpad coordinate system

```
const ds_state_t &s = pad.raw();

if (s.has_touch && s.touch[0].active) {
  Serial.printf("finger 1  %u,%u (id %u)\n",
                s.touch[0].x, s.touch[0].y, s.touch[0].id);
}
```

A DualShock 4's touchpad is the same width and shorter: 1920 x 942. Same width, so x needs nothing; scale y to the pad you actually have, or a finger at the bottom edge reads as seven eighths of the way down.

`id` is **a number that increases each time a finger lands**. It stays the same while a finger drags, so `id` tells apart a continuing stroke from a finger lifted and placed again.

6-6 Gyro and accelerometer

Both come back in units you can use directly. No dividing required.

```
float dps = pad.gyroYaw();     // deg/s. gyroPitch() / gyroRoll() are the same
float g   = pad.accelZ();      // g. one axis reads about 1.0 at rest
```

When the raw number itself is what you want, there are three choices.

ACCESSOR	RETURNS	USE IT WHEN
`pad.gyroYaw()` `pad.accelZ()`	**deg/s** and **g** (float)	you want it ready to use as angular velocity or acceleration
`pad.raw().motion`	calibrated LSB values (integer)	you want to stay in integers
`pad.rawMotion()`	pre-calibration LSB values (integer)	you want to see what calibration changed

> DIVIDING BY HAND
>
> The two sensors use **different scales**. The gyro is 1024 counts per deg/s, the accelerometer 8192 counts per g. The constants are public as `DS_GYRO_LSB_PER_DPS` and `DS_ACCEL_LSB_PER_G`. Assume they match and dividing is off by a factor of sixty.

A DualShock 4 is calibrated too, from its own feature report and its own layout, and the library reads whichever the connected pad keeps. Nothing above changes on that pad.

6-7 Battery

```
uint8_t level = pad.battery();     // 0..10 (1 is roughly 10%)
bool charging = pad.charging();
```

6-8 Which pad is on the other end

```
if (pad.isDualShock4()) Serial.println("a PS4 pad");

if (pad.supports(DS_CAP_ADAPTIVE_TRIGGERS)) pad.triggerRight(block);
```

Prefer `supports()` to `isDualShock4()`. It says what the hardware can do rather than what name it goes by, so the sketch keeps working when a pad this library predates turns up. Both are only meaningful once connected; before that the answer is the DualSense set, because that is what an unidentified pad is assumed to be.

FLAG	WHAT IT IS	DUALSENSE	DUALSHOCK 4
`DS_CAP_ADAPTIVE_TRIGGERS`	L2 / R2 push back	yes	no
`DS_CAP_MIC_LED`	the lamp on the mute key	yes	no
`DS_CAP_MUTE_BUTTON`	there is a microphone to mute	yes	no
`DS_CAP_PLAYER_LEDS`	the five lamps under the touchpad	yes	no
`DS_CAP_LIGHTBAR_BLINK`	the pad blinks the light bar itself	no	yes

The light bar, rumble, both sticks, the triggers, the touchpad, motion and the battery are on both pads and need no flag.

Three more differences are not flags, because nothing can be asked about them:

	DUALSENSE	DUALSHOCK 4
touchpad	1920 x 1080	1920 x 942
the button left of the touchpad	CREATE	SHARE
blinking the light bar	your own loop does it	`lightbarBlink(on, off)` (7-4)

How it works out which pad it is

On a wire, from the USB product id. Both pads send input report `0x01` at 64 bytes, so the report itself cannot tell them apart — the product id on the descriptor can.

PRODUCT ID	PAD
`0x05C4`	DualShock 4, CUH-ZCT1
`0x09CC`	DualShock 4, CUH-ZCT2
`0x0BA0`	the DualShock 4 USB adaptor

Over Bluetooth, from the report id. There is no product id out there. `0x31` is a DualSense and `0x11` a DualShock 4. Report `0x01`, which both pads send until a feature report is asked for, identifies **nothing**, and is deliberately not used to guess: guessing there would pick a pad at random on the first frame of every

connection. Its layout is the same on both pads, so it decodes correctly anyway while the answer is still unknown.

Filling the gap — telling `begin()` what to expect

Only **output** suffers while the answer is unknown: the two pads build genuinely different output reports, so one cannot be assembled until the model is settled. `begin()` takes an expectation for that.

```
pad.begin(DS_DEVICE_DUALSHOCK4);                        // expect a DS4
pad.begin(DS_DEVICE_DUALSHOCK4, "AA:BB:CC:DD:EE:FF");   // and that one pad
```

On a `DualShock4` there is nothing to write — the type has already said it, so `pad.begin()` and `pad.begin("AA:BB:...")` expect a DualShock 4 by themselves.

> Without an expectation, output is **held** rather than built wrong: a `lightbar()` set during the gap is delivered the moment the pad names itself, a few frames later, instead of going out in the wrong dialect and being ignored.
>
> An expectation always loses to what the link works out for itself. If they disagree, `device()` says so and `DualShock4::mismatched()` reports it.

Overriding the answer — for clones

A clone, or a revision newer than this code, can have the answer **overridden** instead. Unlike an expectation, this outranks the product id.

```
ds_link_usb_hid_force_device(DS_DEVICE_DUALSHOCK4);   // before begin()
```

You should not need it. Reach for it when the log says a pad attached and every field past the sticks reads as nonsense.

07

Every output

Everything here is **just set**. `update()` sends it.

7-1 Light bar, rumble, LEDs

```
pad.lightbar(255, 0, 0);      // red
pad.lightbar(0, 160, 255);    // light blue (this library's default)
pad.lightbar(0, 0, 0);        // off

pad.rumble(left, right);      // 0..255 each. left is heavy and low, right fine and high
pad.rumble(0, 0);             // stop

pad.micLed(0);                // 0 off / 1 on / 2 blink
```

A DualShock 4 has no microphone and no lamp for one, so `micLed` returns false there (7-5).

7-2 Player LEDs

The five LEDs under the touchpad. **Write the pattern you want lit, as a number.**

```
pad.playerLeds(10101);        // ● ○ ● ○ ●
pad.playerLeds(  100);        // middle one only. Leading zeros can be dropped
pad.playerLeds(11111);        // all on
pad.playerLeds(    0);        // all off
pad.playerLeds(10101, 0);     // second argument is brightness, 0..2
```




Figure 7-1 — the digits you write become the lit pattern

> ALREADY HOLDING IT AS BITS
>
> If you already have a 5-bit mask, `pad.playerLedsMask(0b10101)` takes it directly. The rightmost LED is bit zero.

A DualShock 4 has no lamps there, so both calls return false and change nothing on that pad (7-5).

7-3 Adaptive triggers

DualSense's headline feature, and the one thing on this list a DualShock 4 cannot be talked into: its triggers are springs, so every call in this section returns false on that pad (7-5).

Build an 11-byte block and hand it over.

```
uint8_t block[DS5_TRIGGER_BLOCK_SIZE];      // 11 bytes

ds5_trigger_weapon(block, 3, 6, 8);         // a gun's trigger
pad.triggerRight(block);                    // apply it to the right trigger
```

Position runs **0 to 9**: 0 is untouched, 9 is pulled all the way in.




Figure 7-2 — the trigger's 10 zones

FUNCTION	FEEL	ARGUMENTS
`ds5_trigger_off(b)`	no resistance (reset)	—
`ds5_trigger_feedback(b, pos, force)`	heavy from that point on	pos 0-9 / force 0-8
`ds5_trigger_weapon(b, start, end, force)`	**a gun**: resists, then breaks	start 2-7 / end start+1..8 / force 0-8
`ds5_trigger_vibration(b, pos, amp, hz)`	vibrates from that point on	pos 0-9 / amp 0-8
`ds5_trigger_slope(b, start, end, force1, force2)`	ramps up gradually	force 1-8
`ds5_trigger_multi_feedback(b, force[10])`	resistance set per zone	each 0-8
`ds5_trigger_multi_vibration(b, hz, amp[10])`	vibration set per zone	each 0-8

FUNCTION	FEEL	ARGUMENTS
`ds5_trigger_bow(b, start, end, force, snap)`	**a bow**: draw and release snaps	each 1-8
`ds5_trigger_galloping(b, start, end, foot1, foot2, hz)`	**a gallop**: a two-beat rhythm	foot1 0-6 / foot2 foot1+1..7
`ds5_trigger_machine(b, start, end, ampA, ampB, hz, period)`	**an engine**: two amplitudes alternate	amp 0-7

> THE LAST THREE
>
> Bow, gallop and machine are undocumented by Sony. They come from independent reverse-engineering, and the argument ranges are "what the real hardware accepted." **To feel all of them, flash the `SendData` example.** Switch effects with the d-pad and pull L2 / R2 to compare.

7-4 Blinking the light bar — DualShock 4 only

A DualShock 4 can blink its own light bar. The pad keeps the rhythm, so a warning light costs the sketch nothing to keep going.

```
pad.lightbar(255, 0, 0);       // the colour is still set the usual way
pad.lightbarBlink(50, 50);     // half a second on, half a second off
pad.lightbarBlink(200, 1);     // reads as lit: 2 s on, 10 ms off
```

> **Never pass an off of zero.** The pad takes a new colour or a new rate only at a blink boundary, and an off of zero leaves it with no boundary to arrive at: the light bar holds what it was showing and ignores what comes after until something else disturbs it. `lightbarBlink(0, 0)` is worse — it puts the bar out. Neither is “solid”.
>
> For a steady-looking bar use a long on and an off of `1`. Measured on a DualShock 4: 10 ms of dark cannot be seen, 20 ms can, and with off at `1` a single report changes both the colour and the rate first time.

Both numbers are in units of 10 ms, so 50 is 500 ms. They are on-time and off-time, and they do not have to match.

A DualSense has no such thing and returns false here. Blinking on both pads means doing it in your own loop, with `millis()` and `lightbar()`.

7-5 Calls a pad cannot honour

Some of the hardware above is not on every pad, and the calls that reach for it **change nothing and return false** when it is absent.

CALL	ABSENT ON
`triggerLeft` `triggerRight`	DualShock 4
`micLed`	DualShock 4
`playerLeds` `playerLedsMask`	DualShock 4
`lightbarBlink`	DualSense
reading `DS5_MUTE`	DualShock 4

```
if (!pad.micLed(1)) Serial.println("no mic lamp on this pad");
```

Nothing is refused before the link is up. Until a pad has identified itself there is nothing to refuse against, so an early call is carried out against the DualSense set.

Ignoring the return is easy, and this is the one failure that leaves no trace on the wire: the field is simply absent from the report, and a report that is one field short looks exactly like a report that arrived. So the refusals are counted as well.

```
pad.refusedCount();     // how many calls have been dropped
pad.lastRefused();      // the name of the last one, or nullptr
pad.clearRefused();
```

And `printEvents()` says so, one line per call it had to drop:

```
unsupported: triggerRight — this pad is a DualShock 4
```

A line every frame means a setter being called every time round `loop()`. That is worth fixing rather than silencing: guard it with `supports()` (6-8), or write the sketch as a `DualShock4` and have the compiler say it once, at build time (chapter 5).

08

Recipes

8-1　RC car (motors from the sticks)

```
#include <DualSense32.h>
DualSense32 pad;

const int PWM_L = 25, PWM_R = 26;

void setup() {
  Serial.begin(115200);
  pinMode(PWM_L, OUTPUT);
  pinMode(PWM_R, OUTPUT);
  pad.begin();
  pad.deadzone(12);          // make sure it stops when you let go
}

void loop() {
  pad.update();

  // ★ always stop when not connected
  if (!pad.connected()) {
    analogWrite(PWM_L, 0);
    analogWrite(PWM_R, 0);
    return;
  }

  int fwd  = -pad.leftY();   // inverted: pushing up reads negative
  int turn =  pad.rightX();

  int l = constrain(fwd + turn, -128, 127);
  int r = constrain(fwd - turn, -128, 127);

  analogWrite(PWM_L, abs(l) * 2);
  analogWrite(PWM_R, abs(r) * 2);
}
```

> The last value read stays put even after the radio drops. Drive off `leftY()` alone without checking `connected()` and **the motors keep spinning at whatever speed they had the instant the link died**. Zero the outputs while not connected.

8-2　Toggling on each press

```
static bool lampOn = false;

if (pad.pressed(DS_CIRCLE)) {     // ★ pressed, not down
  lampOn = !lampOn;
  digitalWrite(LAMP, lampOn);
  pad.lightbar(lampOn ? 255 : 0, 0, 0);
}
```

8-3　Detecting a long press

```
static uint32_t heldSince = 0;
static bool fired = false;

if (pad.down(DS_OPTIONS)) {
  if (heldSince == 0) heldSince = millis();
  if (!fired && millis() - heldSince > 1000) {
    fired = true;
    Serial.println("held for 1 second");
  }
} else {
  heldSince = 0;
  fired = false;
}
```

8-4　Switching modes (colour shows the current one)

```
enum Mode { MANUAL, AUTO, MODE_COUNT };
Mode mode = MANUAL;

if (pad.pressed(DS_TRIANGLE)) {
  mode = (Mode)((mode + 1) % MODE_COUNT);
}
```

```
switch (mode) {
  case MANUAL: pad.lightbar(0, 160, 255); break;   // light blue
  case AUTO:   pad.lightbar(0, 255,   0); break;   // green
  default: break;
}
```

8-5 Just show me everything

```
pad.update();
pad.printEvents(Serial);       // one line per change
if (pad.pressed(DS_OPTIONS)) pad.printState(Serial);   // the whole state
```

Useful for checking wiring or behaviour. The `ReceiveData` example is a **hand-written version that uses neither of these**, so read that one instead when you want to know exactly which value is read how.

09

When it does not work

SYMPTOM	CAUSE	FIX
`text section exceeds available space`	default partition scheme	set **Huge APP** (original ESP32)
nothing in the serial monitor	USB CDC On Boot disabled	set it to **Enabled** (S3)
pairing mode, still no connection	the ESP32 is holding an old key	reflash with Erase All Flash, and CREATE + PS on the pad
connects, then drops immediately	the two keys disagree	same as above; make **both** sides forget
`begin failed`	wrong address format, or the radio failed to start	check it matches `"AA:BB:CC:DD:EE:FF"`
it moves with nobody touching it	deadzone too small	raise it, e.g. `pad.deadzone(12)`
one press fires dozens of times	using `down()`	switch to `pressed()` (6-2)
gyro values are off by orders of magnitude	dividing by the accelerometer's scale	use `pad.gyroYaw()`; by hand it is 1024 (6-6)

SYMPTOM	CAUSE	FIX
light bar and rumble do nothing	`update()` is not being called	`pad.update()` at the top of `loop()`
values jump or mix together	`update()` called more than once per loop, or read from another task	once per cycle, read from that same task
worked before, now connects to nothing	the pad re-paired with something else	a pad remembers **exactly one host**; pair again
the first pad still connects, a **different** one is never found	a stored bond turns the scan off on purpose	`ds_link_usb_hci_clear_bond()`, then reset — see below
the mute button never reads as pressed	a DualShock 4 has no microphone	there is nothing to read (6-1)
`micLed` / `playerLeds` / the trigger effects do nothing	the pad has no such hardware	check the return, or ask `supports()` first (7-5)
a `DualShock4` sketch runs and never sees a button	a DualSense is plugged in	`pad.mismatched()` says so (chapter 5)
everything past the sticks reads as nonsense	a clone whose product id is not in the table	`ds_link_usb_hid_force_device()` (6-8)

The bond that hides a different pad

This one deserves its own paragraph, because the symptom is indistinguishable from a controller that will not pair. The pad flashes in pairing mode, the ESP32 says nothing, and every obvious fix is aimed at the wrong thing.

Once a bond is stored, the link stops running an inquiry scan on purpose. A pad that already knows the host pages the host itself when PS is pressed, and a scan running at the same time would stop that page being answered. So the host waits instead, and waiting is the right answer — for **that** pad. A different pad, which nobody has paired yet, can only be found by the scan that is now never run.

So the old bond has to go first:

```
ds_link_usb_hci_clear_bond(pad.transport());
```

Then reset the board. `Erase All Flash Before Sketch Upload = Enabled` does the same thing with a bigger hammer, since the bond lives in NVS (3-3).

If nothing above fixes it

File > **Examples** > **DualSense32** > **4_Troubleshooting** has diagnostics.

EXAMPLE	WHAT IT SHOWS
`DongleStepByStep`	which stage the dongle's bring-up is stuck at
`WhatIsOnUSB`	what is actually on the USB port, and whether the dongle is recognised
`EventLog`	every field received, plus a consistency check on the values
`Ds4PairingInfo`	which host address a DualShock 4 is still trying to call

`Ds4PairingInfo` is for one specific silence: a DualShock 4 remembers one host and pages it when PS is pressed, so a pad calling an address that is not there lights up and does nothing, which looks exactly like a broken pad. Plug it in over USB — no pairing needed — and it prints what the pad is holding.

`5_SelfTest` is the library's own self-test. **Needs no pad and no dongle**; if everything passes, the decoding side is sound. `Ds4Core` is the DualShock 4 half of it, and the place where the two pads' report layouts are pinned apart.

10

Quick reference

Setup

```
DualSense32 pad;                        // automatic (original = radio, S3 = dongle)
DualSense32 pad(ds_link_usb_hid());     // wired (S3) is the one that must be said

pad.begin();                 // search and connect
pad.begin("AA:BB:...");      // connect to a named pad
pad.update();                // ★ every time, at the top of loop
pad.connected();             // is it connected
char who[18];
pad.address(who);            // the address of whatever is connected
```

```
pad.deadzone(8);             // stick slack
pad.sendInterval(50);        // output send interval, ms (default 50)
```

Which pad

```
pad.device();                // DS_DEVICE_DUALSENSE / DS_DEVICE_DUALSHOCK4
pad.isDualShock4();
pad.supports(DS_CAP_ADAPTIVE_TRIGGERS);   // also _MIC_LED, _PLAYER_LEDS,
                                          // _MUTE_BUTTON, _LIGHTBAR_BLINK

DualShock4 pad(ds_link_usb_hid());   // PS4 only, checked at build time
                                     // + #include <DualShock4.h>
pad.mismatched();            // DualShock4 only: a DualSense turned up

ds_link_usb_hid_force_device(DS_DEVICE_DUALSHOCK4);   // for a clone
```

Reading

```
pad.down(DS_CROSS)          // held
pad.pressed(DS_CROSS)       // the instant it went down
pad.released(DS_CROSS)      // the instant it came up
                            // DualShock4 sketches: DS_CROSS, DS_CREATE,
                            // and no DS4_MUTE at all

pad.leftX()  pad.leftY()    // -128..127 (Y is positive down)
pad.rightX() pad.rightY()
pad.l2()     pad.r2()       // 0..255

pad.battery()               // 0..10
pad.charging()

pad.raw().touch[0].x        // touchpad, 0..1919
pad.raw().touch[0].y        //           0..1079 (a DualShock 4 stops at 941)
pad.gyroPitch() / gyroYaw() / gyroRoll()    // deg/s
pad.accelX()    / accelY()  / accelZ()     // g
pad.raw().motion            // calibrated LSB values
pad.rawMotion()             // pre-calibration LSB values
```

Writing

```
pad.lightbar(r, g, b);      // 0..255 each
pad.rumble(left, right);    // 0..255 each
```

```
pad.playerLeds(10101);       // write the pattern you want lit
pad.playerLedsMask(0b10101); // if you already hold it as bits
pad.micLed(1);               // 0 off / 1 on / 2 blink
pad.lightbarBlink(50, 50);   // DualShock 4 only, units of 10 ms

uint8_t b[DS5_TRIGGER_BLOCK_SIZE];
ds5_trigger_weapon(b, 3, 6, 8);
pad.triggerLeft(b);
pad.triggerRight(b);

// all of the above return false on a pad without the hardware
pad.refusedCount();          // how many calls were dropped
pad.lastRefused();           // the name of the last one
pad.clearRefused();
```

Inspecting

```
pad.printEvents(Serial);     // only what changed
pad.printState(Serial);      // the whole state
```

DualSense32 — Copyright 2026 yuuki1998 — PolyForm Noncommercial License 1.0.0

Noncommercial use only. Personal study, hobby and research projects, and schools and other noncommercial organisations (a school robot club entering a student contest, for example) may use, modify and share it; commercial use is not covered by this licence. Include `LICENSE`, `NOTICE` and `LICENSES/Apache-2.0.txt` with any copy you pass on.

DualSense, DualShock and PlayStation are trademarks of Sony Interactive Entertainment Inc. This project is not affiliated with, authorised by, or endorsed by Sony.