

Device Alpha — User Manual

1. Overview

Device Alpha is a desktop-class IoT gateway designed for indoor industrial use. It supports up to 32 connected sensors over a single mesh and exposes a REST API on its built-in web console.

2. Operating Conditions

- **Maximum ambient temperature:** 65 °C
- **Minimum ambient temperature:** -10 °C
- **Maximum relative humidity:** 90% non-condensing
- **Power input:** 12 V DC, 2 A barrel jack

Operating Device Alpha outside these limits voids the warranty.

3. Initial Setup

1. Connect the included 12 V power adapter and wait for the power LED to turn solid green ($\approx$ 30 seconds).
2. Connect Device Alpha to your network using the Ethernet port labelled **LAN1**.
3. From a computer on the same network, browse to `http://device-alpha.local`.
4. Log in with the default credentials `admin / changeme` and complete the first-run wizard.

4. Network Configuration

To change the network configuration on Device Alpha:

1. Log in to the web console.
2. Navigate to **Settings** → **Network**.
3. Choose either **DHCP** (default) or **Static IP**.
4. If Static IP, enter the IPv4 address, subnet mask, gateway, and at least one DNS server.
5. Click **Apply**. Device Alpha will reboot to apply the change ($\sim$ 45 seconds).

The MAC address can be cloned from **Settings** → **Network** → **Advanced** if your network requires registration.

5. Factory Reset

To factory-reset Device Alpha:

1. Power the device on and wait for the power LED to be solid green.
2. Press and hold the recessed **RESET** button on the rear panel using a paperclip.
3. Continue holding for **10 seconds**, until the power LED begins to blink amber rapidly.
4. Release the button. The device will reboot twice over the next 90 seconds.
5. When the power LED returns to solid green, factory reset is complete.

After a factory reset, all configuration, logs, and paired sensors are erased. Use the first-run wizard from §3 to reconfigure.

6. Firmware Updates

Firmware updates are delivered via the web console at **Settings** → **System** → **Firmware**. Always perform a configuration backup before updating.