

Allan coin slot calibration

- 6 kinds of coin old and new
 - 1 piso old 10pcs
 - 1 piso new 10pcs
 - 5 piso old 10pcs
 - 5 piso new 10pcs
 - 10 piso old 10pcs
 - 10 piso new 10pcs

Display

E – how many sample coin to be program.

H – How many coin sample to be tested per coin program.

Example:

- H1= coin sample of old 1 piso coin
- H2= coin sample of New 1 piso coin

P = Pulse value / signal /per coin

- P1= coin value of fist coin to be program
 - Ex: p1= 1 / 1 piso rate
 - Ex: p2= 5 / 5 piso rate
 - Ex: p3= 10 / 10 piso rate

F= accuracy / sensitivity.

- Standard = 8 (base on all tutorial.)

Set up and programming

Press add (+) and minus (-) button on coin slot simultaneous for 3 sec.

The seven segment display “A” . automatically Press Set for 3 sec. or else the display “E” not appear

The seven segment display “E”

- Press add button (+) how many coin to program?
 - Add button to increase and minus button to decrease.

After " how many coin to program" done

Press Set button

The display show H1

- H1 is coin program 1 / program 1 + to 1 piso coin.
 - Now press + button to program how many 1 piso coin sample to be tested.
 - Standard = 10
 - Best = 20
- Done for H1

Press Set button

The display show P1

- P1 is pulse value of coin 1 / 1 piso + 1 pulse value.
 - Now press + button to program how many pulse on 1 piso coin and minus - button to decrease.
 - 1 pulse = 1 piso
 - 5 pulse = 5 piso
 - 10 pulse = 10 piso
- Done for P1

Press Set button

The display show F1

- F1 is the accuracy / sensitivity of the coin
 - Standard = 8

Done for F1

Press Set button

The display show H2 ready to set coin sample #2

Repeat process H2, P2,F2, for coin sample #2

Repeat process H3, P3,F3, for coin sample #3

Can program upto 6 sample coin H6, P6, F6,

Done programming, next is actual coin calibration.

ACTUAL COIN CALIBRATION

Press Set button

- The display show "A"

Press Set button

- The display show "A1"
 - First coin sample, insert 10 pcs Old 1 piso coin sample. After inserting 10 pcs coin the display automatically change to "A2".
- The display show "A2"
 - second coin sample, insert 10 pcs New 1 piso coin sample. After inserting 10 pcs coin the display automatically change to "A3".
- The display show "A3"
 - 3rd coin sample, insert 10 pcs Old 5 piso coin sample. After inserting 10 pcs coin the display automatically change to "A4".
- The display show "A4"
 - 4th coin sample, insert 10 pcs New 5 piso coin sample. After inserting 10 pcs coin the display automatically change to "A5".
- The display show "A5"
 - 5th coin sample, insert 10 pcs Old 10 piso coin sample. After inserting 10 pcs coin the display automatically change to "A6".
- The display show "A6"
 - 6th coin sample, insert 10 pcs New 10 piso coin sample. After inserting 10 pcs coin the display automatically change to "0".
- The display show "0"
 - All done , the coinslot is ready to use.

Reference:

Allan coin slot

