

Location/ Ref Des	Name and Position	Function	Circuit Breaker	Power Source	Remarks
Panel 3 (cont)	ALARM/TONE	Tests lamps in MASTER ALARM pushbuttons, and tests audible warning tone.	LTG: MASTER ALARM (panel 16)	LMP's 28-vdc bus	
	C/W 1	Tests lamps in first bank of warning lights on panel 1.			
	ENG PB-C/W 2	Tests lamps in engine START and STOP lights and in second bank of warning lights on panel 1.			
	C/W 3	Tests lamps in first bank of caution lights on panel 2.			
	C/W 4	Tests lamps in second bank of caution lights on panel 2.			
	COMPNT	Tests lamps in component caution and lunar contact lights.			
16S17	EXTERIOR LTG switch	Controls docking and tracking lights.	LTG: ANN/ DOCK/ COMPNT (panel 11 and panel 16)	CDR's 28-vdc bus	
	DOCK	Energizes docking lights.			
	OFF	Deenergizes docking and tracking lights.			
	TRACK	Energizes tracking light to full (100%) brightness.			
1DS2	LUNAR CONTACT light	Both lights (red) go on when probe(s) on landing gear touches lunar surface, to indicate that descent engine should be turned off.	N/A	N/A	Light goes off when either engine stop switch is pressed.

Mission LM Basic Date 1 February 1970 Change Date
PANEL 5
Page 3-81

Location/ Ref Des	Name and Position	Function	Circuit Breaker	Power Source	Remarks
Panel 5					
1S5	DES RATE switch + 1 FPS center - 1 FPS	Permits establishing LM rate of descent under PGNS control in fixed increments. Each switch actuation provides a discrete pulse, changing the rate of descent by 1 fps.	N/A	N/A	Response to switch commands is monitored on the altitude rate scale of the Range/Range Rate; Alt/Alt Rate indicator. Plus sign denotes increase in engine thrust. Minus sign denotes decrease in engine thrust.
1S3	Engine stop pushbutton	Provides discrete stop signals to descent and ascent engines, independent of setting of ENG ARM switch, except when in abort sequence.	STAB/CONT: ENG ARM (panel 16)	LMP's 28-vdc bus	When pressed, pushbutton remains pressed and illuminated (red). It is reset by pressing it again.
1S2	Engine START pushbutton	Permits immediate manual firing of descent or ascent engine, depending upon setting of ENG ARM switch.	STAB/CONT: ENG START OVRD (panel 11)	CDR's 28-vdc bus	When pressed, pushbutton remains pressed and illuminated (red). Actuation of either engine stop pushbutton interrupts override function, the engine stops, and the START pushbutton light goes out.
1S12	+X TRANSL pushbutton (momentary)	When held pressed, switch provides four-jet translation in +X-direction by energizing RCS direct (secondary) coils. Upon release of pushbutton, signal is removed from coils, terminating jet firings.	STAB/CONT: ATT DIR CONT (panel 11)	CDR's 28-vdc bus	If switch fails closed, circuit breaker must be opened. The secondary coils of the RCS engines will be disabled, resulting in loss of hardover and direct modes.
9S19	MISSION TIMER: TIMER CONT switch	Provides discrete signals to MISSION TIMER indicator.	FLIGHT DISPLAYS: MISSION TIMER (panel 11)	CDR's 28-vdc bus	
AA	START	Enables indicator to count upward from number preset with SLEW CONT switches.			

PANEL
5

Mission LM Basic Date 1 February 1970 Change Date PANEL 6 Page 3-87

Location/ Ref Des	Name and Position	Function	Circuit Breaker	Power Source	Remarks
Panel 6					
184	Engine stop pushbutton	Provides discrete stop signals to descent and ascent engines, independent of setting of ENG ARM switch, except when in abort sequence.	STAB/CONT: ENG ARM (panel 16)	LMP's 28-vdc bus	Pushbutton is pressed on lunar landing, after LUNAR CONTACT lights go on. When pressed, pushbutton remains pressed and illuminated red. It is reset by pressing it again.
12S17	AGS STATUS switch OFF STANDBY OPERATE	Enables astronauts to place AGS in any one of three states. No power is supplied to AGS. Supplies power to ASA heaters. Applies full power to entire ASA and then places AEA in warmup mode. Applies full power to ASA and AEA.	STAB/CONT: AEA (panel 16) STAB/CONT: ASA (panel 16)	LMP's 28-vdc bus	
12DS1	OPR ERR condition indicator (white)	Goes on if astronaut presses incorrect number of pushbuttons for operation being performed, if + or - keys are not pressed first in entering data, and if "8" or "9" is used in entering address (which is limited to octal digits).	N/A	N/A	If too few pushbuttons are pressed, indicator goes on after ENTR or READOUT pushbutton is pressed. If too many pushbuttons are pressed, indicator goes on before ENTR or READOUT pushbutton is pressed. Indicator goes off when CLR pushbutton is pressed.
12M1	Address indicator	Displays digits that identify AEA computer address selected by astronaut via keyboard.	N/A	N/A	Three octal digits must be set on this indicator, using keyboard, before each DEDA operation.
12M2	Data indicator	Displays data to be entered into AEA computer address displayed on address indicator. Displays data selected for readout from AEA computer location identified on address indicator, if READOUT pushbutton is pressed.	N/A	N/A	Five-digit numeric indicator and + and - indicator. Data to be entered are selected by astronaut via keyboard. Updating rate of any changing data selected for readout is limited to two times per second.