

Location/ Ref Des	Name and Position	Function	Circuit Breaker	Power Source	Remarks
Panel 3 (cont)		throw causes continuous two-jet firing for selected axes. As in PULSE position, open loop acceleration is provided; it must be nulled in as during pulse operation.			
11S24	PGNS MODE CONTROL switch	Affects outputs of ACA's, TTCA's and LGC.	N/A	N/A	Switch is associated with ATTITUDE CONTROL switches and GUID CONT switch.
	OFF	Establishes the following conditions: (a) Limits operation of the ACA's to the hardover position. (b) Enables two-get direct attitude control in axis, selected with ATTITUDE CONTROL switches. (c) Disables translation outputs of TTCA's and LGC attitude commands.			TTCA throttle commands are not affected. LGC engine-off signals are not enabled; engine must be manually turned off.
	ATT HOLD	In this mode, astronauts can command angular rates proportional to displacement of ACA's. Mode is functional with either PGNS or AGS controlling operation. When ACA is out of detent, ATTITUDE CONTROL switches set to MODE CONT, and LGC not in control, attitude loops are opened and axis transducers are compared to rate gyro outputs to provide proportional commands. While maneuvering, attitude synchronizers follow as attitude changes. If PGNS control is selected, astronauts can command attitude rates proportional to ACA displacement, and attitude is held when ACA is			When ATTITUDE CONTROL switches are set to PULSE or DIR, following attitude command capabilities result: With GUID CONT switch set to PGNS and one or more ATTITUDE CONTROL switches set to PULSE, attitude hold mode is not affected. With GUID CONT switch set to PGNS and one or more ATTITUDE CONTROL switches set to DIR, ACA displacement of one-fourth of full throw causes continuous two-jet firing for selected axes, without rate feedback interfering with LGC command signals.

Mission LM Basic Date 1 February 1970 Change Date
PANEL 5
Page 3-81

Location/ Ref Des	Name and Position	Function	Circuit Breaker	Power Source	Remarks
Panel 5					
1S5	DES RATE switch + 1 FPS center - 1 FPS	Permits establishing LM rate of descent under PGNS control in fixed increments. Each switch actuation provides a discrete pulse, changing the rate of descent by 1 fps.	N/A	N/A	Response to switch commands is monitored on the altitude rate scale of the Range/Range Rate; Alt/Alt Rate indicator. Plus sign denotes increase in engine thrust. Minus sign denotes decrease in engine thrust.
1S3	Engine stop pushbutton	Provides discrete stop signals to descent and ascent engines, independent of setting of ENG ARM switch, except when in abort sequence.	STAB/CONT: ENG ARM (panel 16)	LMP's 28-vdc bus	When pressed, pushbutton remains pressed and illuminated (red). It is reset by pressing it again.
1S2	Engine START pushbutton	Permits immediate manual firing of descent or ascent engine, depending upon setting of ENG ARM switch.	STAB/CONT: ENG START OVRD (panel 11)	CDR's 28-vdc bus	When pressed, pushbutton remains pressed and illuminated (red). Actuation of either engine stop pushbutton interrupts override function, the engine stops, and the START pushbutton light goes out.
1S12	+X TRANSL pushbutton (momentary)	When held pressed, switch provides four-jet translation in +X-direction by energizing RCS direct (secondary) coils. Upon release of pushbutton, signal is removed from coils, terminating jet firings.	STAB/CONT: ATT DIR CONT (panel 11)	CDR's 28-vdc bus	If switch fails closed, circuit breaker must be opened. The secondary coils of the RCS engines will be disabled, resulting in loss of hardover and direct modes.
9S19	MISSION TIMER: TIMER CONT switch	Provides discrete signals to MISSION TIMER indicator.	FLIGHT DISPLAYS: MISSION TIMER (panel 11)	CDR's 28-vdc bus	
AA	START	Enables indicator to count upward from number preset with SLEW CONT switches.			

PANEL
5