

Falcon Service Manual (3rd Edition)

Document: MAN-FAL-3

Type: Manual

Model: Falcon

Published: 2019-03-01

1 Engine [Ref: S-FAL-1]

Service procedures for the 2.0T and 1.6 litre engine families.

1.1 Ignition System Overview [Ref: S-FAL-1-1]

The 2.0T engine uses one coil-on-plug ignition coil (part IC-2042-A) per cylinder with spark plug set SP-1108. Coils are matched to the engine calibration.

1.2 Ignition Coil Replacement [Ref: S-FAL-1-2]

Remove the engine cover and disconnect the coil connector. Replace ignition coil IC-2042-A as an assembly. Applies to misfire codes P0301 and P0300 after plug condition is confirmed.

1.3 Misfire Diagnosis [Ref: S-FAL-1-3]

For codes P0300 and P0301, swap coils between cylinders and retest. If the misfire follows the coil, replace it. Inspect spark plug set SP-1108 for gap and fouling.

1.4 Exhaust and Catalyst [Ref: S-FAL-1-4]

Catalyst efficiency code P0420 requires upstream and downstream oxygen sensor comparison before replacing catalytic converter CAT-5500.

2 Electrical [Ref: S-FAL-2]

Charging, battery, and control module service.

2.1 Charging System [Ref: S-FAL-2-1]

Test alternator ALT-8810 output under load before replacing battery BAT-1200. Code P0562 indicates system voltage below threshold.

2.2 Engine Control Module [Ref: S-FAL-2-2]

Engine control module ECM-9901 must be programmed with the latest calibration after replacement.

3 Brakes [Ref: S-FAL-3]

Brake system inspection and service.

3.1 Brake Pad Service [Ref: S-FAL-3-1]

Replace front pads with brake pad kit BP-7720. Measure rotor thickness before reuse.