

To Test Liccon 1 Clutch.

* With engine running and in operating screen,

NOTE: If warning alarm is sounding, press **F8** to stop warning alarm through process,

*Press **Shift + K** simultaneously,

*Enter day code and press **F1**,

*Press **I** key and then **F2** key,

*Enter access code **039** and then press **F8** twice,

*Press Enter to go back to operating screen,

*Press **I** key then press arrow keys to get English translation

*Press **F4** (System Special),

*Press **F4** (Other Displays) Till you reach page 4

***binaere messstellan AS-tronic schaltung,**

*Press **F1** to scroll down to binaere messstellan AS-tronic schaltung,

*Press enter,

*Look at line **15**,

***0.0>TCU.MV.10:**

*Look at number under value column, e.g. **444**

*Get number and follow calculation,

$$444 - 82 = 362$$

$$362 / 9.6 = 37.7\text{mm}$$

*If answer is in between 33-41mm, clutch is fine

*If answer is in between 65-70mm, clutch is worn out.

*Press **F8** three times to get back to operating screen.

TO TEST LICCON 2 CLUTCH (SINGLE ENGINE)

*Start engine and get to operating screen,

*Press **F1** on R/H arm rest,

Press **F3** to turn 'P' symbol black,

Move crane slightly forward and backward, then into neutral,

Press **F3** again to engage park brake,

With engine still running,

Press **I** key, then **F6** and enter day code. Press enter,

Press crane button,

Press **Shift+ I** simultaneously,

Find special system then press enter,

Find special view then press enter,

Scroll down with **F1** to control then press enter,

Scroll down with **F1** to chassis then press enter,

Scroll down to **Gear AS Tronic** then press enter,

Find Analogue test value then press enter,

Get number under value line (mm) **KUPPLUNGSWEG**,

E.g. 444,

Follow calculation: $444 - 82 = 362$

$$362 / 9.6 = 37.7 \text{ mm}$$

If answer is between 33-41mm, clutch is fine,

If answer is between 65-70mm, clutch is worn out,

*If number is four digits, just divide by 1000 to get read out.

Press **F8** till you get to special system,

Press crane button to exit.

TO TEST LICCON 2 CLUTCH (SINGLE ENGINE)

*Start engine and get to operating screen,

*Press **F1** on **R/H** arm rest,

Press **F3** to turn '**P**' symbol black,

Move crane slightly forward and backward, then into neutral,

Press **F3** again to engage park brake,

With engine still running,

Press **I** key, then **F6** and enter day code. Press enter,

Press crane button,

Press **Shift+ I** simultaneously,

Find special system then press enter,

Find special view then press enter,

Scroll down with **F1** to control then press enter,

Scroll down with **F1** to chassis then press enter,

Scroll down to **Gear AS Tronic** then press enter,

Find Analogue test value then press enter,

Get number under value line (**mm**) **KUPPLUNGSWEG**,

E.g. 444,

Follow calculation: $444 - 82 = 362$

$$362 / 9.6 = 37.7 \text{mm}$$

If answer is between 33-41mm, clutch is fine,

If answer is between 65-70mm, clutch is worn out,

Press **F8** till you get to special system,

Press crane button to exit.

TO TEST LICCON 2 CLUTCH (TWO ENGINE)

*Start top engine and get to operating screen,

Start bottom engine from top using touch control unit,

Press ignition button (left button, second from the bottom on BTT)

Press start button (left button, bottom row on BTT),

*Press F1 on R/H arm rest,

Press F3 to turn 'P' symbol black,

Move crane slightly forward and backward, then into neutral,

Press F3 again to engage park brake,

With engine still running,

Press I key, then F6 and enter day code. Press enter,

Press crane button,

Press Shift+ I simultaneously,

Find special system then press enter,

Find special view then press enter,

Scroll down with F1 to control then press enter,

Scroll down with F1 to chassis then press enter,

Scroll down to Gear AS Tronic then press enter,

Find Analogue test value then press enter,

Get number under value line (mm) KUPPLUNGSWEG

E.g. 444,

Follow calculation: $444 - 82 = 362$

$$362 / 9.6 = 37.7 \text{ mm}$$

If answer is between 33-41mm, clutch is fine,

If answer is between 65-70mm, clutch is worn out,

***If answer is four digits, just divide by 1000 to get answer.**

Press F8 till you get to special system, Press crane button to get out.