

MOV:

MOV r4,r0
Save r0 in r4.

MOVS:

加立即数imm
MOVS r7,#0xf
Save 0xf in r7

PUSH:

PUSH {r4-r7,lr}
Saves registers r4-r7 and LR on stack to save registers which need to be restored to their original values.

POP:

POP {r4-r7,pc}
Fetch registers r4-r7 and LR on stack to save registers which need to be restored to their original values.

STR:

STR r0, [sp, #0x10]
Store r0 on stack at offset 0x10.

LDR:

LDR r0, [sp, #0x10]
Load register from address (sp + 0x10) into r0

SXTB:**STRB:**

STRB r0, [r4,#0]
Store one-byte result in memory location pointed to by r4.

MVNS:

Move NOT with Status
MVNS r0,r0