

heartBeatEVT

Overview

`heartBeatEVT` is a **device-emitted** event — the reader publishes it on its own, with **no command triggering it**, to signal that it is alive and to report basic health: uptime, an event sequence number, and optional **inventory** and **battery** sub-payloads. It is read-only telemetry and carries no credentials.

You **enable** a heartbeat rather than requesting it. The reader publishes `heartBeatEVT` at the interval you set in `heartbeatConfiguration` once the heartbeat is enabled with `config_events` (see [Event Semantics](#)).

The reader publishes `heartBeatEVT` at the configured interval (at most 65,535 seconds) while the heartbeat is enabled with `config_events`; a reboot applies the setting. Monitoring can rely on it as its primary liveness signal: when `heartBeatEVT` stops arriving, the reader, its session, or the path to your application needs attention. `heartBeatEVT` is published at [QoS 0](#), so the MQTT layer does not resend one lost in transit. Choose how many missed intervals your application treats as an outage.

Details

Property	Value
Event Type	Heartbeat (periodic liveness / health)
Trigger	Timed interval (every <code>heartbeatConfiguration.interval</code> s while enabled)
Enabled By	<code>config_events</code> with <code>eventConfiguration.heartbeat: true</code> (plus <code>heartbeatConfiguration</code>), applied on <code>reboot</code>
Applies To	Endpoint: Management (MGMT). Reader: RFD40 series, RFD90 series
Credentials	None (read-only telemetry, nothing to mask)
Interaction Pattern	Publish / Subscribe (device-emitted, unsolicited; no request/response, no <code>response.code</code>)
Related	dataEVT , alerts , mqttConnEVT

When to Use

Subscribe to `heartBeatEVT` when you want **continuous, pushed telemetry of reader liveness and health** — uptime, an event sequence number, and optional inventory and battery status — rather than polling for it on demand. It is the asynchronous twin of `get_status` (`heartBeatEVT` ↔ `get_status`): the heartbeat *pushes* health at a fixed interval, while `get_status` *pulls* a correlated snapshot when you ask.

- **Receive:** periodic `heartBeatEVT` payloads on the management event topic once the heartbeat is enabled and the reader has rebooted.
- **Use it for:** liveness monitoring (the *absence* of an expected heartbeat is itself a signal), tracking RFID inventory progression, and routine battery monitoring — without issuing a command per check.
- **Prefer a different call when:** you need an immediate, on-demand reading — call `get_status` instead. It returns a synchronous device-health and battery snapshot in a correlated response (note it does not include the heartbeat's inventory scan counts or uptime).

Topic Mapping

`heartBeatEVT` is device-emitted and flows on the **management event topic** — it has no `cmd` / `resp` topics of its own because no command produces it.

Message	Direction	Topic	Note
Event	Reader → App	<code><tenantId>/MGMT/clients/event/<serial></code>	Published on the management endpoint's event topic.

Topics follow the pattern `<tenantId>/<topic>/<serial>` — the tenant id assigned to you at provisioning (a slot you fill in, never a literal), the base topic you configure on the endpoint, and the reader's serial number, which the reader appends itself in its model-prefixed form (for example `RFD40-212735201D0053`). `App → Reader` means your app publishes and the reader subscribes; `Reader → App` means the reader publishes and your app subscribes.

The event arrives on the same management-event plane you enabled it on with `config_events`.

See [Topics and Channels](#).

Key Fields

- `eventName` (event) — names the event; the fixed value `heartbeat`. Required.
- `timestamp` (event) — ISO-8601 time the heartbeat was generated. Required.
- `eventNumber` (event) — a unique identifier or sequence number for the event. The schema does not guarantee it is monotonic or contiguous, so a gap between consecutive heartbeats is not necessarily a missed heartbeat. Required.
- `data.inventoryStatus` (event) — RFID scan state (`rfidStatus`), plus `tagCount` and `scanCount`. Present when `heartbeatConfiguration.inventoryStatus` is `true`.
- `data.batteryAlert` (event) — battery `status`, `stateOfHealth`, and `chargePercentage`. Present when `heartbeatConfiguration.batteryStatus` is `true`.
- `heartbeat` (request) — the gate flag in `config_events`; the heartbeat publishes only once `heartbeat: true` and `heartbeatConfiguration.interval` is set (at most 65,535 seconds) (see [Event Semantics](#)).

Event Payload

The top-level shape is `eventName`, `timestamp`, `eventNumber` (all **required**), an optional `upTime`, and an optional `data` object carrying the inventory and/or battery sub-payloads. Use the **Schema** tab for the field reference and the **Example** tab for a full heartbeat.

Event payload

Example: inventory + battery

```
1  {
2    "eventName": "heartbeat",
3    "timestamp": "2019-08-24T14:15:22Z",
4    "eventNumber": 120,
5    "data": {
6      "inventoryStatus": {
7        "rfidStatus": "INPROGRESS",
8        "tagCount": 45,
9        "scanCount": 128
10     },
11     "batteryAlert": {
12       "status": "HIGH",
13       "stateOfHealth": "GOOD",
14       "chargePercentage": 85
15     }
16   }
17 }
```

Event payload

* required • — not applicable • Colored badge = JSON type

#	FIELD	TYPE	ENUM / UNITS	EXAMPLE	DESCRIPTION
1	eventName *	string	—	heartbeat	Names the event — the fixed value heartbeat for this event.
2	timestamp *	string	—	2019-08-24T14:15:22Z	ISO-8601 time the event was generated.
3	eventNumber *	integer	—	120	A unique identifier or sequence number for the event. The schema does not guarantee it is monotonic or contiguous per heartbeat.
4	uptime	string	—	5 days 4hr 3min	Device uptime when the event was generated. Free-form human-readable string (not a duration type).
5	data	object	—	—	Optional health payload. The schema declares it as anyOf two flat shapes — the inventory fields or the battery fields below — while the contract's example nests them as data.inventoryStatus and data.batteryAlert (see Field Support). Which appear is gated by heartbeatConfiguration (see Event Semantics).

#	FIELD	TYPE	ENUM / UNITS	EXAMPLE	DESCRIPTION
6	r f i d S t a t u s	enum	INPROGRESS STOPPED	—	The current status of the RFID scanning process.
7	t a g C o u n t	integer	—	—	The total number of RFID tags scanned in the current operation.
8	s c a n C o u n t	integer	—	—	The total number of scan attempts made during the operation.
9	s t a t u s	enum	LOW CRITICAL CHARGING FULL HIGH	LOW	The current status of the battery, which indicates its operational state.

#	FIELD	TYPE	ENUM / UNITS	EXAMPLE	DESCRIPTION
10	status	enum	GOOD CRITICAL MODERATE	—	The overall health of the battery, which reflects its long-term capacity and performance.
11	chargePercentage	integer	max 100	—	The current charge level of the battery, represented as a percentage.

In the examples, `data` nests its sub-payloads, and a heartbeat may carry **one, both, or neither** of `inventoryStatus` and `batteryAlert` (the schema declares a flatter shape — see [Field Support](#)). The `heartbeatConfiguration` inclusion flags you set when enabling the heartbeat control which ones appear:

- `inventoryStatus` — RFID scan state (`rfidStatus`), plus `tagCount` and `scanCount` . Present when `heartbeatConfiguration.inventoryStatus` is `true` .

- `batteryAlert` — `battery` `status`, `stateOfHealth`, and `chargePercentage`. Present when `heartbeatConfiguration.batteryStatus` is `true`.

Event Semantics

Emission

Enable the heartbeat with `config_events` under `eventConfiguration`: set `heartbeat` to `true` and `heartbeatConfiguration.interval` to a value of at most 65,535 seconds. The contract documents no default for either. After the reader has rebooted, it publishes `heartBeatEVT` every `heartbeatConfiguration.interval` seconds on the management event topic.

Field	Type	Meaning
<code>heartbeat</code>	boolean	Set <code>true</code> to enable the heartbeat stream.
<code>heartbeatConfiguration.interval</code>	integer (seconds)	Seconds between heartbeats. Lower = more telemetry, higher battery cost.

Enable the heartbeat via config_events

```
1  {
2    "command" : "config_events",
3    "requestId" : "abc123",
4    "eventConfiguration" : {
5      "terminalConnection" : true,
6      "firmwareUpdate" : true,
7      "network" : true,
8      "heartbeat" : true,
9      "power" : true,
10     "battery" : true,
11     "temperature" : true,
12     "fileDownload" : true,
13     "heartbeatConfiguration" : {
14       "interval" : 100,
15       "inventoryStatus" : true,
16       "batteryStatus" : true
17     }
18   }
19 }
```

`config_events` stores the heartbeat configuration immediately (confirm it with `get_endpoint_config`), but the reader begins emitting only after a `reboot`. Also note `heartbeatConfiguration` appears in a `get_endpoint_config` read only after `config_events` sets it — it is absent from a default read. See `config_events` for the full enable workflow.

- **If no heartbeat arrives.** Read the endpoint configuration with `get_endpoint_config` and confirm `heartbeat: true` and an `interval` of at most 65,535. Confirm that the reader has rebooted since you sent `config_events`, and that you subscribed to the management event topic; a heartbeat published before your subscription is active is not delivered later.

Shaping

The `heartbeatConfiguration` inclusion flags shape each heartbeat's optional `data` object — they select which sub-payloads a heartbeat carries, independently of the enabling above.

Field	Type	Meaning
<code>heartbeatConfiguration.inventoryStatus</code>	boolean	Include the <code>data.inventoryStatus</code> block in each heartbeat.
<code>heartbeatConfiguration.batteryStatus</code>	boolean	Include the <code>data.batteryAlert</code> block in each heartbeat.
<code>heartbeatConfiguration.userApps</code>	boolean	Declared for a <code>data.userApps</code> block. Not supported: firmware does not implement user-application status, so no heartbeat carries it.

Because every member of `data` is optional, a heartbeat carries one, both, or neither of `inventoryStatus` and `batteryAlert`, depending on these flags. Set them alongside the enable flags via `config_events`.

Field Support

- **The schema and the example disagree on the shape of `data`.** The schema declares `data` as `anyOf` two flat objects — `rfidStatus` / `tagCount` / `scanCount`, or `status` / `stateOfHealth` / `chargePercentage` — so those fields would sit directly under `data`. The contract's own example, like every example on this page, nests them as

`data.inventoryStatus` and `data.batteryAlert`; it validates only because neither branch forbids extra keys. Parse the nested form shown here, and tolerate the flat form.

- `stateOfHealth` is not a charge band. `batteryAlert.stateOfHealth` is enumerated `GOOD` / `CRITICAL` / `MODERATE`. `FULL` is a value of `status`, not of `stateOfHealth`, so a payload carrying `stateOfHealth: "FULL"` is outside the enum. Trust the enum.
- `batteryAlert.stateOfHealth` is the same health grade as `get_status`. The value set here is `GOOD` / `CRITICAL` / `MODERATE`, and `get_status` reports `deviceStatus.batteryStatus.stateOfHealth` from that same enum. One grade, so nothing needs translating when you share battery logic between the heartbeat and the command. The battery's charge state is the separate `status` field. See [get_status](#).
- **Required fields and** `upTime`. `eventName`, `timestamp`, and `eventNumber` are required; `upTime` and `data` are optional. `upTime` is a **free-form string** (e.g. `"5 days 4hr 3min"`), not a machine-parseable duration — do not parse it as a number.

Examples

A heartbeat carrying **both** sub-objects appears in the **Example** tab of the payload above. The variants below show the minimal required-only shape and an inventory-only heartbeat.

The minimum a heartbeat must carry (the three required fields; `data` and `upTime` omitted):

heartBeatEVT — minimal (required fields only)

```
1  {
2    "eventName" : "heartbeat" ,
3    "timestamp" : "2019-08-24T14:15:22Z" ,
4    "eventNumber" : 121
5  }
```

An **inventory-only** heartbeat (`heartbeatConfiguration.inventoryStatus: true`, `batteryStatus: false`):

heartBeatEVT — inventory status only

```
1  {
2    "eventName" : "heartbeat" ,
3    "timestamp" : "2019-08-24T14:15:37Z" ,
4    "eventNumber" : 122 ,
5    "data" : {
6      "inventoryStatus" : {
7        "rfidStatus" : "STOPPED" ,
8        "tagCount" : 45 ,
9        "scanCount" : 128
10     }
11   }
12 }
```

Notes and Caveats

- **No response envelope.** `heartBeatEVT` is a device-emitted event, so it carries no `response` / `code` — the command response-code table does not apply. No response code is defined for any event.

`heartBeatEVT` is **read-only telemetry** and carries no credentials. Use it for liveness checks (the *absence* of expected heartbeats is itself a signal), inventory progression, and routine battery monitoring. For the concept-level view, see [MQTT Connectivity](#) and Monitor Reader Health and Battery.

Related:  [config_events](#) ·  [get_endpoint_config](#) ·  [Events](#) ·  [dataEVT](#) ·  [MQTT Connectivity](#) ·  [Events](#)