



Upgrading the ZeroNoise Wired Wireless (WW) System to a new firmware version



Scan for full product
instructions



Short guide for firmware update

When a new firmware is released for bug fixing and general improvements of the product, this simple procedure can be followed to upgrade the WW System components

This short guide shows how to update the intercom and the units

What you will need to perform the required steps:

Helmet Unit procedure

- A PC and a USB-A to USB-C cable

Intercom Display and Device

- A device capable to be connected in Wi-Fi that has the new firmware version on it

Intercom Unit: display

1. Turn ON the Intercom.
2. Connect the device that has the last version of the firmware to the Intercom Wi-Fi. The password of the Wi-Fi is PasswordABCD, where ABCD are the same of the Wi-Fi you are connecting.
3. Open a Browser and go to the page 192.168.4.1/update.
4. Select “click to select (.bin) file” and select the last firmware version from the device.
5. Wait for the bar to reach 100%. Once completed, the Display will automatically reset.
6. Reset the Intercom.

⚠ Non sicuro 192.168.4.1/update



Drag and drop here
or
click to select (.bin) file

SETTINGS

OTA Mode

Firmware

Dark UI



LCD Version

1.0.0

Mainboard Version

1.0.0

Intercom Unit: device

1. Turn ON the Intercom.
2. Connect the device that has the last version of the firmware to the Intercom Wi-Fi. The password of the Wi-Fi is PasswordABCD, where ABCD are the same of the Wi-Fi you are connecting.
3. Open a Browser and go to the page 192.168.4.1.
4. Select “Modalità Aggiornamento”.

⚠ Non sicuro 192.168.4.1



WIRED WIRELESS Intercom

Scegli una modalità:



Modalità Aggiornamento

IT Italiano ▼

Intercom Unit: device

5. Select “Scegli File” and select the last firmware version from the device, then press “Carica firmware”.
6. Wait for the first bar to reach 100%, then press “Avvia aggiornamento”.
7. Wait for the second bar to reach 100%. Information about the good end of the process will be shown.
8. Reset the Intercom.

⚠ Non sicuro 192.168.4.1/upload

Aggiorna WIRED WIRELESS

IT Italiano ▾

 Scegli file

 Carica firmware

0%

 Avvia aggiornamento

0%

 Torna alla Home

Helmet Unit

1. Connect the unit to your computer using the USB-C port on the bottom part of the helmet side cover: the unit will turn on automatically
2. Quickly press 5 times the ON/OFF button positioned on the bottom part of the helmet side cover
3. Your computer should now recognize the helmet unit as an external memory device named RPI-RP2
4. Now you can simply copy and paste (or drag and drop) the firmware file into the RPI-RP2 device
5. Firmware file for helmet unit: WW_PU_v4.0.0_RELEASE.uf2
6. After the firmware upload is successful, you can disconnect the device from the computer and reboot it

