

Air Compressor Maintenance Manual

Normal Parameters:

Discharge Pressure: 6-8 bar

Motor Temperature: Below 80°C

Inspection Activities:

- Check oil level.
- Inspect air filters.
- Verify cooling fan operation.
- Monitor vibration.

Failure Modes:

- Bearing failure
- Air leakage
- Overheating
- Lubrication issues

Maintenance Interval:

Monthly inspection. Quarterly overhaul.