

Continuous Caster Roll Change SOP

Objective:

Replace damaged caster rolls safely.

Procedure:

1. Stop casting operation.
2. Lock equipment.
3. Remove damaged roll.
4. Inspect bearing housing.
5. Install replacement roll.
6. Verify alignment.
7. Resume operation.

Inspection Points:

- Roll wear
- Bearing condition
- Alignment accuracy