

Gearbox Alignment SOP

Objective:

Ensure proper alignment between gearbox and motor.

Procedure:

1. Shutdown equipment.
2. Apply lockout/tagout.
3. Inspect coupling.
4. Measure alignment.
5. Adjust position.
6. Recheck readings.
7. Restart equipment.

Failure Symptoms:

- Excessive vibration
- Coupling wear
- Oil leakage
- Bearing overheating