

CCM Maintenance Manual

Continuous Casting Machine Segment Bearings Normal operating temperature: 40-75°C Warning temperature: 75-90°C Critical temperature: Above 90°C Normal vibration: Less than 4 mm/s Warning vibration: 4-8 mm/s Critical vibration: Above 8 mm/s Common failure causes: 1. Lubrication failure 2. Water ingress 3. Bearing fatigue 4. Misalignment 5. Overload condition Recommended action: Immediately inspect bearings when temperature exceeds 90°C or vibration exceeds 8 mm/s. Typical RUL after critical alarm: 24-72 hours.