

1. We add sentences to NOTE of Section 3.1 last.

NOTE

- 1 When you change "Number of Stations", "Number of AIs" or "Number of AOs", clear the current I/O assignment by pushing NEXT and F1(CLR_ASG). The changes will be activated at the next power-on. Clear assignment may be necessary before changing assignment.

Add

If clear assignment isn't done, I/O communication may not be done. If it doesn't work fine, try clear assignment or do whenever possible.

- 2 When you change "Station No." or its following items, cycle power to activate the changes.
- 3 In case that two CC-Link communication boards are installed to a robot, the board which has a smaller physical slot number will be "Board1" and another will be "Board2". For information of the physical slot number, refer to "B.1 Installation".
- 4 The values set on this screen will be saved in the system file "CCLINK.SV." To save settings of the CC-Link, press [FCTN] key and select "SAVE" when displaying any CC-Link screen. You can also save it from FILE screen -> F4 key BACKUP -> "1 System files" or "8 All of above". To select a device for saving, press [F5] "UTIL" on the file screen and select "Set Device".

Add

Please check whether CCLINK.SV is wrote because writing is missed when device is write protected even when prompt shows them as saved.

- 5 If an out of range value is entered into a remote register, "PRIO-331 CC-LK Reg data invalid (Board No.)" will be posted and zero value will be sent to master device instead of the invalid register data.

2. We add Subsection 2.3.1 to end of Section 2.3.

2.3.1 How to send the integer other than 16 bit (signed / unsigned) integer or real number

You should use 2 register to send them. Concretely, for example, set integral part of the value, which is divided by 65536 from sent value, to R[2], set the odd to R[1], and send both register by CC-Link.

Example of TP program (When you want to send R[100])

```
R[1] = R[100] MOD 65536
// Pay attention R[100] isn't changed at here.
R[2] = R[100] DIV 65536
```

When you want to receive the value larger than 65535, convert the value received by 2 register.

Example of TP program (When you convert received data by R[1] and R[2] to R[100])

```
R[100] = R[2] * 65536 + R[1] (Pay attention R[1] and R[2] are changed during running this line.)
```

You can send the value less than signed 16 bit value or real number by similar way.

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

3. We add a sentence to Section A.1.

A. 1 REMOTE INPUT RX/REMOTE OUTPUT RY

The following shows the memory mapped profile of Remote Input(RX) and Remote Output(RY). The set of 16 bits located at the bottom is “System area.” The “System area” can not be used for any purposes other than the usage defined by CLPA.

Initial data setting isn't necessary for CC-Link of robot controller.

Add

						Title	FANUC Robot Series R-30iA/R-30iA Mate/R-30iB CONTROLLER CC-Link Interface (Slave) Operator's Manual Description is added					
							Draw No.	B-82654EN/04 - 01				
01	2017.05.08	S. Ozaki	Initial release			FANUC CORPORATION					Page	3/3
Ed.	Date	Design	Description									
	Date	2017.05.08	Design.	S. Ozaki	Apprv.							