

SX126x 驱动 demo 使用说明

修	改记录	₹	. 1
		用法	
		硬件和连线	
		软件 demo 用法	
2.		移植	

修改记录

	类型	修改内容	修改人	日期	固件版本	文档版本
	А	初稿版本	杨宾	2021/02/26	V0.0.0	V0.0.0

类型: A-新增 M-修改 D-删除

1. Demo 用法

1.1 硬件和连线

该 demo 是用 STM32F103C8T6 单片机驱动的 SX126x demo,硬件接线如下

STM32F103	RA-01S(H)(C)
3V3	3V3
GND	GND
PA9(uart1 TX 用于查看 log 波特率 115200)	
PA10(uart1 RX 用于查看 log 波特率 115200)	
PA4	NSS
PA7	MOSI
PA6	MISO
PA5	SCK
PB1	RST
PB11	DIO1
PA0	BUSY

1.2 软件 demo 用法

软件 demo 应用例子可以参考 peripherals\radio\sx126x_example 目录下的 demo,具体效果可以查看 demo 中的使用说明

然后在 main 函数中打开对应 demo 的例子即可(注意一个模组只能打开一个 demo,测试收



发可以一个烧录接收程序,一个烧录发射程序)

例如

发射端烧录发射 demo

```
main.c SX126xSTM32F103-board.c project_config.h sx126x_example
     5 #include "stm32f10x_it.h"
6 #include "project_config.h"
7 #include "sx126x_example_send.h"
8 #include "sx126x_example_recive.h"
 NVIC_PriorityGroupConfig(NVIC_PriorityGroup_4): //NVIC(中断优RC_APB2PeriphClockCmd(RCC_APB2Periph_AFIO, ENABLE): //JGPIO_PinRemapConfig(GPIO_Remap_SWJ_JTAGDisable,ENABLE): //美能
                 //led描示灯
RCC_APB2PeriphClockCmd(RCC_APB2Periph_GPIOB, ENABLE);
GPIO_InitStructure.GPIO_Fin = GPIO_Pin_12:
GPIO_InitStructure.GPIO_Mode = GPIO_Mode_Out_PP; //推換輸出
GPIO_InitStructure.GPIO_Speed = GPIO_Speed_50MHz; //IO口速度
GPIO_Init(GPIOB, &GPIO_D InitStructure);
GPIO_SetBits(GPIOB,GPIO_Pin_12); //PB.12 輸出高
                printf("SysInit OK, version:%s\r\n", SOFT_VERSION);
              //測试demo。一个程序只能打开一条测试demo,进入测试demo后将进入死/
//ExampleSX126xRectveDemo(): //備対接収demo
ExampleSX126xSendDemo(): //定时发送demo
                     hile(1) {
    printf("systick=%d\r\n",Get_SysTick());
    GPIO_ResetBits(GPIOB,GPIO_Pin_12);
```


接收端烧录接收 demo

```
32F103C8Den 🗸 🔊 🔓 💝 🕸
                                main.c* SX126xSTM32F103-board.c project_config.h sx126x_exa
                                                                #include "stm32f10x_it.h"
#include "project_config.h"
#include "sx126x_example_send.h"
#include "sx126x_example_recive.h"
                                                                 //硬件初始化
                                           NVIC_PriorityGroupConfig(NVIC_PriorityGroup_4): //NVIC(中自RCC_APB2PeriphClockCmd(RCC_APB2Periph_AFIO, ENABLE); GPIO_PinRemapConfig(GPIO_Remap_SWJ_JTAGDisable,ENABLE); //
                                           14
15
                                           16
17
18
19
                                                                         //led指示灯
RCC_APB2PeriphClockCmd(RCC_APB2Periph_GPIOB, ENABLE);
GPIO_InitStructure.GPIO_Pin = GPIO_Pin 12;
GPIO_InitStructure.GPIO_Mode = GPIO_Mode_Out_PP; //推挽等
GPIO_InitStructure.GPIO_Speed = GPIO_Speed_50MHz; //IO口证GPIO_InitGPIOB, &GPIO_InitStructure);
GPIO_SetBits(GPIOB, GPIO_Pin_12); //PB. 12 输出高
                                         20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
40
41
42
43
44
45
46
47
                                                                            HALUart1Init();
SysTick_Config(SystemCoreClock/1000);
                                                          □ int main(void) {
    SysInit(); //硬件初始化
                                                                            printf("SysInit OK, version:%s\r\n", SOFT_VERSION);
                                                                                                                                                                                                                                                                                                                        widdemo后将进)
                                                                      ExampleSX126xReciveDemo(): //循环接收demo
//ExampleSX126xSendDemo(): //定时发送demo
                                                                              //开启测试demo后代码就执行不到这里了
                                                                            // 并無明はEMPU/FINESSEE | The Manual | The Man
                                                                                       delay_ms(500);
```

2. 驱动移植

驱动移植首先将 peripherals\radio 目录添加到自己的工程中,例如





并添加头文件路径

然后参考 HAL\SX126xSTM32F103-board.c 自己新建一个中间层文件,用于实现该文件中的功能(主要包含 GPIO,外部中断,SPI 和定时器的驱动)

当上面的 board 文件移植完成后驱动就基本可用了

注意:如果包含文件系统,需要实现 peripherals\radio\sx126x-board.h 中关于临界区保护的宏定义,否则多任务的时候可能会出错

